正面
（front）

背面
（Back）

Wireless Speaker

USER MANUAL

RS055

Specifications

Item No.	RS055
Battery Capacity	400mAh
Type-C Input	DC 5V
Loudspeaker Output	5W
Operating Distance	≤10m
Frequency Response	20Hz-20KHz
Signal-To-Noise	≥85dB
Distortion	≤1.0%
Dimensions	59.7x59.7x44.6mm

Package Contents

Speaker x1
Travel Ring x1   Charging Cable x1   User Manual x1   Universal Magnetic Ring x1

Product Features

①
⑥
④   ⑤   ③   ②

1. Power Button(Play/ Pause)
2. Type-C Input
3. Lanyard
4. Universal Magnetic Ring
5. Travel Ring
6. LED Indicator

Operating Instructions

Wall charger or power adapter with USB port output
Computer USB port

Charging the Speaker

Use the included Type-C cable to connect to the speaker to a wall charger or power adapter(not included).

The LED indicator will turn on while charging and turn off once the speaker is fully charged.

Audio Playback Mode

1. Power on the speaker: Press and hold the

speaker for 3 seconds. A prompt tone will sound, and the LED indicator will begin flashing blue slowly, indicating that the speaker has entered Bluetooth pairing mode.

2. Enable Bluetooth on your phone or other device, search for"RS055" in the list of available devices and select it to pair. A prompt tone will confirm successful pairing. Once connected, audio from your device will play through the speaker.

3. Adjusting the Volume: Use the volume buttons on your device to increase or decrease the speaker's volume.

Note: Make sure to disconnect the speaker from any previously connected Bluetooth devices before pairing a new one.

TWS (True Wireless Stereo) Mode

1. Turn on both speakers you want to connect in

TWS mode.
2. On one of the speakers, quickly press the power button three times in a row to activate TWS pairing mode. A prompt tone will indicate successful connection.
3. Enable Bluetooth on your phone or device, search for"RS055"in the available devices list, and connect. Once paired, both speakers will play audio simultaneously.
4. After successful pairing, the two speakers will automatically connect in TWS mode the next time they are powered on.
5. To exit TWS mode, quickly press the power button three times on either speaker.

Universal Magnetic Ring(included)

Attach the non-magnetic portion of the ring to the outside of a smooth, flat phone case for optimal alignment. This features strong and reliable

adhesion.
Note: Not recommend for direct application to your phone.

Selfie Mode
After successfully pairing your phone with the speaker via Bluetooth, open your phone's camera app.

1. Activate Selfie Mode: Double- press the speaker's power button.
2. Take a Photo: Press the power button once.
3. Exit Selfie Mode: Double-press the power button again.

Note: These steps are compatible with Apple, Samsung and most other smartphones. Some models may not allow entering or exiting selfie mode separately -simply pressing the button once may be enough to take a photo.

Tips

1. Bluetooth connection and transmission can be influenced by nearby obstacles, such a trees, metal objects, or other materials that may block or absorb the signal, reducing the effective range.
2. Fully charge the speaker before first use. As the battery level drops, sound quality may be affected---recharge the speaker as needed.
3. Keep the speaker away from high-temperature environments to prevent damage.

FAQs

1. Why won't the speaker turn on?
The battery may be low. Recharge thes peaker and try turning it on again.

2. Why isn't the speaker charging?
Ensure the power source or wall charger is functioning properly and that it provides a DC 5V Output. Also, check that the charging cable and connectors are in good condition.

3. Why is there no sound from the speaker?
Confirm that the speaker is paired with the correct Bluetooth device. Make sure it is disconnected from any other Bluetooth connections. Also, check that the volume on your phone is turned up.