thumbsUp!

ARWORK INFORMATION PANEL

PRODUCT NAME: TRUE WIRELESS EARPHONES

ARTWORK TYPE: ☐ PRODUCT ☐ PACKAGING ■ MANUAL ☐ STICKER

MATERIAL: 90gsm

FINISH: uncoated

CUTTER GUIDE SIZE: 80 X 95mm (when folded)

PRODUCT CODE:

BARCODE:

TYPE: EAN 13, 80%

CMYK	SPECIFIC PANTONE COLOURS	FOLDING GUIDE	CUTTER GUIDE
	Spot Colour 'Folding'	To prevent possible bearing damage, do not listen at high volume levels for long periods	Spot Colour 'Cutter guide'

FONT LISTING:

WHERE	WHAT
1.	Product Title
2.	General Text
3.	TU Details
4.	Warnings

NOTES:

Black and white print.
Double sided print
Folded manual.

VERSION DATE:

DATE	DESIGNER
16/12/2019	SHANE O'CONNELL

WHEN SENDING FINAL ARTWORK TO FACTORY PLEASE MAKE SURE ALL FONTS HAVE BEEN OUTLINED, AND ALL IMAGED EMBEDDED.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

FCC ID: 2AHHETWSEWZPRM

Primark Limited
PO Box 842
Arthur Street West
2024 Penrell Street
Dublin 1
Ireland

Primark Tandas S.L.U
Gran Via, 32, 3
Madrid
28013
CIF – B86975427

Primark US Corp.
101 Arch Street,
Boston, MA 02110
Tax ID: 046-5476
Season Code: 5920

Made in China / Fabricado en China
Fabricado en China / Fabricado en China
Fabriqué en Chine / Gefertigt in China
Prodotto in Cina / Feito na China
Erdeleno na Kitajskem / Vyrobeno v Číně

TRUE WIRELESS EARPHONES

INSTRUCTIONS

EN TWS Earphones

Contents:
Charge Box
x1 Bluetooth Earphone
Silicone Earbuds
USB Charging Cable

LED Light Functions:
Charge Box: Red light is light will switch on
Pulse (charge): The Red light will switch off
Flashing (charge): Charge Box is fully charged
Flashed OK (Blue and red light flash rapidly)
Pulse (Pair): Blue and red light flash slowly
Flashing (Pair): Red and blue lights flash alternately

Power On:
Take out the earphones from Charge Box, they should switch on and interconnect automatically.
If for any reason the earphones are not paired, switch off the earphones, place back into the charging case for 3 seconds, then take the ones was 'paired' to the charging case out and they should pair automatically.
To Turn Off press the function button for 3 seconds, the LED will flash red, then the LED will flash rapidly, and then when you hear a beep (Between the voice saying 'pairing' again, the earphones should automatically pair.

Connecting to Bluetooth:
Turn on the Bluetooth function on your smartphone or other device, and the "TWS EARPHONES" will select to pair the earphones to the device.
Once the device has successfully paired to the earphones, the earphones will beep twice and the LED will stay on.
If you do not receive the voice/music do not connect you only have sound through one earphone, switch off both earphones and place back into the charging case for step 2 and then repeat the steps in Connecting to Bluetooth (Pairing) Mode.
•Pairing Distance Mode: take out either the L or the R earphone and pair it to your phone or device to pair the Earphone mode.

Listening to music:
•Press the function button once to pause and play music.
•Long press the right earphone's function button for two seconds and release to skip to the next track.
•Long press the left earphone's function button for two seconds and release to skip back to the previous track.
•Long press the function button for three seconds and release to quick increase the volume.

Answered calls:
•Press either function button once to answer and again to end a call.
•Long press the function button for 2 secs and release to reject incoming calls.

Charging the Earphones:
•Place earphones back in Charging box you will hear an audibe beep and the LED will flash slowly.
•When earphones OFF before charging, the LED will stay on for 3 seconds then flash slowly.
•When earphones are in the charging box and fully charged, the red light will turn to blue.
•Pulsing: The red and blue lights flicker alternately.

Power On:
•Take out the earphones from Charge Box, they should switch on and interconnect automatically.
•If for any reason the earphones are not paired, switch off the earphones, place back into the charging case for 3 seconds, then take the ones was 'paired' to the charging case out and they should pair automatically.
•To Turn Off press the function button for 3 seconds, the LED will flash red, then the LED will flash rapidly, and then when you hear a beep (Between the voice saying 'pairing' again, the earphones should automatically pair.

Connecting to Bluetooth:
•Turn on the Bluetooth function on your smartphone or other device, and the "TWS EARPHONES" will select to pair the earphones to the device.
•Once the device has successfully paired to the earphones, the earphones will beep twice and the LED will stay on.
•If you do not receive the voice/music do not connect you only have sound through one earphone, switch off both earphones and place back into the charging case for step 2 and then repeat the steps in Connecting to Bluetooth (Pairing) Mode.
•Pairing Distance Mode: take out either the L or the R earphone and pair it to your phone or device to pair the Earphone mode.

Listening to music:
•Press the function button once to pause and play music.
•Long press the right earphone's function button for two seconds and release to skip to the next track.
•Long press the left earphone's function button for two seconds and release to skip back to the previous track.
•Long press the function button for three seconds and release to quick increase the volume.

Troubleshooting:
If the device fails to pair more than twice:
1.Double check that the product is compatible with your device
2.Turn off your Bluetooth device
3.Reset it (Turn off earphones and put back into the charging case for 10 seconds)
4.If surrounded by too many Bluetooth devices this might be causing interference, try pairing in another area
5.Check and adjust the volume on the connected device
6.Change the earphones in case of low battery
7.Reset your device
8.If the product still does not pair please contact customer service

If the LED Light is not working:
1.Check the earphones are fully charging the earphones
2.Reset the earphones

Technical Specifications:
•Bluetooth Version: V5.0
•Bluetooth Profile: SPP,HFP,HSP,A2DP,AVRCP,HID,PBAP,MAP
•Connection Distance: TBD
•Charging Time: 1.5H (Earphone Charge box) 3.7V,450mAh (Earphones)
•Charge Time: 3.2H (Charge Box) 5V,1000mAh (Charge Box) 400mAh Silicon-Polymer (Earphones)
•Frequency response: 20HZ-20KHZ
•Sensitivity: TBD
•Frequency Range: 2.402-2.480 GHz
•Music playback time: Up to 3h 70% volume, 3.5h 100% volume
•Talk time: Up to 4h
•Charging Box provides 3 extra full charges

Warnings & Safety:
•Take the earphones out of the charging case before use.
•Avoid exposure to rain and moisture.
•Do not drop or apply forcible pressure to either the earbuds or carry case to avoid damaging the product.
•Do not dismantle the product, doing so will void the warranty.
•Do not place the earphones in the charging case if the product is damaged.
•Do not use the product if the battery is damaged, if the battery is damaged please contact your local authorities for disposal instructions.
•Do not place or attempt to dismantle or modify the earbuds or charging case, doing so may cause injury or damage to the product and will void the warranty.
•Do not place or attempt to dismantle or modify the earbuds or charging case, doing so may cause injury or damage to the product and will void the warranty.
•Do not place the earbuds or charging case in a microwave or pressure cooker as this