ART DEPARTMENT			
Job # / Filename 2017-03-13_SI_ToyRCMonsterSpinningCar_TurboTumbler_BluRed_BlkRed_v3		**Product Line** Sharper Image	**Revision #** 3
Designer Jack Ma	**Brand Manager** Lisa Nagamoto	**Finished Size** 9.35" L x 7.68" H x 7.36" W / 23.75cm L x 19.5cm H x 18.7cm W	**Today's Date** 03.13.2017
File Format Adobe Illustrator CC (live)/CS4 (OL)	**Fonts** DIN, Helvetica, Univers	**Color (Spot or 4C)** 4 Color Process	**# of Colors** 4
Printing Process / Finishing Matte PP Coating		**Comments**	

MerchSource

All copyright, trademark and patent rights or any other intellectual property rights or material associated with the content provided herein, and the selection, coordination and arrangement of such content, are owned exclusively by MERCHSOURCE LLC., or any third-party licensors. The use or misuse of any copyrights, trademarks, patents or any other intellectual property or materials, except as permitted herein, is expressly prohibited. Any infringements shall be prosecuted to the fullest extent of the law, both foreign and domestic.

C M Y K DIELINE

SHARPER IMAGE®

RC 360° RALLY CAR TURBO TUMBLER®

BOX CONTAINS THE FOLLOWING FREQUENCY:
☐ 27 MHz
☐ 49 MHz

BATTERY OPERATED PLAY VEHICLE

AGES 6 AND UP

⚠ WARNING! CHOKING HAZARD - Small parts. Not suitable for children under 3 years.

TWO FREQUENCIES
COMPETITIVE RACING

AGES 6+

360 DEGREE SPINS
SPINS AND FLIPS

SHARPER IMAGE®

RC 360° RALLY CAR
TURBO TUMBLER®

RC 360° RALLY CAR
TURBO TUMBLER®

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

OPERATING INSTRUCTIONS

Operation requires 4 "AA" 1.5V alkaline batteries (not included) for car and one 9V battery (not included) for remote control.

1. Carefully remove items from package.
2. Locate the battery compartment on the back of each item (see diagram on right).
3. Swivel latches on bottom of car to release battery pack and reset batteries.
4. Switch both car and remote buttons to "ON" position.
5. For best results use the car on hard surfaces such as wood or tile.

REMOTE CONTROL ASSEMBLY

USES ONE 9V BATTERY (NOT INCLUDED)

ON/OFF SWITCH

BATTERY DIAGRAM

ON/OFF SWITCH

BATTERY PACK USES 4 "AA" BATTERIES (NOT INCLUDED)

USE ALKALINE BATTERIES FOR BEST PERFORMANCE

GENERAL CONTROLS

Reverse: Press both control sticks backward.

Forward: Press both control sticks forward.

Spinning Action: Press and hold the control sticks in opposite directions to make the car spin.

ACTION BUTTON

Action Button: Press and hold the action button to have the car stand up on its back wheels and move forward.

SPINNING ON REAR WHEEL (ACTION BUTTON)

1) Spin the car by pressing and holding the control sticks in opposite directions.

2) Press and hold the action button while the car is spinning.

SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water, sand and snow when operating car.
- Do not submerge car or controller in water.
- Never operate your car on the street or highway.
- Never operate your car in a crowded or crowded area, and do not use people or animals as obstacles.
- Do not run your car into furniture, objects or hard surfaces, as this will cause damage to both the objects and the car.
- Always remove the battery pack after playing and keep it away from the tires, gears and motor while the car is switched to "ON".
- Do not leave car or transmitter near sources of heat or under direct sunlight for long periods of time.
- Do not place car transmitter outside overnight. Dampness is harmful to interior components.
- Remove all batteries when not in use to avoid accidental operation.
- Adult supervision is recommended when operating this car.

BATTERY WARNING:
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Insert batteries using the correct polarity, do not short-circuit the supply terminals.
- Remove batteries when the vehicle is not in use for long periods of time. Do not dispose of batteries in fire, they may leak or explode.
- Replace, dispose and recycle batteries in accordance with local regulations. Do not dispose of batteries in fire, they may leak or explode.
- Do not recharge non-rechargeable batteries, remove rechargeable batteries from the vehicle before recharging, and recharge only rechargeable batteries under adult supervision.

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

Colors and styles may vary.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For technical support, please call 1-800-274-7444.

The overall outcome of this package are protected by US copyright law and may not be reproduced, distributed, displayed, modified and used for any purpose without written permission. It is not permitted to alter, remove or reproduce any trademarks or copyright notice from this package.

1003362 (2304012)

6 942412 957724 1

Made in China

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

©2017 Sharper Image. Sharper Image® name and logo are registered trademarks. All rights reserved.

Distributed by MerchSource, LLC, Irvine, CA 92618.

The artwork and design of this package are protected by US copyright law and may not be reproduced, distributed, displayed, modified and used for any purpose without written permission. It is not permitted to alter, remove or reproduce any trademarks or copyright notice from this package.

China Patent No. ZL201230226850.1