börne

Wireless Headphones

B7HP40

IMPORTANT SAFETY INSTRUCTIONS

- Listening with headset at high volume may affect your hearing. For your safety, do not use this headset while driving, cycling, or in other areas.
- Do not use this product in explosive environments or in the presence of any article or fear ambient sound, such as in a school crossing, from sirens or alarms, construction crossings, and construction sites.
- To avoid impairing your hearing with prolonged operation, keep the volume at a moderate level.
- Do not expose this product to humidity, dust, rust or steam, or subject it to shock and drop.
- Do not place this product near a heat source or place with high heat temperatures for a long period of time as it may cause a malfunction.
- Clean the headset with a soft dry cloth.
- Do not use this product in cars or other vehicles. The product is not waterproof.
- Do not use this product in harsh locations or bad weather, such as in the sun or snow.
- To avoid electronic interference and or compatibility conflicts, turn off this product in any facilities where posted notices instruct you to do so (especially hospitals, health care facilities, etc.).
- Clean this product with a dry cloth only.

SAVE THESE INSTRUCTIONS

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should not be installed or operated in conjunction with any other antenna or transmitter.

⚠ Warning:

This device complies with Industry Canada's licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. Son exploitation est autorisée sur les deux conditions suivantes : (1) il ne doit pas occasionner de brouillage préjudiciable, et (2) il doit accepter tout brouillage radioélectrique reçu, y compris un brouillage susceptible de compromettre le fonctionnement du dispositif.

Cet équipement est conforme aux CNR-102 et RSS-247

SAR/ Radiation Exposure Statement:
This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

DAS Radiation d'exposition aux radiations:
Cet équipement est conforme au Canada limites d'exposition aux radiations dans un environnement non contrôlé.

Thank you for your purchase.

LOCATION OF CONTROLS

1. Power / Mode Button	5. Volume Down
2. Microphone / Call Accept/End Button	6. USB Charging Port
3. Volume Up / Forward Button	7. USB Charging Port Cover
4. Previous / Rewind Button	8. LED Indicator Light

CHARGING THE UNIT

Using the Charging Cable provided, plug the USB-C Type into the USB-C Charging Port and plug the other end into a USB-C port on your computer or USB-C wall charger (not included). The LED Indicator Light will illuminate red while charging and turn off when complete. A full charge will take approximately 3 hours.

PRODUCT AND BATTERY DISPOSAL

This product contains a built-in lithium battery and should not be disposed of in normal household waste. The battery in this product, or its internal to be removed by the individual in end-user, or replaced and recycled, please contact your local waste management authorities. The recycling and processing of electronic waste will make a significant contribution towards helping protect the environment.

Warning: To reduce the risk of fire and burns, do not disassemble, crush, puncture, short external contacts or dispose of in fire or water.

POWER ON/OFF

To turn on/off the headphones press and hold the Power Button. When the headset is on, the LED Indicator Light will blink red and green to indicate the headphones are ready to pair to your Bluetooth device.

BLUETOOTH OPERATION

Pairing a Bluetooth Enabled Device for the First Time

NOTE: Refer to the user manual for your Bluetooth enabled device for instructions on pairing and connecting Bluetooth devices.

1. Keep the unit and your Bluetooth enabled device within 3 feet of each other during the pairing process.
2. Press and hold the Power Button for approximately 3 seconds to turn on the unit and enter the pairing mode. The LED Indicator Light will blink red and green.
3. Turn on the Bluetooth function on your device and search for Bluetooth devices. When the search is complete, select "B7HP40" from the Bluetooth device list. When the Bluetooth connection is successful, you will hear an audible chime and the LED Indicator Light will turn solid blue.

NOTE:

- If pairing was unsuccessful, turn off the unit and repeat the steps above to retry again.
- After successful pairing, paired devices will remember each other, making pairing information is deleted, pairing is not required after the first time.
- If you wish to pair with a new device, or if the connection fails, please disconnect the existing device and pair with the new device according to the steps above.

LISTENING TO BLUETOOTH MODE

When you have successfully connected the unit via Bluetooth, use the native controls on the connected Bluetooth device to select and play your media.

- Press Play/Pause Button to play and pause your media playing.
- Press and hold the Volume Up Button to increase the volume.
- Press the Next or Previous Button to skip to the next or backward between songs.

PHONE CALLS

This unit has a built-in microphone to enjoy hands-free calls with a smartphone or mobile phone. When a call is received, the unit will ring to notify you of the incoming call. To answer the call, you need to press the phone Call button and hold to disconnect the call.

NOTE: If a phone call comes in while listening to your music, a ring tone will be heard. If you answer the call, the music being played automatically pause for the duration of the phone call and resume playing when the phone call ends.

HANDS-ON MODE

These headphones allow you to play music from a MicroSD memory card with MP3 formatted files, insert the MicroSD card, Press the Mode Button to cycle through to the MicroSD mode.

NOTE: To insert the MicroSD card, use your fingernail to help pull it out. If the way until it clicks. Do not force the MicroSD card into the slot. Do not use any other MicroSD memory card. Use the Previous or Next Button to search through the saved tracks.

Tips for Best Reception: If the FM reception is weak, change location of the headphones or try detaching the radio cord a window sill to get the best reception.

VIDEO MODE

Using the 3.5mm audio cable provided, plug one end into a smartphone, tablet, MP3 player or other audio source and the other into the AUX Input jack.

Need help? Have questions,

If you encounter any difficulties with this product, please call or email us and our representatives will be ready to help you.

Call Now: +852-3043-2418 (Monday to Friday, 9am – 5pm EST)

Email: support@borne@hello.com

Thank you for your purchase, We want you to start enjoying your product.

LIMITED WARRANTY

Warranty: Borne Products may contain components that are refurbished to be as effective as new out of the box of a new.

Before returning your Product for service under this Warranty, please read the instruction manual carefully and check all the controls, connections and settings. No product can be repaired and maintained unauthorized. Thus, Borne is not responsible for any damage caused by improper handling or unauthorized repair. Please contact Borne Customer Service or visit our Website.

Subject to the terms and conditions herein, Borne Warranties warrants to the original purchaser of the Product (hereinafter "Purchaser") that the Product will be free of defects in material or workmanship under normal use and maintenance for the Warranty Period (as defined below).

Warranty Period commencement depends "Coverage Period" for Parts and Labor, with each Coverage Period to begin on the date of original retail purchase of the Product by the Purchaser, and ending on the date of the Customer Service or alternative Product acceptance, subject to Borne's Product Return Procedures, or its alternative equivalent, as determined by Borne in its sole discretion, in accordance with the terms of this Warranty. Product with a new or refurbished Product, installed under the Warranty, assumes the remainder of the original Coverage Period for Parts and Labor, or ninety (90) days from the date of installation, repair or service, whichever is longer, unless Borne agrees to a longer period in writing. Any Replacement Parts furnished to Purchaser under this Warranty shall be free from defects in material and workmanship for a period of ninety (90) days.

This Warranty covers only Defects in Parts and Products, as defined below, and commencement that the Defects resulting from, but not limited to Misuse by Customer, an unauthorized repair, improper or improper operating instructions by Customer, or Defects in Parts and Products not caused by Borne, shall not be covered by this Warranty. Any modifications or repairs to Product by any party other than Borne's Customer or Agent, unless prior written consent by Borne, shall void this Warranty. Borne's Warranties shall not be extended to Product or Parts that have been subjected to any abuse, misuse, neglect, improper handling, improper installation, improper storage, improper operating conditions, improper power supply, improper maintenance, improper repair, improper modification, or other improper conditions, or any such action.

Processing: Upon Customer's request, and at Borne's sole discretion, Borne's commitment for Customer's commitment to return the Product to Borne, Borne will provide Customer with a Return Authorization Number ("RAN") and address where to send it, or in lieu of any return and/or verification, Borne may instruct Customer to destroy the Product, and upon Borne's request, Customer shall provide Borne with a written certification of such destruction. Borne's commitment to provide Customer with such credit or Product, and upon Customer's Borne's commitment to return or destroy the Product, Borne will

RECHARGER L'APTÉ

L'Aptée est livrée avec un chargeur mural, branchez Aptée sur le port de chargement USB C et branchez l'autre extrémité dans un port USB C ou votre ordinateur ou dans un chargeur mural USB. 2 heures, L'indicateur lumineux LED, L'Aptée en charge pendant 2 heures. Une fois entièrement chargé, vous pouvez profiter jusqu'à environ 3.4 heures.

CAPACITÉ DES PRODUITS ET DES VÉLO

Ce produit contient une pile au lithium intégrée et ne doit pas être jeté avec les ordures ménagères. Le contenu de cet appareil n'est pas destiné à être retiré par le particulier ou le bricoleur. Pour l'élimination et le recyclage, veuillez contacter les autorités locales chargées de la gestion des déchets. Ne pas jeter les piles usagées ou les déchets électriques conformément aux réglementations de collecte des déchets municipaux.

Avertissement: Pour réduire les risques d'incendie et de blessure, ne pas démonter, écraser, percer, court-circuiter les contacts externes ou jeter au feu ou dans l'eau.

MISE À JOUR DES FONCTIONS

Pour bénéficiant de toutes les fonctions, assurez-vous d'installer et maintenir les mises à jour du logiciel de votre Aptée. Vérifiez régulièrement les mises à jour pour rester sur la version actuelle et bénéficier des améliorations de sécurité et de performance.

FONCTIONNEMENT BLUETOOTH

Jumelage d'un appareil Bluetooth pour la première fois

Assurez-vous que votre Aptée est éteinte et que votre appareil Bluetooth est activé. Maintenez le bouton Marche/Pairing enfoncé pendant 5 secondes jusqu'à ce que le voyant LED clignote en bleu et rouge. Sur votre appareil Bluetooth, recherchez « Aptée » et sélectionnez-le pour terminer le jumelage.

- Contrôle Facile et rapide disponibilité compatible Bluetooth à moins de 2 pieds à tout moment
- Appuyez sur le bouton Marche/Pairing pendant 5 secondes
- Appuyez sur le bouton Alimentation et maintenez-le enfoncé pendant environ 2 secondes pour allumer l'appareil et passer en mode de jumelage ou appuyez brièvement dessus en cas de connexion.
- Activez le Bluetooth sur votre appareil compatible Bluetooth et recherchez les appareils disponibles. Sélectionnez « Aptée » dans la liste des appareils disponibles. Lorsque la connexion est établie, le voyant LED clignote, indiquant la connexion réussie.
- Une fois jumelé, vous pouvez ajouter jusqu'à six appareils supplémentaires. Répétez simplement le processus de jumelage pour chaque appareil. Il n'est pas nécessaire de répéter le processus pour les appareils déjà jumelés.
- Une fois jumelé, votre appareil se connectera automatiquement à votre Aptée lorsque vous allumerez le casque et que vous activerez le Bluetooth sur votre appareil compatible. Il n'est pas nécessaire de répéter le processus de jumelage.

ÉCOUTER DES MÉDIAS VIA BLUETOOTH

Une fois que vous avez terminé le jumelage, vous pouvez commencer à écouter de la musique, à passer des appels téléphoniques ou discuter à l'aide de votre Aptée. Voici quelques conseils pour profiter de votre expérience :

- Appuyez sur le bouton Lecture/Pause pour lancer ou mettre en pause votre média préféré.
- Ajustez le volume à l'aide du bouton Volume +/- et maintenez-le enfoncé pour augmenter ou diminuer le volume de manière continue.
- Appuyez rapidement sur le bouton Suivant ou Précédent pour passer d'une chanson à l'autre ou revenir au début.

APPELS TÉLÉPHONIQUES

Cet appareil est équipé d'un microphone intégré qui permet d'effectuer des appels mains-libres avec un téléphone portable ou un smartphone compatible avec le connexion Bluetooth. Pour répondre à un appel, appuyez sur le bouton Marche/Pairing. Pour rejeter un appel entrant, maintenez appuyé le bouton Marche/Pairing pendant environ 2 secondes. Pour terminer un appel, appuyez sur le bouton Marche/Pairing ou maintenez-le enfoncé.

REMARQUE : Si vous recevez un appel téléphonique pendant que vous écoutez votre média, vous entendrez une sonnerie. Si vous répondez à l'appel, la lecture du contenu multimédia s'interrompt automatiquement pendant la durée de l'appel téléphonique et reprend à la fin de l'appel.

MODE MÉDIAS

Ce casque vous permet d'écouter de la musique à partir d'une autre ressource équipée nativement sans fil(sans cordon) Bluetooth. Pour activer le mode mixte(2), appuyez sur le bouton Mode pour passer au mode mixte(2).

REMARQUE : Pour traiter le mode mixte(2), utilisez votre angle pour fonctionner jusqu'à ce qu'un signal. Pour activer le mode mixte(2), assurez-vous d'avoir jusqu'à ce qu'un signal. Pour activer le mode mixte(2), appuyez sur le bouton Mode pour passer au mode mixte(2). Les fonctions pour le fonctionnement des données brouge vous passeur d'un mode à l'autre.

MODE FM

Appuyez sur le bouton Mode pour passer au mode FM. Appuyez sur le bouton Lecture/Pause pour lancer la radio. Ajustez le volume à l'aide du bouton Volume +/- et maintenez-le enfoncé pour ajuster le volume. Accédez aux stations enregistrées en appuyant sur le bouton Précédent ou Suivant pour naviguer parmi vos stations préférées.

Connecté pour une meilleure réception : Si la réception FM est faible, changez provisoirement de mode en passant d'Aptée à Aux pour d'une heure jusqu'à ce que vous obtenez la meilleure réception.

MODE À L'ARRÊT

L'Aptée du casque bénéficie de 3.5 mm Aux2. Branchez une extrémité sur un smartphone, une tablette, un ordinateur MP3 ou une autre source audio et profitez d'un son pour d'entre autre.

Vous avez besoin d'aide ? Voici les mes appels.

Si vous rencontrez des difficultés avec ce produit, veuillez nous appeler ou nous envoyer un courriel et nos représentants seront ploin à vous aider.

Appel gratuit : 1-855-645-6400 (ou gratuit au canada) : 9 h – 17 h (HE)
Courriel: support@borne-audio.com

Nous vous remercions pour votre achat, nous souhaitons que vous puissiez commencer à profiter de votre produit.

GARANTIE LIMITÉE

Avertissement: Conformez-vous toujours scrupuleusement aux consignes suffisamment publiques fournies avec votre produit. Borne décline toute responsabilité

Après de nombreuses ville Francisco Vancouver Québec Montréal Toronto Ottawa Calgary Edmonton Winnipeg Halifax Saint-John Saint-Jean Saint-Pierre-et-Miquelon Saint-Boniface Saint-Hyacinthe Saint-Jérôme Saint-Jean-sur-Richelieu Saint-Eustache Saint-Eustache Saint-Eustache