Cover OUTSIDE

11" (27.9cm)

6" (15.2 cm)

LED STUNT DRONE

Sharper Image® name and logo (including the 77 logo) are trademarks or registered trademarks.
Distributed by and © 2020 MerchSource, LLC. Irvine, CA 92618. All rights reserved.

For customer support, please visit www.merchsource.com or call 1-800-374-2744.

The artwork and design of this manual are protected by US copyright law and may not be reproduced, distributed, displayed, published or used for any purpose without prior written permission. It is not permitted to alter, remove or reproduce any trademarks or copyright notice from this manual.

Printed in China

CHOKING HAZARD –
SMALL PARTS NOT FOR CHILDREN UNDER 3 YEARS
ADULT ASSEMBLY REQUIRED.

LED STUNT DRONE

14+

INSTRUCTION MANUAL



BC

LED STUNT DRONE

Cover INSIDE

INTRODUCTION

Congratulations on your purchase of the LED Stunt Drone.
It's time for some fun. This drone is capable of total controlled flight, fly up/down, left/right, and pitch forward or backward, on 6 axis gyro stabilization with a control range of 150 feet. Includes USB charging cable, replacement blades and for auto orientation, auto take-off and auto landing control. Included, is a 500 mAh Li-po drone battery. The remote controller requires requires 3 AAA 1.5V batteries (not included). Alkaline batteries are recommended.

Please read all instructions and warnings in this manual prior to using your LED Stunt Drone, and keep this instruction manual as it contains important information for future reference. Adult assembly and a Phillips screwdriver will be required for battery installation.

Table of Contents

General Warnings	Page 2
Contents	Page 3
Remote Battery installation and Charging Battery	Page 4
Replacing Propellers	Page 5
Remote Overview	Page 6
Operating Drone	Page 7
Operating	Page 8
Other Features	Page 9

INTRODUCTION

1. Prepare for flight

- Drone must be charged before each use (Cable included).
- Indicator light on USB plug will turn off when fully charged.
- Install batteries in remote.

2. Pair your drone

Before each flight pair the remote with the drone:
1. Turn your drone on and place on a flat, level surface.
2. Turn on the remote.
3. Push the left stick up and then down.
4. Repeat steps 1 and 2 if necessary.

3. Calibrate

- Move both joysticks diagonally in toward the middle of the remote.

4. Remote Control Overview

Practice flying your drone below 10 feet and at low speeds until comfortable with all controls to avoid unnecessary damage or injury.
- Left joystick: Up/Down controls elevation.
- Right joystick: controls flight direction.
- Direction Trim: Use to eliminate drift.

To cut power to drone, move left joystick to down position.

GENERAL WARNINGS

⚠ SAFETY WARNINGS

- Not recommended for children under 14 years of age. As with all electrical products, precautions should be observed during handling and use to reduce the risk of electrical shock.
- Adult supervision is required at all times.
- Never fly drones above or near people, sudden changes in wind or other conditions could lead to unexpected crashes.
- Always use caution when flying drone vehicles, obey relevant laws, respect the privacy and property rights of others.
- The drone shall never be modified or used for anything except its intended purpose.
- Before each use, an adult should review the product and battery to determine that no damage or hazards exist. Do not use if any damage is found.
- Do not allow anything to intentionally make contact in any way with spinning propellers or prevent contact with spinning blades by turning off remote prior to handling drone.
- Use caution and pay attention to your surroundings while operating drone.
- Do not fly drone into animals, people, or inanimate objects.
- Do not operate in crowded areas, near high voltage lines, power stations, and any other potentially hazardous areas.
- Do not operate in rain, heavy wind, and or any type of severe weather.
- Do not land drone on wet surfaces.
- Never touch or allow others to touch drone while it is flying.
- Always turn drone off when it is not in use.
- Always fly drone in large open areas.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accord- ance with the instructions, may cause harmful interference to radio communications. However there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined in turning the equipment off and on the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Fly-aways are the responsibility of the individual pilot and will not be replaced by the manufacturer.

CONTENTS



LED Drone

Drone Controller

4 Replacement Propellers.

USB Charger Cable

REMOTE BATTERY INSTALLATION

1. Slide open the remote's battery compartment.
2. Install 3 "AAA" batteries as shown in the diagram above.
3. Replace and close battery compartment.

⚠ BATTERY WARNING - LITHIUM-POLYMER:
There is a risk of fire and personal injury if LiPo batteries is punctured, damaged or misused. Follow the following safety precautions when using LiPo batteries:
- Do not subject batteries to strong impacts.
- Do not puncture batteries with any sharp objects.
- Only use manufacturer specified battery(ies), charger(s) and/or adapter. If applicable, follow manufacturer's instructions.
- Battery is not rechargeable.
- Let battery cool to room temperature before charging.
- Do not short circuit battery terminals.
- Dispose of dispose of battery according to local, state and local laws.

KEEP THIS PACKAGING FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

BATTERY WARNING:
- Do not mix old and new batteries.
- Do not use alkaline, standard (carbon-zinc), or rechargeable batteries.
- Insert batteries using the correct polarity. Do not short circuit the supply terminal.
- Dispose of dispose of battery according to local, state and local laws. Do not dispose of batteries in fire. Recycling is helpful, state, and local laws. Do not dispose of batteries in fire. Recycling is helpful.
- Remove batteries from equipment, if equipment is not used for a long period of time. Remove batteries also from the remote/charger.
- Remove old batteries and recharge if applicable before use when not supervising.

KEEP THIS PACKAGING FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

Charging Battery

1. Turn off the drone before charging.
2. Connect the battery charger cable to the charging port on the drone.
3. Connect USB connector to the power source.

Note: The Battery Charger will light up when it is charging the battery and turn off when the battery is fully charged.



REPLACING PROPELLERS



- Only an adult should replace blades. To remove, pull up the blades directly.
- Replace propellers by following the diagram.
- Each blade spins differently. Blade B spins counter clockwise and Blade A spins clockwise.

REMOTE OVERVIEW



OPERATING DRONE

Step 1 - Pre-Flight Checklist.
1. Read all warnings and instructions.
2. Install and charge batteries, page 4.
3. Charge battery, page 4.
4. Make sure that the drone and remote are powered off.



Step 2 - Choosing a location.
- Drone is designed to be flown indoors and outdoors.
- Always make sure you have enough space to fly drone.
- Always follow warnings, page 2.

Step 3 - Pre-Flight.
- Make sure your remote is off.
- Push the power button on top of the drone and hold on 1-2s until LED lights on.
- Place drone on a flat even surface. For ease of control, the blue lights should be toward you.
- Turn on the Remote controller. Push the left stick up and then down.
- The drone's lights will flicker during the pairing process and then remain on once it has paired.

Step 4 - Lift Off.

Press the Auto Take-off Button.

OR

Slowly and carefully press the Throttle stick. Drone will begin to elevate.

OPERATING

Step 5 - Operating Drone in Flight.



1. Follow this step if your drone begins to drift during take-off or during flight.

A. Drone drifts backwards: Press the Forward Trim Button.

B. Drone drifts forwards: Press the Backwards Trim button.

C. Drone drift right: Press the Left Trim Button.

D. Drone drift left Press the Right Trim Button.

2. Use the Throttle Joystick to increase or decrease your elevation.

3. Use the Multi Directional Joystick to move forward/backwards or side to side.

4. Stunt - Press the Stunt Button then press the Multi Directional Joystick in the direction you want to complete a stunt.

Note:
1. The stunt function may be disabled if the drone battery power is low.
2. Throw the drone up or down if flips are not allowed. It has been attempting a stunt.

Step 6 - Landing Drone



1. Lower drone to20 feet or less then press the Auto Land button. Use the Multi Directional Joystick to maneuver drone. Or Push the left joystick down until the drone landing.

2. In the event the blades will not stop spinning, you can perform an emergency stop.

Step 7 - Retrieving Drone



1. Turn off your remote by pressing the Power Button. This will stop you from accidently turning the propellersun.

2. Make sure the propellers have stopped spinning then pick up your drone.

Note: You will need to pair your drone again before your next flight, (part 1 of step 4).

OTHER FEATURES

Auto Orientation



Press the Auto Orientation Button to turn the mode ON and then again to turn off.

- In this mode, the drone will always move in the direction you press the Multi Directional Button no matter which way the drone faces.

- To stop blades in case of an emergency.

When drone is in auto orientation mode, the drone will orient to the user (remote), no matter what direction the drone is facing.

- Press the Orientation button. Remote will beep every 4 seconds to indicate it is in Auto Orientation mode.
- Push the right stick up will send the drone away from the user; push left will move left, etc.
- Press Auto Orientation button to exit mode.

Tips

- Do not crash drone into sand or dirt. Drone gears may become clogged.
- When first learning to fly, practice lifting off and hovering.
- Stay several feet from walls and buildings.