KRONO 说明书模板　　料号：602.7100100140
成品:100*140MM/骑马钉/4色印/内页100G太阳哑粉纸+封面200G太阳哑粉纸

krono
www.kronodigital.com

NET K7 PLUS

MANUAL DE USO

THE FUNCTION PREVIEW

Google, Android, Google Play, YouTube,Gmail and other marks are trademarks of Google LLC.

START

EnXnVdf

- Press and hold the power key (3 to 5 seconds to turn on the tablet. Then follow the on-screen instructions to set up your device and select your language.
- Depending on your region, time zone, and network, date, time, time zone, and Screenrotation are displayed on the screen. Click the Power off to turn off the tablet.
- When the tablet has no reaction, press the button 10 seconds for resetting.

Battery

- A rechargeable Li-ion battery is installed in the tablet.
- Use only the charger and cable provided with the tablet as this may damage the tablet or cause a fire. Do not short circuit the battery.
- DO NOT throw the tablet into a fire.
- Do not place the tablet battery in very hear source, direct sunlight or high temperature.
- Use only the CR2Ultra, power charger supplied to charge the tablet battery.
- Do not attempt to open or change the battery completely once a month if you only use occasional charge.
- The Li-ion battery of your tablet must be repaired or recycled by a supplier authorized by Krono or disposed of in accordance with local environmental laws.
- Dispose of the battery in accordance with local environmental laws and regulations.

Suspension Mode:

- On the home screen, press the power button once to activate the sleep mode, press it again to close it.

Sleep Mode:

Go to Settings > Display > Screen sleep timeout to set the sleep mode time.

Captura de Pantalla

- Press and hold volume - and Power key for 2 seconds for screenshot.
- Screenshot can be taken in Gallery, Photos, Screenshot, Facebook Shadows, Hotsot and Screenrec. Select Screenrec for screenshot.

THE HOME SCREEN

BOTTOM MENU ICON

HOME SCREEN SETTINGS AND WALLPAPERS

Press and hold the white part of the home screen , Home screen settings and Wallpapers are displayed

- Press Home screen settings to start customizing your Home screens.

- Add icon to the Home screen:
  Select the Apps installed from Google Play to be displayed on the main Home Screen.
- Home Screen Loop:
  Enable to allow switching or hiding icons on your Home Screen.
- Swipe down action:
  Select the action when you swipe down on the main Home screen.

Select Wallpapers to change the current wallpaper of the tablet from the preset/set pictures or backgrounds.

GENERAL SETTINGS

Quick Settings

Swipe down from the top of the screen for quick settings.

- Wi-Fi : Click to connect or disconnect.
- Bluetooth : Click to turn on or off.
- Do not disturb: Mute the sound and stop the notification from appearing on the screen.
- Auto Screen Rotation: Switch Enable or Disable Auto Screen Rotation Mode.
- According to your favourites, select the setting to enable or disable.
- Simulation mode: The blue light will be filtered and the screen will take on a yellowish tint when this function is enabled.
- Night light : The screen will appear black and white after enabling this option.

More Settings

Go to the Quick Settings, scroll down and select ⚙ to enter your page to enter your desired settings page. Or select App Settings from the home screen to enter it.

Network & Internet
- Connected to any available WiFi.
- Activate / deactivate Flight mode
- Mobile network
- VoLtE VPN connections

Connected Devices
- Activate / deactivate devices and search for paired devices
- Activate / deactivate Bluetooth
- Set the current printing equipment View the documents received via Bluetooth from other devices
- Add and view the printing device

Applications and notifications
- Manage apps and notifications
- View all applications on the device Adjust application notification settings
- Check screen time for Apps Check screen time for Apps
- Set default apps Set default apps and permissions
- Set permissions for applications and notifications
- Set permissions for applications etc.

Battery
- Display battery percentage
- Battery Saver Battery Percentage and Battery Saver Set Power Saving Optimization
- Set Power Saving Optimization
- Set power saving optimization for all applications Check detailed battery settings for Apps
- Check detailed battery settings for Apps

Display
- Adjust screen brightness
- Adjust screen brightness, blue light
- Change the wallpaper
- Activate / deactivate the dark theme
- Set the font size and zoom Set the font size and zoom
- Set the font size and monitor size etc. * Set the font size and monitor size etc.

Programmed switching on/off
- Set the time and days of the week to be switched on or off automatically

Sound
- Set the sound level for Multimedia, Alarm and notifications
- Activate / deactivate the Do not disturb function and set stop vibration
- Activate the Hotgot Gesture function (no shortcut)
- Set the default ringtone sound and alarm sound Enable / disable lock screen sounds etc.
- Enable / Disable lock screen sounds etc.

Storage
- View accessible storage space

Privacy
- Set application permissions
- Set to show/hide the password when entering a password
- Set the clipboard permissions
- Hold a google account and automatic service etc.

Location
- Enable/disable location services for specific applications
- Set the location mode to high accuracy etc.
- Turn on / off Wi-Fi and Bluetooth Search etc.

Security
- Check security status
- Set the screen lock method, e.g., Swipe, Pattern, PIN and Password. Swipe, Pattern, PIN and Password
- Choose your backup screen lock method, e.g. Facial Authentication + Pattern, Facial Authentication + PIN, Facial Authentication + Password
- Enable the management application to find your tablet and lock or erase a lost device etc.

Accounts
- Add and manage user accounts on the tablet

Accessibility
- Fine vision and hearing impaired users, Screen Readers, Display and Interaction Controls are provided.

Digital well-being and parental control
- Set the screen time of your Notifications received in Times opened to view mobile app usage.
- Manage app-related notifications to reduce annoyance
- Take parental controls to help your children balance their time

Google
- Set the preference of Google ™ service

System
- Set the language
- Set the keyboard, e.g. Gboard + Language + + Add a language to add your language, then press and hold and slide the ⚙ on Google the language
- Turn camera shortcut on and off.
- Turn on / off the time
- Turn backup on and off
- Factory reset
- Set the Advanced > Recovery Options > Erase All Data to Reset
- Check current version of your tablet and check for updates if there is a new version etc.

Phone Information
- Check your tablet information

CONNECT TO NETWORK

Run the Settings App or long press the WiFi / Bluetooth icon in Quick Settings.

Connect to WiFi

1. Select Network & Internet and activate WiFi. There is the list of available WiFi.
2. Select the WiFi you want and enter the password.

BROWSING WEB PAGES

Before browsing, make sure the tablet is connected to the available WiFi . You can use the pre-installed Chrome browser or download the browser from the Play Store.

Use Bluetooth function

Please turn on Bluetooth on your Bluetooth device first.

1. Go to Connected Devices > Connection Preferences > Bluetooth to turn on the Bluetooth of your tablet.
2. Select the new device to enter the scanning interface. A few seconds, all available devices will be displayed on the screen.
3. Select a device. Get the pairing code, and last select ENG on both devices. Some devices may connect automatically.

Notes:
Use the quick settings , select Hotspot System - Changing device to USB Touch to use more options, select the required connection method.

- Choose Change only to charge your tablet.
- Select MTP to transfer media files (music and photos) between the two.
- Select PTP to transfer files from the computer.

APPLICATION MANAGEMENT

Download and Install

- On the home screen activate the Play Store application.
- Sign in to your Google account, and search for the application you want.

Application Management

Move the application

Touch and hold the app icon, and move it to the desired screen.

Delete app from the Home screen

Touch and hold the app , then slide it towards X Remove to remove the app from the home screen.

Download APP

Touch and hold any app , and move it towards ⓘ Uninstall to remove it.

Clear APP Cache

1. Enter Settings > Apps & Notifications.
2. Select an APP > Storage > Cache > CLEAR CACHE.

MULTIMEDIA

Connecting to the Computer

1. Connect your tablet to the computer with a USB cable.
2. Charging only is the default setting. You can switch to Media Device (MTP) or Photo Transfer (PTP) in the notification bar. Once MTP is enabled, you can manage the documents between the tablet and the computer.

Notes:
Use the quick settings , select Hotspot System - Changing device to USB Touch to use more options, select the required connection method.

- Choose Charge only to charge your tablet.
- Select MTP to transfer media files (music and photos) between the two.
- Select PTP to transfer files from the computer.

Connecting to the External Device

1. Install a memory card with a capacity of up to 64G and go to Quick Setup
2. Select SETUP
3. Select Portable Storage , set the card to the removable device . You can transfer files between the tablet and the removable device.

ESPECIFICACIONES

Tamaño	10"
Chip	MT8321
CPU	Max T310
RAM	2GB
Almacenamiento	32GB
Memoria	64GB
Cámara frontal	0.3MP
Cámara trasera	2.0MP
Batería	3400mAh
Sistema operativo	Powered by Android™ 12 (Go edition)
Conexión	4G
Fuente de alimentación	9V2.1Vapps
Redes	5G 2G/2A
Punto de A	Multimedi
Puertos	Type-C

MULTIMEDIA

Q1. The screen fails to reaction :
- Check for dust on the screen, wipe it with a cloth and try again.

Q2. The first icon is too small to be read.
- Please go to Settings > Display > Advanced > Font Size to adjust the text size.

Q3. Could the tablet support OTG function?
- Yes, but it requires an extra OTG cable. Then you can connect the tablet to a mouse or USB drive via the cable.

CAUTION
DANGER OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Suitcase relocates DC voltage.

DEPARTMENTS COLLECTION

This product bears the separate collection symbol for waste electrical and electronic equipment (WEEE). This product has been made with high quality components and materials which can be reused and recycled. Electrical and electronic equipment which bears the WEEE symbol can be recycled to dismantled or removed to protect the environment. This product can be used in all member states of Criteria. The packaging should be retained because it contains important information.

Notes:
1. High circuit utilization
2. Clean the carbon deposits
3. Do not leave at high volume levels for long periods of time.

FCC Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.