Product label



Product S/N

Product instructions

PRODUCT CONTENTS

CTR79P

WALL HANG CONTROLLER (x1)

SENSOR PROBE (x1)

WALL-HANG WOOD SCREWS (x2)

WIRE TIE (x1)

CABLE TIE MOUNT (x1)

POWERING AND SETUP

STEP 1

Plug the sensor probe into the 3.5mm port located at the bottom side of your controller.



STEP 2

Insert the power plug into a wall outlet to power your controller.



POWERING AND SETUP

STEP 3

Position the corded sensor probe and secure it by using the included zip ties and tie mounts.



STEP 4

Locate a spot free of obstruction and secure the anchor into your wall. Twist the wood screw into the anchor.



POWERING AND SETUP

STEP 5

Hang your controller by the screw using the hole located on its backside.



STEP 6

Plug your device (not included) into one of the two sockets to power it with your controller.



PROGRAMMING

1. OUTLET BUTTON

Cycles through the two outlet devices. Each outlet device is programmed independently, or together when navigating to ALL.

---

2. MODE BUTTON

Cycles through each of your controller's modes: OFF, ON, AUTO (4 triggers), TIMER TO ON, TIMER TO OFF, CYCLE (On and Off), and SCHEDULE (On and Off).

---

3. UP/DOWN BUTTONS

Adjusts the value of your current mode. The up button increases and down button decreases the setting. Hold both to reset values to OFF or 0.

---

4. SETTING BUTTON

Cycles through each of your controller's settings: DISPLAY BRIGHTNESS, °F/ °C, CLOCK, CALIBRATION (Temperature and Humidity), and BUFFER (Temperature and Humidity).

DOWNLOAD THE APP

THE AC INFINITY APP

The AC Infinity app enables you to connect with the next generation of our intelligent controllers, giving you access to advance programs and environmental data.

1. Download the AC Infinity app from the App Store or Play Store by searching "AC Infinity".

2. Open the AC Infinity app and follow the instructions on page 36-42 to pair your controller with the app.

Download on the App Store

GET IT ON Google Play

HOW TO USE THE APP

Visit our website at www.acinfinity.com or open your smartphone camera and scan the QR code below for more information on the AC Infinity app.

*Appearance and features subject to change.

ADD A DEVICE
BLUETOOTH

SETUP AND PAIRING

Power your device on before pairing your device with the app. Refer to pages 10-12 for more information regarding controller setup.

1. Tap on the “+” tab to add your smart device.

2. To launch the app, tap on the "Smart Outlets" tab to begin pairing.



Please note: Bluetooth must be enabled on your mobile device before starting the pairing process.

ADD A DEVICE
BLUETOOTH

3

Select your controller to begin pairing.



4

Hold the port button for 5 seconds to activate Bluetooth. Wait for the Bluetooth icon to start flashing on your controller's screen.

ADD A DEVICE
BLUETOOTH

5

Connect using Bluetooth. To connect using Wi-Fi, skip to step 8.

6

Connecting with Bluetooth will disable Wi-Fi functionality. Go to the app settings page to re-enable and connect using Wi-Fi.

When pairing the app around multiple controllers, move your mobile device closer to your desired controller.

ADD A DEVICE
BLUETOOTH

7

Tap the DONE button to complete the pairing process.

ADD A DEVICE

WIFI

8

Log in or create an account to continue.

9

Enter your Wi-Fi network's password. You may also connect to an alternate 2.4 GHz router*.

When pairing the app around multiple controllers, move your mobile device closer to your desired controller.

ADD A DEVICE
WIFI

10

Follow these tips if the pairing process is unsuccessful.

11

Tap the DONE button to complete the pairing process.



*This controller is only compatible with 2.4 GHz frequency band routers. When connecting using Wi-Fi, make sure your mobile device is not connected to a 5 GHz frequency band network.

ADD A DEVICE

WIFI

12

Your controller will appear in your smart device with a unique ID.



FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference

that may cause undesired operation.

RF Exposure Statement
To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

IC warning:
This device contains licence-exempt transmitter(s)/receiver(s)/ that comply with Innovation Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
1) this device may not cause interference and
2) this device must accept any interference, including interference that may cause undesired operation of the device.

Radiation Exposure: This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment; To maintain compliance with IC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Déclaration de l'ISEDCanada :
Cetappareilcontient des tasmittre (s) / récepteur (s) sans licence / conformes à l'innovationRSSexemptes de licence de Sciences et Développementéconomique Canada.
L'opérationest sous réserve des deux conditions suivantes :
1) cetappareil ne peut pas causer d'interférences et
2) cedispositif doit accepter touteinterférence, y comprispeutprovoquer le fonctionnementindésirable de l'appareil.

Exposition aux rayonnements :Cetéquipementestconforme aux radiations du Canada limitesd'exposition pour un environnementincontrôlénoncéd'exposition RF Pour maintenir le respect des guides d'exposition RF d'IC, cquipment doit être.installé et actionnéavec une distance minimale de 20cm le radiateur de votre corps. Cetappareil et sesantennes ne doivent pas être co-localiséouenopérationenconjonction avec touteautreantenneouémetteur.