英

110mm

65mm

NOBIS Sound N1 Wireless Speaker User Manual Model No.: 96311

Catalog

English 2
Français 11
Deutsch 19
Español 27
日本語 35
Italiano 43

Packing List

At a Glance

1. Power
2. Bluetooth Pairing
3. Volume Down
4. Volume Up
5. Mode
6. Bass Boost
7. Bluetooth Indicator
8. Power Indicator
9. Charge Indicator
10. Type-C Charging Port
11. USB-A Power Bank Port
12. Lanyard Hole
13. Crossbody Strap Hole
14. Rubber Plug

Note: The rubber Plug must be in place to prevent water ingress.

Specifications

- Speaker Output Power: ..... 10W x 2(4Ω)
- Frequency Response: 100Hz-20KHz
- Power Consumption: ..... 0.5W(Max)
- Signal to Noise Ratio: 75dB
- Battery: ..... Lithium Battery 1000mAh
- Charging Time: ..... Approx. 3 hours
- Music Play Time: ..... Approx. 10 hours at 50%Volume (Time varies may vary depending on volume and use)
- Bluetooth Version: 5.3
- Bluetooth Range: ..... Up to 10 meters (Open Area)
- Waterproof: IP Rating: IP67
- Dimensions: ..... 78 x 31 x 31 mm
- Weight: 100g

Specifications are subject to change without notice.

Speaker User Instructions

1. Power On/Off

Hold power button for about two seconds for connection and initial pairing.

Hold power button for about two seconds to turn off.

2. Charging the Speaker

- Please ensure the charging port is free of water droplets before charging.
- The rubber Cap/Rubber Plug must be in place to prevent water ingress during charging.

Note:
- Charge is not suitable playing in the sunshine and in and direct to sunlight operation. It is suitable will automatically power off after 30 minutes.

3. Power Bank Function

Note:
The power bank function is only available when the speaker is on and connected to a USB-A power bank (power bank and cable sold separately).

4. Bluetooth Pairing

- Turn on the Bluetooth function on your Bluetooth pairing mode, the speaker will enter pairing mode automatically.
- Hold the pairing button for about two seconds to turn off pairing, wait for "Bluetooth Disconnected" prompt, then the speaker will automatically power off.
- The speaker can pair up to 8 paired devices to list. If not automatically connected, please manually connect the speaker in the Bluetooth settings.
- The speaker will only connect to one device at a time.
- Bluetooth connection range is up to 10 meters (Open Area).
- Connection may be affected by other Bluetooth devices, wireless networks, or other electronic interference.

Note:
- Bluetooth connection range may be affected by other Bluetooth devices, wireless networks, or other electronic interference.
- Connection may be affected by other Bluetooth devices, wireless networks, or other electronic interference.

5. TWS Mode

Note: Ensure the speaker is in pairing mode before connecting.

6. Music Mode

Short press the music mode button to cycle through Bluetooth mode and other available audio modes.

Note:
- Ensure your Bluetooth device is paired and connected before using the music mode button.
- Ensure the music mode button will switch to the corresponding audio mode.

Note:
- In mode pairing mode, the speaker will automatically disconnect from the current Bluetooth device and enter pairing mode.
- Ensure the music mode button will switch to the corresponding audio mode.

Note:
- In mode pairing mode, the speaker will automatically disconnect from the current Bluetooth device and enter pairing mode.
- Ensure the music mode button will switch to the corresponding audio mode.

Note:
- In mode pairing mode, the speaker will automatically disconnect from the current Bluetooth device and enter pairing mode.
- Ensure the music mode button will switch to the corresponding audio mode.

7. Music Playback Control

Action	Function
Short Press	Play/Pause
Long Press	Volume Up
Long Press	Volume Down
Short Press	Next Track
Short Press	Previous Track
Short Press	Answer Call
Long Press	Reject Call
Short Press	Hang Up Call

8. Beat Function

The rotating light has 3 colors corresponding to 3 sound effects, and it will offset the beat when the music is playing.

Note: Light Beat Function only supports Bluetooth mode.

Note: Light Beat Function only supports Bluetooth mode.

Note: Light Beat Function only supports Bluetooth mode.

Note: Light Beat Function only supports Bluetooth mode.

- The speaker supports TWS connection, allowing two speakers to be paired for an even richer and bold Bluetooth stereo sound.
- Ensure both speakers are fully charged before pairing for optimal performance.
- Place both speakers in pairing mode: Hold the pairing button on each speaker for about two seconds until the indicator flashes rapidly.
- Connect the speakers: Once both speakers are in pairing mode, they will automatically connect to each other. The speaker that was paired last will act as the left channel, and the other as the right channel.
- Disconnecting the speakers: To disconnect the pair, simply turn off one speaker or disconnect the Bluetooth connection.
- Reconnecting the speakers: To reconnect the pair, ensure both speakers are in pairing mode and they will automatically reconnect.
- After successfully pairing in TWS mode, the main device can play music, adjust volume, and control music playback. The slave device can only adjust volume and control music playback.
- Ensure both speakers are within the Bluetooth range (10 meters) for optimal performance.
- If you encounter any issues with pairing or connection, try resetting the speakers by turning them off and on.

Note: Ensure the speaker is in pairing mode before connecting.

Note: Ensure the speaker is in pairing mode before connecting.

Note: Ensure the speaker is in pairing mode before connecting.

Note: Ensure the speaker is in pairing mode before connecting.

9. Hearing Call Mode

Note: Ensure the speaker is in pairing mode before connecting.

Note: Ensure the speaker is in pairing mode before connecting.

Note: Ensure the speaker is in pairing mode before connecting.

10. Auto Function

Enable AI Function, the indicator light turns on.

- When connected to your phone via Bluetooth, press and hold the volume down button for 3 seconds to activate your voice assistant. Apple phones will open Siri, while Android or Harmony OS phones will open Google Assistant or Huawei Assistant respectively.
- Ensure your Bluetooth connection is established before using the voice assistant function.
- Ensure your phone's voice assistant is enabled and set up correctly.
- Ensure a stable Bluetooth connection. Weak signals may affect voice assistant performance.

The specific features of the AI large model will be updated through OTA upgrades.

Note:
- Ensure your Bluetooth connection is established before using the voice assistant function.
- Ensure your phone's voice assistant is enabled and set up correctly.
- Ensure a stable Bluetooth connection. Weak signals may affect voice assistant performance.

11. Forced Reset

If your speaker experiences issues like unresponsive buttons, failure to connect, or other malfunctions, you can perform a forced reset.

- Press and hold music mode button.
- Press and hold power button for 10 seconds.
- The speaker will automatically power on once the reset is complete.

12. IP68 Waterproof and Dustproof

Perfect for taking the fake, the beach, listening to the pool, listening in the shower.

The rubber Plug needs to be closed to keep the speaker waterproof and dustproof.

Important Safety Reminder: When the speaker is plugged into a charging source with the USB-C charging cable, never use the speaker in the shower bath, or near water to prevent the risk of electric shock.

IMPORTANT SAFETY INSTRUCTIONS

- Read, follow and keep these instructions.
- Heed all warnings on the product and in the manual.
- Do not use this product near water for example, near a bathtub, washbowl, kitchen sink, or laundry tub, in a wet basement, or near a swimming pool, or in any other location that has exposed liquids.
- Wipe only with a dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all repairs to qualified personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Do not expose this product to extreme heat e.g. from direct sunlight or other sources, such as the sun.
- If the battery leaks, do not allow the liquid to come in contact with the skin or eyes. If contact occurs, seek medical advice.

CE

Hereby Grande Cruise Inter International Co. Ltd declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The complete declaration of conformity can be found at www.nobiscustomer.com

FCC

This device complies the guidelines and with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Contains FCC ID: 2AC7Z-ESP32S3WROOM1U, 2AC7Z-ESP32S3WROOM1UN4

This product is RoHS compliant.

This product complies with Directive 2011/65/EU and (EU) 2015/863 on the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment (RoHS recast) and its amendment Directive (EU) 2015/863 on behalf of the European Union of Electrical Engineers.

WEEE DIRECTIVE - DISPOSAL OF CHARGERS

Waste Electrical and Electronic Equipment (WEEE) is the Directive of the Union of Electrical Engineers. Regulation 2 Scotland and Electrical Equipment (Waste Electrical and Electronic Equipment) (WEEE) Regulations 2013 (as amended) contains a reference to WEEE Regulations.

WARNING: Illegal disposal of battery is extremely hazardous to the environment and human health. Consumers are responsible for the disposal of their waste electrical and electronic equipment (WEEE) and must ensure that it is disposed of in a way that minimizes its impact on the environment and human health. Batteries are not classified as WEEE. Batteries are classified as waste batteries and must be disposed of in a way that minimizes its impact on the environment and human health. Batteries must be removed from WEEE before disposal.

Consumers are required to return waste electrical and electronic equipment (WEEE) and waste batteries to the WEEE collection points. Consumers are required to return waste electrical and electronic equipment (WEEE) and waste batteries to the WEEE collection points.

Instructions for Users on Removal, Recycling and Disposal of Used Batteries

- Remove the battery from the WEEE before disposal. Ensure the battery is fully discharged before removal.
- Do not dispose of batteries in fire, as this can cause explosions or the release of toxic fumes. Do not dispose of batteries in the trash or in any other manner that is contrary to the local laws and regulations. Instead, take the battery to a recycling center or a designated collection point.
- Do not short-circuit the battery by connecting the positive and negative terminals together. This can lead to overheating and potential hazards. Insulate the terminals with tape or other insulating materials before disposal.
- Do not disassemble, crush, or puncture the battery. These actions can release hazardous materials and pose a risk of fire or explosion.
- The battery has been evaluated to meet general RF exposure requirement.
- Contains FCC ID: 2AC7Z-ESP32S3WROOM1U, 2AC7Z-ESP32S3WROOM1UN4

CALIFORNIA PROP 65 WARN

The Safe Drinking Water and Toxic Enforcement Act of 1986 (Proposition 65) is the following two conditions: (1) The device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Industry Canada's licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the Industry Canada's Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Contains IC: 23406-ESP32S3WROOM1U, 23406-ESP32S3WROOM1UN4

Customer Service

For FAQ and more information:
Email: support@nobiscustomer.com
www.nobiscustomer.com