Dance Mat

User Manual

If there is any issue with your order,
please contact below email to ask for warranty.
Email:DM_Bussiness@outlook.com

Package Contents



Product Overview

❶

Instruction of Function Keys

Power On / Off Knob(Volume up/down): Switch the knob referred to the direction indicated to Power on/off. Rotate the knob to adjust music volume.

MODE Button: Press the Mode button, then the indicator lights of Mode 1-6 are on. Select your preferred mode by stepping on the corresponding key, and press Start button to enjoy your game.

LEVELS Button: Press to select the difficulty levels in Mode 1-4. Please be noted that the level cannot be adjusted in Mode 5-6 as it should be endless mode

START Button: Press to start the game.

MUSIC Button: Press to switch the background music. There are 13 tracks built in and available for selection.
Press & hold 2 seconds to Play/Pause background music.
Tap to skip to the beginning of the next track;
Double tap to skip to the beginning of the previous track.

Dance Mat Setup

Step1: Unfold the Dance Mat

1.Remove the dance mat and unfold it.
2.Lay it out in a location that is flat with no sharp object (indoors is best, but certainly no sticks, rocks, etc. if you choose an outdoor spot). Make sure there is at least 7 feet of clearance around all sides in case of falls.

Notes: Remove socks or shoes. Bare feet are recommended to avoid slipping and possible damage to the dance mat. Before allowing children to use the product, always clearly and carefully instruct them on the Dance Mat user manual.

Step2: Power Supply

1.Power supply via USB-C port:
Plug the supplied USB Type-C cable to the dance mat and a USB AC adapter with power output 5V/2A(AC adapter not included), as figure shows.

2.Power supply via batteries:
① Using a small screwdriver (provided), unscrew the small screw on the battery compartment and remove the cover by pressing the finger latch.
② Insert the 4pcs new AA batteries (not included) according to the polarity marks on the inside of the battery compartment.(please refer to the battery installation diagram)
③ Replace the battery cover and screw. Tighten with the screwdriver.

Notes: Please make sure the product is turned off before power supply.

❷



Battery Installation Diagram

BATTERY WARNING AND CAUTION:

- Replacement of batteries must be done by an adult.
- Do not mix alkaline,standard, or rechargeable batteries.
- Never mix old and new batteries.

Bluetooth Connection

Switch on Power On knob, go to your Bluetooth setting on your audio device and select "Dancing Music", once connected, the prompt tone will be played, . then you can play your preferred music with dancing mat from your audio device.

How to Play

After power on, dance mat will automatically enter Challenge Mode, . you can choose your preferred built-in background music or other music from your audio device once Bluetooth connected to start the game.

Notes: The dance mat will enter Standby mode if not used for 5 minutes. Tap any button to wake it up.

Mode 1 - Challenge Mode (Total 48 levels)

- Tap Mode Button and select Mode 1 (display shows 100), then press **START** to enter the game.
- You can tap Levels button to adjust the game levels while playing the game.
- To tap the corresponding foot key on the mat to get a point.

❸

- It will be presented with a set of 1~4 command lights: once you tap the correct foot key, the "**Ding**" sound plays and you are awarded a point. If you tap the incorrect foot key or no foot key at all, a buzzing sound plays and you are not awarded a point.
- To pass the level and advance to the next, you need at least 7 points.
- After 3 incorrect answers, the game ends. You can press the **START** button to play again.

Tips: Regarding to the display panel, the first two digits of the display indicate the level, and the 3rd digit indicates the point awarded of the level.

Mode 2 - Full Light Mode (Total 48 levels)

- Tap Mode Button and select Mode 2 (display shows 200), then press **START** to enter the game.
- You can tap Levels button to adjust the game levels while playing the game.
- All keys 1-6 light up, to tap the corresponding foot key to turn off the light.
- To pass the level and advance to the next, you need to turn off the light of foot key 1-6 in specific time. If not, a buzzing sound plays and the game ends. You can press the START button to play again.

Tips: Regarding to the display panel, the first two digits of the display indicate the level, and the 3rd digit indicates the point awarded of the level.

Mode 3 - Memory Mode (Total 99 levels)

- Tap Mode Button and select Mode 3 (display shows 300), then press **START** to enter the game.
- You can tap Levels button to adjust the game levels while playing the game.
- Remember the sequence of the illuminated lights, after hearing "**Go**" sound, step on the keys in sequence to pass the level. Once you tap all correct foot key, you'll hear a victory sound then enter the next level. If you tap the incorrect foot key, a buzzing sound plays and the game will restart from current levels.
- With each level passed, the sequence of lit buttons increases, increasing the challenge.

Tips: Regarding to the display panel, the first two digits of the display indicate the level, and the 3rd digit indicates the point awarded of the level.

Mode 4 - Single Key Training Mode (Total 48 levels)

- Tap Mode Button and select Mode 4 (display shows 400), then press **START** to enter the game.
- You can tap Levels button to adjust the game levels while playing the game.
- To tap the corresponding foot key on the mat to get a point.
- After command key lights up, you tap the correct foot key, the victory sound plays and you are awarded a point. If you tap the incorrect foot key or no foot key at all, a buzzing sound plays and you are not awarded a point.
- To pass the level and advance to the next, you need at least 7 points.
- After 3 incorrect answers, the game ends. You can press the START button to play again.

Tips: Regarding to the display panel, the first two digits of the display indicate the level, and the 3rd digit indicates the point awarded of the level.

❹

✉ DM_Bussiness@outlook.com
🏠 Shenzhen Dance Master Technology Co., Ltd
🏠 5th Floor, Building A, No. 23 Guanjin Road, Shapu Community, Songgang Street, Baoan District, Shenzhen, Guangdong, China

⚠ **WARNING:**
CHOKING HAZARD- Small parts.
Not for Children under 3 years

Made In China

Mode 5 - Animal Sound Memory Mode (Endless mode)

- Tap Mode Button and select Mode 5 (display shows 500), then press **START** to enter the game.
- Each foot key will correspond to the sound of an animal (e.g., elephant, cow, cat, dog, horse, tiger).
- Remember the correspondence of each key. 1 After hearing "Go" sound, you'll hear the sound of an animal, then step on the corresponding key to pass the level. Once you tap the correct foot 1 1 key, the "**Ding**" sound plays and the next animal sound will play, the player continues stepping until all 6 buttons are correct, resulting in cheers for 1 successful completion.If you tap the incorrect foot key, a buzzing sound plays and the game will restart from current levels.

Tips: The display will show 500 on in Mode 5.

Mode 6 - Animal Meeting Friends Mode (Endless mode)

- Tap Mode Button and select Mode 6 (display shows 600), then press **START** to enter the game.
- All keys 1-6 light up, tapping each button will produce an animal sound (e.g., elephant, cow, cat, dog, horse, tiger). When two identical animal sounds are heard, the player needs to hit those two buttons. The lights on the two pressed buttons will turn off. (Note: If two buttons are pressed incorrectly, the lights will not turn off). Continue until all 6 buttons' lights are extinguished, at which point cheers indicate successful completion of 1 round.

Tips: The display will show 600 on in Mode 6.

Trouble Shooting Guide

Issue	Possible Cause	Trouble Shooting Step
Dancing mat is not working.	The device is not turned on.	Switch the knob referred to the direction indicated to Power on.
	The charging cable is not well connected.	Make sure the power adapter, Type-C cable and the device are well connected.
	The batteries are low or dead.	Replace the batteries with 4pcs new AA batteries, make sure the batteries are properly positioned in the battery compartment.
	The device has gone to sleep.	The device goes to sleep after 5 minutes of inactivity. Tap any button or key to wake it.
Music sounds distorted.	The battery is low.	Charge to power supply via USB-C port, or replace the batteries with 4pcs new AA batteries.

❺

Safe Use Warnings

- This product is not for children under 3 years of age.
- Do not swallow the batteries, EVER!
- For individuals who are not suitable to use this product,if you have any of the following conditions, please consult a doctor before using this
  - Women who are trying to conceive, pregnant, or menstruating.
  - Patients with malignant tumors, heart disease.
  - Individuals with physical intolerance.
- Children must be closely supervised by a responsible adult at all times. Never leave children unattended at any time.
- Before allowing children to use this product, a responsible adult who has read all safety warnings and instructions in this manual must clearly inform them on all safe dancing rules, safety warnings, and using common sense when dancing.
- Individual parents must determine if their children have the maturity and ability to understand and follow safety instructions. Children that cannot follow safety instructions should not use the product.
- Do not leave the product out when not in use. Always store the product against unsupervised or unauthorized use.
- Keep the product away from heat and open flames; the material will burn or melt when in contact with open flames or heat.
- Do not stand on the display screen. It could break.

Precautions

1. Keep the dance mat away from water and other liquids.
2. Do not use the dance mat in damp environments.
3. Do not place the dance mat in direct sunlight for a long time.
4. Keep the dance mat away from sharp objects to prevent surface damage.
5. Avoid using the dance mat in high-temperature environments, such as near heating devices.
6. When cleaning the dance mat, gently wipe the surface with a soft, damp cloth. Do not use any abrasive or chemical cleaners, and do not wash with water.
7. Do not place this dance mat in a place exposed to humidity,dust,acid or steam,or subject to direct sunlight.
8. Do not subject the headset to excessive shock.
9. If you have any questions or problems concerning this dance mat are not covered in this manual, please contact us by email at: **DM_Bussiness@outlook.com**.

❻

Limited 18-Month warranty

18 MONTH

What this warranty covers?
We warrant to the original purchaser of this product that the product shall be free of defectsin design,assembly,material,or workmanship.

What the period of coverage is?
We warrant the product for 18 Months.

What will we do to correct problems?
We will repair or replace,at its option,any defective product free of charge(except for shipping charges for the product).

What is not covered by this warranty?
All above warranties are null and void if the product is not provided to for inspection upon request at the sole expense of the purchaser,or if determines that the product has been improperly installed,altered in any way,or tampered with. The Product
Warranty does not protect against acts of God such as flood, earthquake, lightning, war,
vandalism, theft, normal use wear and tear, erosion, depletion, obsolescence ,abuse, damage due
to low voltage disturbances (e.g.,brownouts or sags), nonauthorized program, or system equipment modification or alteration.

How to claim the warranty
Please contact retailers or visit **DM_Bussiness@outlook.com** for more information.
To extend the warranty period, please visit our website and register as our member within 1 month of purchasing the product.

Disclaimer
Every effort has been made to ensure that the information and procedures in this guide are
accurate and complete,no liability can be accepted for any errors or omissions and we reserve the right to make any changeswithout further notice to
any products mentioned herein.

Product Specification

Unfolded Size: 36.2×35.2×0.5 in.
Net Weight: ~2.88 lbs
Maximum Weight Capacity: ~300 lbs per individual
Input Voltage: 5V DC or 4x1.5V （"AA" Size)
Operating Temperature: 50-95 °F
Battery Usage Time: ~ 3 hours

❼

FCC Statement

Note:
This equipment has been tested and found tocomply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits aredesigned to provide
reasonable protection againstharmful interference in a residential installation.
This equipment generates uses and can radiate radiofrequency energy and,
if not installed and used inaccordance with the instructions, may cause harmfulinterference to radio communications. However, there is no guarantee that interference will not occur in aparticular installation. If this equipment does causeharmful interference to radio or
television reception, which can be determined by turning the equipmentoff and on
the user is encouraged to try to correct theinterference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that towhichthe receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 ofthe FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference,and
(2)this device musta ccepany interference received, including interference that may cause undesiredoperation.

Caution!

Changes or modifications not expressly approved bythe party responsible for compliance
could vost thauser's authority to operate the equipment.

The device has been evaluated to meet general RFexposure requirement.
The device can be used inportable exposure condition without restriction.

❽