说明书尺寸：**L120*H95mm**说明书**(**折叠尺寸**)**,材质**:105g**双铜纸,双面**2**色印刷,风琴折,**L380*W360mm(**展开尺寸**)**

PANTONE 2297C　PANTONE Black 3C

OMNIBAR

INTELLIGENT POSITIONING

SWIFT TAG USER GUIDE

追踪器用户指南

追跡用ユーザーガイドです

AT53A

EN

IMPORTANT SAFETY INSTRUCTIONS

Before using this Bluetooth Tracker, thoroughly read all warnings and instructions. To avoid risks like explosions, fires, electric shocks, or personal injury, adhere strictly to these guidelines and those from the manufacturers of any equipment you use with the Bluetooth Tracker. Omnibar may update this information without prior notice. For the latest updates and the most recent User Manual, visit www.omnibar.com.

WARNINGS

Please read all the instructions before using the product:

- This product has a built-in 3V Li-Mn button cell battery. Do not disassemble, hit, crush, or throw it into the fire.
- Discontinue use immediately if the battery is severely swollen.
- Do not use it in a high-temperature environment.
- Do not use the battery if it is immersed in water!
- Please keep this product out of the reach of children.
- If the battery has been accidentally swallowed or placed inside any part of the body, please seek medical attention immediately, or it may cause severe internal burns or other hazards.
- If the battery compartment is not securely closed, stop using the product and keep it away from children.
- Do not charge the battery. If the battery is low, please replace it in time. Do not reverse the polarity when replacing the battery.
- To prevent product damage from battery leakage and corrosion, remove the battery if not in use for prolonged periods.
- If battery leakage occurs, avoid contact with skin or eyes. In case of contact with skin or eyes, rinse with water and seek medical attention immediately.
- Keep the dead battery out of the reach of children, and dispose of or recycle it properly according to local laws and regulations.

TECHNICAL SPECIFICATIONS

MODEL: AT53A
BATTERIES: CR2032 Lithium Metal batteries required. (included)
CONNECTIVITY TECHNOLOGIES: Bluetooth 5.3
OPERATING SYSTEM: iOS or iPadOS 14.5 or newer
SOUND SEARCH: 10-20M(Indoor)/ 20-50M(outdoor)
VOLUME: 105dB(Sound Output at 10cm)
OPERATING TEMPERATURE: -10~45℃
MATERIALS: Fireproof PC
SIZE: ~43.5*43.5*7.95mm
WEIGHT: 8.7g
FCC ID: 2BM7E-AT53A

IN THE BOX

Bluetooth Tracker X 4
Protective Cover X 4
Instruction Manual
3M Adhesive X 8

PRODUCT BINDING

1. Remove the insulating film

2. Enable the "Find My" app on your iPhone

3. Go to "Items" > "Add Item"

4. Bring the Smart Bluetooth Finder near your iPhone. wait for device search

5. Click "Connect" and rename it

PRODUCT FIND

1. Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch.
2. Tap on your Smart Bluetooth Finder from the list.
3. Click "Directions" and follow the distance shown on the map to find the Smart Bluetooth Finder;
4. Tap "Play Sound" to make your Smart Bluetooth Finder beep.
5. Tap "Stop Sound" to stop the beeps once you find.

PRODUCT REMOVE BINDING

1. On the Device TAB page, slide down the menu and click "Remove Item".
2. Confirm the device account information that has been bound to avoid false removal.
3. Finally, click "Remove" to confirm.







BATTERY REPLACEMENT

1. Turn counterclockwise to open

2. Put the battery in with the positive polarity(+)facing up

3. Turn clockwise to close

ENABLING "NOTIFY WHEN LEFT BEHIND"

1. Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch.
2. Tap on your Smart Bluetooth Finder from the list.
3. Under "Notifications" enable the "Notify When Left Behind" toggle.
4. You will receive a notification when you leave your Smart Bluetooth Finder behind and its no longer in range of your device.

ENABLING "NOTIFY WHEN FOUND"

1. Under "Notifications", enable the "Notify When Found" toggle.
2. When your Smart Bluetooth Finder is seen by another Find My network device, you will receive a notification of its location.

Note: "Notify when found" can only be activated when your Smart Bluetooth Finder is out ofrange.

ENABLING "LOST MODE"

1. Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch.
2. Tap on your Smart Bluetooth Finder from the list.
3. Under "Lost Mode" tap "Enable".
4. A screen detailing Lost Mode will pop up, tap "Continue".
5. Enter your phone number or email address and tap "Next".
6. You may enter a message that will be shared with the person that finds your item.
7. Tap "Activate" to enable "Lost Mode.

Note: When "Lost Mode" is enabled, "Notify When Found" is automatically enabled.
Note: When" Lost Mode" is enabled, your Smart Bluetooth Finder is locked and cannot be paired to a new device.

REMOVE THE SMART BLUETOOTH FINDER FROM MY APP

1. Open Find My app and select the "Items" tab.
2. Tap on your Smart Bluetooth Finder from the list.
3. Please ensure "Lost Mode" is disabled.
4. Scroll to the bottom of the screen and tap "Remove Item".
5. A summary will open, tap "Remove" to confirm.
6. After successfully removing the Smart Bluetooth Finder from Find My app, open the case and remove the battery.
7. Insert the battery and hear a sound. This sound indicates that the battery is connected. When you hear a sound, repeat the operation for four more times (remove the battery, insert it. You should hear a sound every time you Insert the battery; A total of five sounds will be heard during the whole process. The fifth tone is different from the first four.
8. The Smart Bluetooth finder is now reset and ready to be paired to a new Apple ID.

UNWANTED TRACKING

If any Find My network accessory separated from its owner is seen moving with you over time you'll be notified in one of two ways:
1. If you have an iPhone, iPad, Find My will send a notification to your Apple device. This feature is available on iOS or iPad0S 14.5 or later.
2. If you don't have an iOS device or a smartphone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when it's moved.
These features were created specifically to discourage people from trying to track you without your knowledge.

SAFETY INSTRUCTIONS

- Avoid moisture. Do not use aerosol, solvent or abrasive agents to clean theproduct.
- Keep out of reach of children to avoid accidental swallowing.
- The product has built-in battery, please stop use when it is swollen.
- Do not expose the product to excessive temperature.
- Stop using when the product is submerged.

ABOUT APPLE FIND MY

The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch.
To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS.
Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.
Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPados, Mac, macOS and watchOS are trademarks of Apple Inc.

FCC COMPLIANCE STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1)Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3)Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help.

Omnibar is a trademark of Omnibar LLC. All the images and text in this user guide are the copyright of Omnibar. The photos and illustrations in this guide may differ from the actual product.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WEEE INFORMATION

Disposal and recycling information This product and battery should not be used as household garbage or thrown into the fire. When you decide to dispose of the product and battery, please handle the battery according to the local environment all laws to avoid explosion.

WARNING: Do not disassemble, crush, or expose to fire or high temperatures. If significant swelling occurs, discontinue use immediately. Never use after submersion in water.

Only suitable for safe use in non-tropical climates
Made in China

CN

重要的安全说明

在使用本产品前请仔细阅读所有警告和说明。为避免爆炸、火灾、触电或人身伤害等危险，请严格遵守这些指导方针。
以及与蓝牙追踪器一起使用的任何设备的制造商提供的信息。Omnibar可能会在不事先通知的情况下更新此信息。有关最新更新和最新用户手册，请访问www.omnibar.com。

警告

使用本产品前请仔细阅读所有使用说明：

- 本产品内置3V锂纽扣电池，请勿拆卸，撞击，压碎或扔入火中。
- 如果电池严重肿胀，请立即停止使用。
- 请勿在高温环境下使用。
- 请勿将电池浸入水中使用！
- 请将本产品放在儿童接触不到的地方。
- 如果电池意外吞下，请立即寻求医疗帮助，或立即就医，否则可能会导致严重的内部烧伤或其他危险。
- 如果电池仓没有完全关闭，请停止使用本产品并将其置于儿童接触不到的地方。
- 请勿给电池充电。如果电池电量不足，请及时更换。更换电池时，请勿调换极性。
- 为防止电池漏液和腐蚀损坏产品，请在长时间不使用时取出电池。
- 如果电池漏液，请避免接触皮肤或眼睛。如不慎接触皮肤或眼睛，请立即用清水冲洗并就医。
- 将废电池放在儿童接触不到的地方，并妥善处理或回收遵守当地法律法规。

技术规格

型号: AT53A
电池: 使用CR2032锂金属电池(包含)
连接技术: 蓝牙 5.3
操作系统: iOS、iPadOS 14.5及以上
声音搜索: 10-20M (室内) / 20-50M (室外)
音量: 83dB (声音输出在10cm)
工作温度: -10~45℃
材料: 防火PC
尺寸: 43.5*43.5*7.95mm
重量: 8.7g
FCC ID: 2BM7E-AT53A

包装内容

产品追踪器 X 4
保护套 X 4
使用说明书
3M胶 X 8

产品绑定

1. 去掉绝缘膜

2. 在iPhone上启用"查找我的"应用程序

3. 前往"物品">"添加物品"



4. 将智能追踪器放在您的iPhone附近，等待设备搜索

5. 点击"连接"并重命名

产品查找

1. 打开"查找我的"应用程序，选择"物品"标签，或者打开Apple Watch上的"查找物品"应用程序。
2. 从列表中点击您的智能蓝牙追踪器。
3. 点击"方向"，按照地图上显示的距离找到智能蓝牙追踪器；
4. 点击"播放声音"，让你的智能蓝牙查找器发出响声。
5. 找到追踪器后，点击"停止声音"停止响声。





产品解除绑定

1. 在"设备选项卡"页上，向下滑动菜单并单击"删除物品"。
2. 确认已绑定的设备账号信息，避免误移除。
3. 最后，点击"删除"确认。

电池更换

1. 逆时针旋转打开

2. 将电池正极性（+）朝上放入

3. 顺时针旋转关闭

提示"待命时通知"

1.打开"查找我的"应用程序并选择"物品"选项卡，或打开Apple Watch上的"查找物品"应用程序。
2.从列表中点击您的智能蓝牙追踪器。
3.在"通知"下启用"待命时通知"。
4.当你离开你的智能蓝牙追踪器，并且它不再在你的设备范围内时，你会收到通知。

警告"发现时通知"

1.在"通知"下，切换"发现时通知"。
2.当您的智能蓝牙追踪器被另一台"查找我的"网络设备看到时，您将收到其位置的通知。

*注意：*发现时通知"只能在智能蓝牙追踪器超出范围时激活。

振动"丢失模式"

1.打开"查找我的"应用程序并选择"物品"选项卡，或打开Apple Watch上的"查找物品"应用程序。
2.从列表中点击你的智能蓝牙追踪器。
3.在"丢失模式"下点击"启用"。
4.将展示一个详细说明丢失模式的屏幕，点击"继续"
5.输入您的电话号码或电子邮件地址，然后点击"下一步"
6.您可以输入一条消息，该消息将与找到您物品的人共享。
7.点击"激活"以启用"丢失模式"。

*注意：*启用"丢失模式"时，会自动启用"发现时通知"
*注意：*启用"丢失模式"时，您的智能蓝牙追踪器将被锁定，无法与新设备配对。

从我的应用中移除智能蓝牙追踪器

1.打开"查找我的"应用。
2.从列表中选择您的智能蓝牙追踪器。
3.请确保"丢失模式"已禁用。
4.滚动到屏幕底部并点击"移除物品"。
5.将打开一个摘要，点击"移除"以确认。
6.在成功从"查找我的"应用程序中移除智能蓝牙查找器后，打开外壳并取下电池。
7.插入电池并听到声音。这个声音表示电池已连接。当你听到声音时，重复操作四次（取出电池，插入电池，你应该每次插入电池时都会听到声音；在整个过程中总共会听到五次声音，第五个音调与前面四个不同。
8.智能蓝牙查找器现在已经重置，并准备与新的Apple ID配对。

箱の中

智能追踪器 X 4
保護カバー X 4
取扱説明書
3M粘着材 X 8

製品のバインディング

1. 絶縁フィルムを剥がす

2. iPhoneで「探す」アプリを有効にする

3. 「持ち物」>「持ち物を追加」に移動します

4. 智能手追跡装置をiPhoneの近くに置き、デバイスの検索を待ちます。

5.「接続」をクリックして名前を変更します

製品検索

1.「探す」アプリを開いて「持ち物」タブを選択するか、Apple Watch で「持ち物探す」アプリを開きます。
2.リストから智能手追跡装置をタップします。
3.「経路」をクリックし、地図に表示された距離に従って智能手追跡装置を見つけます。
4.「サウンドを再生」をタップして、智能手追跡装置へのビープ音を鳴らします。
5.「サウンドを停止」をタップして、見つかったらビープ音を停止します。

製品のバインディングを削除

1. デバイスタウページで、メニューを下にスライドし、「持ち物を削除」をクリックします。
2. 誤って削除されないようにするために、バインドされたデバイスとアカウントの情報を確認します。
3. 最後に、「削除」をクリックして確認します。





未经授权跟踪

如果发现任何与其使用者分离、"查找我的"网络配件随着时间的推移与您一起移动，您将通过以下两种方式之一收到通知：
1.如果您有iPhone或iPad。"查找我的"将向您的App设备发送通知。此功能在iOS或iPad OS14.5或更高版本上可用。iOS或iPad0S的不久将来上入市一起时，应发出声音。
2.如果你没有iOS设备或智能手机，"查找我的"网络配件出现能力指出他人在你不知情的情况下追踪你的物品。

安全说明

- 避免潮湿。不要使用气雾剂、溶剂或研磨剂清洁产品。
- 放置在儿童接触不到的地方，以免异吞食。
- 产品内置电池，请勿使用。
- 不要将产品暴露在过高的温度下。
- 产品浸没后，请停止使用。

关于Apple查找我的

Apple查找我的网络可通过iPhone、iPad、Mac上"查找我的"应用或Apple Watch上的"查找物品"应用，轻松、安全地查找兼容的个人物品。
要使用Apple"查找我的"应用程序来定位此物品，最新版本的iOS、iPadOS或macOS是推荐。Apple Watch 上的"查找物品"应用程序需要最新版本的watchOS。使用Works with Apple徽章表明配件产品专为使用蓝牙特定技术而设计，并且已经过产品制造商认证，符合Apple查找我的网络产品规格和要求。Apple不对本设备的操作或本产品的使用或其对安全和监管标准的遵守情况负责。
Apple、Apple Find My、Apple Watch、Find My、iPhone、iPad、iPadOS、Mac、macOS和watchOS是苹果公司的商标。

FCC符合性声明

本设备符合 FCC 规则第 15 部分的规定。操作须遵守以下两个条件：(1) 本设备不得造成有害干扰，(2) 本设备必须接受任何收到的干扰，包括可能导致意外操作的干扰。

警告： 未经合规负责方明确批准的更改或修改可能会使用户无权操作该设备。
注意： 本设备已通过测试，符合 FCC 规则第 15 部分对 B 类数字设备的限制。这些限制旨在为住宅安装提供合理的保护，防止有害干扰。本设备会产生、使用并能辐射射频能量，如果不按照说明进行安装和使用，可能会对无线电通信造成有害干扰。但是，不能保证在特定安装中不会发生干扰。如果本设备确实对无线电或电视接收造成有害干扰（可通过关闭和打开设备来确定），则建议用户尝试通过以下一种或多种措施来纠正干扰：(1) 重新调整或重新放置接收天线。(2) 增加设备与接收器之间的距离。(3) 将设备连接到与接收器所连接电路不同的电路插座上。(4) 咨询经销商或经验丰富的无线电/电视技术人员寻求帮助。

Omnibar 是 Omnibar LLC 的商标。本用户指南中的所有图片和文字均为 Omnibar 的版权所有。本指南中的照片和插图可能与实际产品不同。

该装置已经证评估，可满足一般射频暴露要求。本装置可在使用无暴露条件下使用，不受任何限制。

電子廃棄物説明

処置或回收本产品电池不应作为家庭垃圾或扔进火中。当您决定处置本产品电池时，请根据当地环境法规处理电池，以避免爆炸。

警告：禁止拆解、撞击、挤压或投入火中。若出现严重鼓胀，切勿继续使用。切勿置于高温环境中，潜水后禁止使用。

仅适用于非热带气候下安全使用
中国制造

重要な安全注意事項

このパワーバンクを使用する前に、すべての警告と指示をよくお読みください。爆発、火災、感電、人身傷害などのリスクを回避するために、これらのガイドラインと、パワーバンクで使用する機器の製造元からのガイドラインを厳守してください。Omnibar は、この情報を予告なしに更新する場合があります。最新の更新および最新の使用説明書については、www.omnibar.com をご覧ください。

警告

この製品を使用する前に、すべての指示をよくお読みください：

- この製品にはリチウムマンガン二酸化コイン型電池が内蔵されています。分解したり、衝撃を与えたり、押したり、つぶしたり、火の中に投げたりしないでください。
- バッテリーがひどく膨張したら、使用を中止してください。
- 高温環境では使用しないでください。
- バッテリーを水に浸けない！
- この製品はお子様の手の届かないところにおいてください。
- 電池を誤って飲み込んだり、身体の一部に入ったりした場合は、重度の火傷やその他の危険がおこる可能性があるため、直ちに医師の診察を受けてください。
- 電池ボックスが完全に閉まっていない場合は、製品の使用を中止し、お子様の手の届かない場所に保管してください。
- バッテリーを交換しないでください。電池残量が少なくなった場合は、早めに交換してください。電池を交換するときは、極性を逆にしないでください。
- 電池の液漏れや腐食による製品の損傷を防ぐために、長期間使用しない場合は電池を取り外してください。
- 電池が漏れた場合は、皮膚や目に触れないようにしてください。誤って皮膚や目に触れた場合は、すぐにきれいな水で洗い流し、医師の診察を受けてください。
- 使用済みの電池はお子様の手の届かない場所に保管し、現地の法律や規制に従って適切に廃棄またはリサイクルしてください。

技術仕様

モデル: AT53A
電池: CR2032リチウム金属電池（付属）を使用
接続技術: BLUETOOTH 5.3
オペレーティングシステム: iOS、iPadOS 14.5いじょう
音声検索: 10~20M (屋内) / 20~50M (屋外)
音量: 83DB (10CM で の音出力)
動作温度: -10~45℃
材質：耐火PC
サイズ: 43.5*43.5*7.95mm
重量: 8.7g
FCC ID: 2BM7E-AT53A

箱の中

智能追踪器 X 4
保護カバー X 4
取扱説明書
3M粘着材 X 8

製品のバインディング

1. 絶縁フィルムを剥がす

2. iPhoneで「探す」アプリを有効にする

3. 「持ち物」>「持ち物を追加」に移動します

4. 智能手追跡装置をiPhoneの近くに置き、デバイスの検索を待ちます。

5.「接続」をクリックして名前を変更します

製品検索

1.「探す」アプリを開いて「持ち物」タブを選択するか、Apple Watch で「持ち物探す」アプリを開きます。
2.リストから智能手追跡装置をタップします。
3.「経路」をクリックし、地図に表示された距離に従って智能手追跡装置を見つけます。
4.「サウンドを再生」をタップして、智能手追跡装置へのビープ音を鳴らします。
5.「サウンドを停止」をタップして、見つかったらビープ音を停止します。

製品のバインディングを削除

1. デバイスタウページで、メニューを下にスライドし、「持ち物を削除」をクリックします。
2. 誤って削除されないようにするために、バインドされたデバイスとアカウントの情報を確認します。
3. 最後に、「削除」をクリックして確認します。

不正な追跡

「探す」ネットワークアクセサリがユーザーから離れ、時間の経過とともにユーザーと一緒に移動していることが判明した場合、次の2つの方法のいずれかで通知されます。
1. iPhone または iPad を お持ちの場合は、「探す」から Appe デバイスに通知が送信されます。この機能は、iPhone または iPad iPhone 14.5 以降で利用できます。iOS いじゃ一定時間離れているときに機能します。
2. iOS デバイスやスマートフォンをお持ちでない場合は、「探す」ネットワーク機能を使用すると、知らないうちに他人に追跡されるのを防ぐことができます。

安全に関する注意事項

- 湿気を避ける。製品を清掃する際にはエアゾール、溶剤、研磨剤を使用しないでください。
- 誤って飲み込まないように、お子様の手の届かない場所に保管してください。
- 製品は内蔵バッテリーです。膨れがある場合は使用を中止してください。
- 製品を過度の温度にさらさないでください。
- 一度水に浸かってしまったら使用を中止してください。

APPLE探すについて

Apple の「探す」ネットワークを使用すると、iPhone、iPad、Mac の「探す」アプリ、または Apple Watch のアイテムを探すアプリを通じて、互換性のある個人用アイテムを簡単かつ安全に見つけることができます。Apple の「探す」アプリを使用してこのアイテムを見つけるには、最新バージョンの iOS、iPadOS、または macOS を推奨します。Apple Watch の「Find Things」アプリには、watchOS の最新バージョンが必要です。Works with Apple バッジを使用することは、製品がバッジで識別されたテクノロジーと連携するように設計されており、Apple の Find My Network 製品仕様と要件を満たしていることが製品メーカーによって認定されていることを意味します。Apple は、本デバイスの操作、本製品の使用、または安全および規制基準への準拠については一切責任を負いません。
Apple、Apple Find My、Apple Watch、Find My、Phone、iPad、iPadOS、Mac、macOS、watchOS は、Apple Inc. の商標です。

FCC適合宣言です

このデバイスは、FCC 規則のパート 15 に準拠しています。操作には、次の 2 つの条件が適用されます：(1) このデバイスは有害な干渉を引き起こしてはならず、(2) このデバイスは、望ましくない操作を引き起こす可能性のある干渉を含め、受信した干渉をすべて受け入れるなければなります。

警告：準拠責任者によって明示的に承認されていない変更または修正を行うと、ユーザーの機器操作権限が無効になる場合があります。
注：この機器は、FCC 規則のパート 15 に従って、クラス B デジタル デバイスの制限に準拠していることがテストで確認されています。これらの制限は、住宅への設置において有害な干渉に対する適切な保護を提供するように設計されています。この機器は、無線周波数エネルギーを生成、使用、および放射する可能性があり、指示に従って設置および使用していないと、無線通信に有害な干渉を引き起こす可能性があります。ただし、特定の設置で干渉が発生しないという保証はありません。この機器がラジオやテレビの受信に有害な干渉を引き起こしている場合（機器の電源のオンとオフによって確認できます）、ユーザーは次の 1 つ以上の対策を実行して干渉を修正することをお勧めします。(1) 受信アンテナの方向を変えるか、場所を移動します。(2) 機器と受信機の距離を広げます。(3) 受信機が接続されている回路とは別の回路のコンセントに機器を接続します。(4) 販売店または経験豊富なラジオ/テレビ技術者に相談してください。

Omnibar は Omnibar LLC の商標です。このユーザー ガイドのすべての画像とテキストの著作権は Omnibar が所有します。このガイドの写真やイラストは実際の製品と異なる場合があります。

この装置は、一般的な無線周波数の露出要件を満たしていると評価されています。この装置は、任意の制限を受けることなく、携帯型の露出条件で使用することができます。

WEEE情報

廃棄およびリサイクルに関する情報：この製品およびバッテリーは、家庭ごみとして使用したり、火の中に投げ込んだりしないでください。製品およびバッテリーを廃棄する場合は、爆発を防ぐために、地域の環境法に従ってバッテリーを取り扱ってください。

警告：分解、粉砕、火や高温への曝露はしないでください。著しい膨張が起こった場合は、直ちに使用を中止してください。水に浸した後は絶対に使用しないでください。

非熱帯気候での安全な使用にのみ適しています
中国製です

FCC合性声明

本设备符合 FCC 规则第 15 部分的规定。操作须遵守以下两个条件：(1) 本设备不得造成有害干扰，(2) 本设备必须接受任何收到的干扰，包括可能导致意外操作的干扰。

警告： 未经合规负责方明确批准的更改或修改可能会使用户无权操作该设备。
注意： 本设备已通过测试，符合 FCC 规则第 15 部分对 B 类数字设备的限制。这些限制旨在为住宅安装提供合理的保护，防止有害干扰。本设备会产生、使用并能辐射射频能量，如果不按照说明进行安装和使用，可能会对无线电通信造成有害干扰。但是，不能保证在特定安装中不会发生干扰。如果本设备确实对无线电或电视接收造成有害干扰（可通过关闭和打开设备来确定），则建议用户尝试通过以下一种或多种措施来纠正干扰：(1) 重新调整或重新放置接收天线。(2) 增加设备与接收器之间的距离。(3) 将设备连接到与接收器所连接电路不同的电路插座上。(4) 咨询经销商或经验丰富的无线电/电视技术人员寻求帮助。

Omnibar 是 Omnibar LLC 的商标。本用户指南中的所有图片和文字均为 Omnibar 的版权所有。本指南中的照片和插图可能与实际产品不同。

该装置已经证评估，可满足一般射频暴露要求。本装置可在使用无暴露条件下使用，不受任何限制。

電子廃棄物説明

処置或回収本产品电池不应作为家庭垃圾或扔进火中。当您决定处置本产品电池时，请根据当地环境法规处理电池，以避免爆炸。

警告：禁止拆解、撞击、挤压或投入火中。若出现严重鼓胀，切勿继续使用。切勿置于高温环境中，潜水后禁止使用。

仅适用于非热带气候下安全使用
中国制造

LIST OF TOXIC AND HAZARDOUS SUBSTANCES IN ELECTRONIC PRODUCTS

Part Name	Poisonous Or Harmful Substance Or Element				
	(Pb)	(Hg)	(Cd)	(Cr+CVI6)	(PBB)	(PBDE)
Equipment	X	O	O	O	O	O

This form is prepared in accordance with SJ/T 11364
O: indicates that the content of the hazardous substance in all homogeneous materials of the component is below the limit requirements stipulated in GB/T 26572.
X: indicates that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit requirements stipulated in GB/T 26572.
For the parts marked "X" in the table, the replacement of hazardous substances cannot be realized due to the limitation of global technological development level.
The product you purchase may not contain all of the above components.

The number in this label indicates that the product has an environmental protection service life of 10 years under normal use condition. Some parts may also have an environmental service life label, and the number in the label shall prevail.

WARRANTY

This device has a 1-year warranty, covering 12 months from the date of purchase (the "warranty period"). During the warranty period, if a device failure occurs under normal use due to a manufacturing defect, Omnibar will repair or replace the device. The company reserves the right to verify that proper use and maintenance guidelines were followed.

CONDITIONS THAT VOID THIS WARRANTY:

1. Unauthorized repair, disassembly, or alteration of any kind.
2. Evidence of abnormal usage or misuse.
3. Damage from dropping, abuse, or negligence.
4. Damages caused by failure to follow the operating instructions.
5. Tampering with the product's original serial number label and other similar markings.
6. Fake products, including those indicated by a missing product serial number or nonconformity between the product model and serial number.
7. Improper storage, such as long-term exposure to humidity or temperatures outside the parameters specified in the technical specifications of this user's guide.
8. Expiration of the product warranty.

FORCE MAJEURE: Omnibar shall not be liable for any failure or delay in performing any of its obligations under this warranty if such failure or delay is caused by or results from events beyond its reasonable control, including, but not limited to:
A. Natural disasters (e.g., earthquakes, floods, hurricanes, wildfires)
B. Acts of God
C. War, invasion, or acts of terrorism
D. Civil unrest, riots, or strikes
E. Government actions, regulations, or restrictions
F. Epidemics, pandemics, or quarantines
G. Power outages or electrical failures
H. Supply chain disruptions

Dear user, this warranty card is your future warranty application voucher, please cooperate with the seller to fill in and properly Keep it for later!

User information			
User name		E-mail	
Contact Number		Zip code	
Address of correspondence			
Product Information			
Product name		Model number	
Product barcode/number/batch number			
Seller Information			
Name			
Address			
Contact Number		Zip code	
Date of sale		Invoice number	
Remarks			

The above information shall be filled in by the buyer

+1(208)252-5229　www.omnibar.com