说明书尺寸：70*90MM

PANTONE 2297C　PANTONE Black 3C

OMNIBAR

10,000mAh

MAGFAST POWER BANK XL USER GUIDE

20W磁吸快充移动电源用户指南

マグネット式クイックチャージ10パワーバンク用ユーザーガイド

#MAGFAST

IMPORTANT SAFETY INSTRUCTIONS

Before using this power bank, thoroughly read all warnings and instructions. To avoid risks like explosions, fires, electric shocks, or personal injury, adhere strictly to these guidelines and those from the manufacturers of any equipment you use with the power bank. Omnibar may update this information without prior notice. For the latest updates and the most recent User Manual, visit www.omnibar.com.

WARNINGS

INSTRUCTIONS PERTAINING TO RISK OF FIRE, ELECTRIC SHOCK, OR PERSONAL INJURY.

With great power comes great responsibility

When using this power bank, basic safety precautions should always be followed. Please read all the instructions before using the product:

- **KEEP AWAY FROM CHILDREN:** Don't allow children to operate or play with the power bank.
- **ALWAYS KEEP DRY:** Protect the power bank from rain, snow, and any form of liquid. Do not charge or use the power bank if it's exposed to liquid. If internal components get wet, your power bank MUST be disposed of. Isopiate it is a fire safe location before disposal. Failure to comply with these guidelines could cause serious damage, injury, or worse. Contact your local fire department if you see any sparks or smell burning.
- **FLAME-FREE ZONE:** Keep smoking, sparks, and flames away from the power bank.
- **AVOID STATIC:** Do not expose the device to strong electrostatic or electromagnetic interference.
- **HANDLE GENTLY:** Avoid dropping or severe impacts to ensure the power bank works smoothly.
- **DO NOT TAMPERING:** Do not attempt to open the power bank casing. Never allow foreign objects to enter into inputs, outputs or ventilation holes.
- **NO BATTERY REPLACEMENT:** Do not try to replace or alter the power bank battery. It is non-replaceable but not rechargeable.
- **PROFESSIONAL SERVICING ONLY:** Only a qualified repair person should service the device using the correct parts to ensure continued safety.

TECHNICAL SPECIFICATIONS

MODEL: PBK10KD
CAPACITY: 10,000mAh(3.7V 37Wh)
RATED CAPACITY: 5800mAh(5V⎓2.4A)
USB-C INPUT: 5V⎓3A 9V⎓2.22A 12V⎓1.67A(20W Max)
USB-C OUTPUT: 5V⎓2.4A 9V⎓2.22A 12V⎓1.67A(20W Max)
WIRELESS CHARGING: 5W / 7.5W / 10W / 15W
TOTAL OUTPUT: 5V⎓2.4A
MATERIALS: Fireproof PC+ABS Plastic
SIZE: 106.6*68.9*20mm
WEIGHT: 198g

IN THE BOX

Power Bank X 1
2ft USB-C to USB-C Charging Cable X 1
Instruction Manual X 1

PRODUCT OVERVIEW

Recharging Power Bank

Charging Your Phone or Tablet Using Charging Cables

Charging Other Devices

Charging an iPhone and Other Devices Wirelessly

OPERATING GUIDELINES

- **AVOID WATER:** When traveling, take care to keep it dry; avoid rain, snow and any water. It's also best to keep it cool and shaded from direct sunlight.
- **KEEP IT COOL:** Give your power bank some breathing room. Don't stack things on it or block its ventilation while in use or in storage.
- **COOL DOWN BEFORE CHARGING:** After a full discharge, let your power bank chill for 1-2 hours before recharging. It's like letting it take a nap and prolong the life of your battery!
- **RECHARGE REGULARLY:** To preserve the battery, use and recharge the power bank at least every three months.
- **ONE PORT, ONE DEVICE:** Don't overload it! Only power one device per port or socket on the power bank. Using a cheap or much-quicker-to-drain device can cause overheating issues.
- **USE CERTIFIED ACCESSORIES:** Trust all accessories, attachments and appliances used with the power bank are safety certified to avoid potential hazards.
- **PULL THE PLUG:** When disconnecting, pull the plug and the cord. It's less likely to break into an accidental tug-of-war, damaging your cables or power bank.
- **INSPECT CORDS:** Ensure that cords, plugs, and cables are not damaged before ulling with the power station.
- **CHECK FOR DAMAGE:** If you spot any cracks or damage, stop using the power bank immediately. Avoid contact with any leaked liquid. The battery acid can be irritating or worse. If it touches skin or eyes, flush with water and seek medical attention.
- **AVOID USING DAMAGED UNITS:** Do not operate the power bank or any connected devices if they are damaged or altered.

OPERATION INSTRUCTIONS

- **To check battery status:** Press the button once to check the battery status (remaining power). The indicator will light up about 30s before it automatically turns off.
- **When charging using a cable:** The power bank will automatically starts to output when you connect a charging cable to it. However, due to compatibility issues, for some phones you need to press the power button once to start charging. The output mode will stay for 30s after you press the button, during which if there's no device connected, the mode will automatically shut down.
- **When charging wirelessly:** This product has an auto-wake function for wireless charging, just place your phone onto it, and it will automatically start charging. But for some phones, due to compatibility issues, the wireless charging function needs to be activated by pressing the button. Press it once, the battery indicator will light up and the wireless charging is turned on, and you can place your device on. If there's no load connected for the wireless charging in 30s, the product will automatically shut off the wireless charging function.

WIRELESS CHARGING TIPS

Place your phone onto the wireless charging area (as it shows in the picture) for wireless charging. The distance between the charging phone and the power bank must be within 8mm for wireless charging to work. If not it will stop charging, and you need to adjust the phone's position.

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help.

Omnibar is a trademark of Omnibar LLC. All the images and text in this user guide are the copyright of Omnibar. The photos and illustrations in this guide may differ from the actual product.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WEEE INFORMATION

Disposal and recycling information This product and battery should not be used as household garbage or thrown into the fire. When you decide to dispose of the product and battery, please handle the battery according to the local environment all laws to avoid explosion.

WARNING: Do not disassemble, crush, or expose to fire or high temperatures. If significant swelling occurs, discontinue use immediately. Never use after submersion in water.

Only suitable for safe use in non-tropical climates
Made in China

产品概述

警告

有关火灾、触电或人身伤害风险的说明。

权力越大，责任越大！

使用此移动电源时，应始终遵循基本的安全预防措施。使用产品前，请阅读所有说明：

- **请远离儿童：**请勿让儿童操作或玩弄移动电源。
- **始终保持干燥：**保护移动电源免受雨、雪及和任何形式的液体的侵扰。如果移动电源接触到液体，请勿充电或使用。如果内部组件被浸湿，则必须丢弃移动电源。丢弃前请将其隔离在防火位置。不遵守这些准则可能会导致严重伤害、受伤或更糟的情况。如果您看见任何火花或闻到烧焦味，请联系当地消防部门。
- **无火区：**请吸烟、火花和火焰远离移动电源。
- **避免静电：**请勿将设备暴露在强静电或电磁干扰下。
- **轻拿轻放：**避免掉落或严重撞击，以确保移动电源正常工作。
- **禁止篡改：**请勿尝试打开移动电源外壳。切勿让异物进入输入、输出口。
- **不可更换电池：**请勿尝试更换或改装移动电源电池。
- **仅供专业维修：**只有合格的维修人员才能使用正确的零件维修设备，以确保安全。

技术规格

型号：PBK10KD
电池类型：聚合物锂电池
容量：10,000mAh
容量：10,000mAh(3.7V 37Wh)
额定容量：5800mAh(5V⎓2.4A)
USB-C输入：5V⎓3A 9V⎓2A(18W Max)
USB-C输出：5V⎓2.4A 9V⎓2.22A 12V⎓1.67A(20W Max)
无线输出：5W / 7.5W / 10W / 15W
总输出：5V⎓2.4A
材料：防火PC+ABS塑料
尺寸：106.6*68.9*20mm
重量：198g
执行标准：GB 4943.1-2022;GB 31241-2022
制造商：深圳市欧迪斯科技有限公司

包装内容

移动电源 X 1
2英尺USB-C充电电缆 X 1
使用说明书 X 1

为自己充电

为手机或平板电脑充电

为其他设备充电

使用无电线为手机或平板电脑充电

为 iPhone 和其他设备无线充电

操作指南

- **避免潮湿：**旅行时，注意保持干燥；避免雨、雪和任何液体。最好保持干燥并避免阳光直射。
- **保持干爽：**给您的移动电源留出一些呼吸空间。使用或储存时，请勿在其上堆放物品或阻挡其通风口。
- **充电前降温：**完全放电后，让您的移动电源冷却1-2小时后再充电。这有电池寿命！
- **定期充电：**为保护电池，请至少每3个月使用和充电一次移动电源。
- **一个端口，一个设备：**不要超载！请勿在单上的每个端口或插座只能为一个设备供电。切勿连接易宜电源的廉价、电速快的设备。
- **仅使用经认证的配件：**确保与移动电源一起使用的所有配件、附件和设备都经过安全认证，以避免潜在危险。
- **轻轻拔头：**断开连接时，拔掉插头。避免拉扯连接数据线或移动电源部件。
- **检查电线：**在使用电源之前，确保电源线、插头和数据线没有损坏。
- **检查损坏情况：**如果发现任何裂缝或损坏，请立即停止使用移动电源。避免接触任何泄漏的液体。电池酸可能会刺激或更糟。如果接触到皮肤或眼睛，请用水冲洗并就医。
- **避免使用损坏的设备：**如果移动电源或任何连接的设备出现损坏或变形，请勿操作它们。

操作说明

- **检查电池状态：**按一下按钮检查电池状态（剩余电量）。指示灯亮约30秒后自动灭。
- **有线充电时：**连接充电线后，移动电源自动开始输出。但由于兼容性问题，部分手机需要按一下电源键才能开始充电。那一下按钮后输出模式会持续30秒，期间若没有设备连接，则自动关闭。
- **无线充电时：**本产品具有无线充电自动唤醒功能，将手机放置于其上，即可自动开始充电。但由于兼容性问题，部分手机需要按一下按钮才能开启无线充电功能。按一下按钮后，无线充电指示灯亮起，充电功能开启，您现在可放置设备。若30秒内未连接任何设备进行无线充电，则该产品将自动关闭无线充电功能。

无线充电技巧

将手机放置在无线充电区域（如图所示）即可进行无线充电。充电手机与移动电源之间的最大间隔为8毫米以内才能进行无线充电。否则将停止充电，需要重调整手机的位置。

FCC符合性声明

本设备符合FCC规则第15部分的规定。操作须遵守以下两个条件：(1) 本设备不得造成有害干扰，(2) 本设备必须接受任何干扰，包括可能导致意外操作的干扰。

警告：未经责任方明确批准的更改或修改可能会使用户丧失操作设备。

注意：本设备已通过测试，符合FCC规则第15部分的A类数字设备的限制。这些限制旨在为住宅安装提供合理的保护。这台有害干扰，本设备产生、使用并辐射射频能量，如果不按照说明进行安装和使用，可能会对无线电通信造成有害干扰。但是，不能保证在特定安装中不会发生干扰。如果该设备确实对无线电或电视接收造成有害干扰（可通过关闭和打开设备来确定），则建议用户尝试通过以下一种或多种措施来纠正干扰：(1) 重新调整或重新放置接收天线。(2) 增加设备与接收器之间的距离。(3) 将设备连接到与接收器所连接的电路不同的电路插座上。(4) 咨询经销商或经验丰富的无线电/电视技术人员寻求帮助。

Omnibar 是 Omnibar LLC 的商标。此用户指南中的所有图片和文字均为 Omnibar 的版权所有。本指南中的图片和插图与实际产品不同。

该装置已经过评估，可满足一般射频暴露要求。该装置可在使携式暴露条件下使用，不受任何限制。

电子废弃物说明

处置或回收本产品和电池可作为家庭垃圾或焚烧处理。当决定处置本产品和电池时，请根据当地环境法规处理电池。以避免爆炸。

警告：禁止拆解、挤压、浮压或接入火中。若出现严重鼓胀，切勿继续使用。切勿浸水或进行维修。请在禁止使用。

仅适用于非热带气候下安全使用
中国制造

重要安全注意事项

这台 iOVERPOWER 电源组不是婴儿、不代表产品的安全。请阅读本说明书。

警告

火灾、爆炸、或人身伤害的危险说明。

权力越大，责任越大！

这台 iOVERPOWER 电源组的使用，请务必遵守以下两个条件：(1) 本设备不得造成有害干扰，(2) 本设备必须接受任何干扰，包括可能导致意外操作的干扰。

- **远离儿童：**请勿让儿童操作或玩弄移动电源。
- **始终保持干燥：**保护移动电源免受雨、雪及和任何形式的液体的侵扰。如果移动电源接触到液体，请勿充电或使用。如果内部组件被浸湿，则必须丢弃移动电源。丢弃前请将其隔离在防火位置。不遵守这些准则可能会导致严重伤害、受伤或更糟的情况。如果您看见任何火花或闻到烧焦味，请联系当地消防部门。
- **无火区：**请吸烟、火花和火焰远离移动电源。
- **避免静电：**请勿将设备暴露在强静电或电磁干扰下。
- **轻拿轻放：**避免掉落或严重撞击，以确保移动电源正常工作。
- **禁止篡改：**请勿尝试打开移动电源外壳。切勿让异物进入输入、输出口。
- **不可更换电池：**请勿尝试更换或改装移动电源电池。
- **仅供专业维修：**只有合格的维修人员才能使用正确的零件维修设备，以确保安全。

技术规格

型号：PBK10KD
容量：10000mAh (3.7V 37Wh)
定额容量:5800mAh (5V⎓2.4A)
USB-C入力：5V⎓3A 9V⎓2A (18W Max)
USB-C出力：5V⎓2.4A 9V⎓2.22A 12V⎓1.67A(20W Max)
無線出力:5W / 7.5W / 10W / 15W
総出力:5V⎓2.4A
素材:防火PC+ABS プラスチック
サイズ:106.6*68.9*20mm
重さ:198g

箱の中

電力銀行 X 1
2ft USB-C to USB-C 充電ケーブル X 1
マニュアル X 1

製品概要

チャージ電力銀行

充電ケーブルを使用して携帯電話やタブレットを充電します



充電器の装置

iPhoneなどのデバイスをワイヤレスで充電する

运用ガイドライン

- **水を避ける：**旅行中は、雨や雪、水を避けて乾いた状態を保つように注意してください。また、直射日光を避けて涼しい場所に置くのがベストです。
- **涼しく保つ：**パワーバンクに余裕を持たせてください。使用中や保管中に、上に物を積み重ねたり、通気口を塞いだりしないでください。
- **充電前に冷却：**完全に放電した後、パワーバンクを1～2時間冷やしてから充電してください。これは電池の寿命を延ばすようなものです！
- **定期的に充電する：**バッテリーを長持ちさせるには、少なくとも3カ月に1回はパワーバンクを使用して充電してください。
- **1つのポートに1つのデバイス：**過負荷をさけてください！パワーバンクのポートまたはソケットに1台のデバイスのみを電源に使用してください。安価で充電が早いデバイスの電源は、オーバーヒートの原因となることがあります。
- **認定アクセサリのみを使用して：**パワーバンクに使用する全ての付属品、アタッチメント、および機器が安全認定されていることを確認してください。
- **プラグを抜く：**切り離すときは、コードではなくプラグを抜いてください。ケーブルを引っ張ってケーブルやパワーバンクが損傷する可能性が低くなります。
- **コードを検査する：**パワーステーションを使用する前にコード、プラグ、ケーブルが損傷していないことを確認してください。
- **損傷がないか確認する：**ひび割れや損傷を見つけた場合は、パワーバンクの使用を直ちに中止してください。漏れた液体に触れないようにしてください。バッテリーの酸は刺激的であり、さらに悪い場合があります。皮膚や目に触れた場合は、水で洗い流し、医師の診断を仰ぎます。
- **損傷したユニットの使用を避ける：**パワーバンクまたは接続されたデバイスが損傷または改造されている場合は、操作しないでください。

操作手順

- **バッテリーの状態を確認するには：**ボタンを短押しして、バッテリーの状態（残量）を確認します。インジケーターは約30秒間点灯し、その後自動的に消灯します。
- **ケーブルを使用して充電する場合：**ケーブルを接続すると、パワーバンクは自動的に出力を開始します。ただし、互換性の問題により、一部の電話では、充電を開始するために電源ボタンを短押しする必要があります。出力モードは1回ボタンを押してから30秒間維持され、その間にデバイスが接続されていない場合は、モードは自動的にシャットダウンします。
- **ワイヤレス充電する場合：**この製品にはワイヤレス充電用の自動ウェイク機能があり、携帯電話を置くだけで自動的に充電を開始します。ただし、一部の電話では、互換性の問題により、ボタンを押してワイヤレス充電機能を有効にする必要があります。短押すと、バッテリーインジケーターが点灯し、ワイヤレス充電がオンになり、デバイスを置くことができます。ワイヤレス充電用の負荷が30秒間接続されていない場合、製品はワイヤレス充電機能を自動的にオフにします。

無線充電のヒント

携帯電話をワイヤレス充電エリア（写真に示すように）に置き、ワイヤレス充電を行います。ワイヤレス充電を機能させるには、携帯電話と電源バンクの間の距離は、ワイヤレス充電が機能するために8mm以内でなければなりません。そうでなければ充電が停止し、携帯電話の位置を調整する必要があります。

FCC适合宣言书

このデバイスは、FCC 規則のパート 15 に準拠しています。操作には、次の 2 つの条件が適用されます：(1) このデバイスは有害な干渉を引き起こしてはなりません。(2) このデバイスは、望ましくない操作を引き起こす可能性のある干渉を含め、受信した干渉をすべて受け入れる必要があります。

警告：承認責任者によって明示的に承認されていない変更または修正を行うと、ユーザーの機器操作権限が無効になる場合があります。

注：この機器は、FCC 規則のパート 15 に従って、クラス B デジタル デバイスの制限に準拠していることがテストで確認されています。これらの制限は、住宅への設置において有害な干渉に対する合理的な保護を提供するように設計されています。この機器は、無線周波数エネルギーを生成、使用、および放射する可能性があり、指示に従って設置および使用しない場合、無線通信に有害な干渉を引き起こす可能性があります。ただし、特定の設置で干渉が発生しないという保証はありません。この機器が実際にラジオまたはテレビの受信に有害な干渉を引き起こしていると判断でき、機器の電源のオンとオフによって確認できます、(2) 受信アンテナの向きを変えるか、場所を移動します。(2) 機器と受信機の間隔を広げます。(3) 受信機が接続されている回路とは別の回路のコンセントに機器を接続します。(4) 販売店または経験豊富なラジオ/テレビ技術者に相談してください。

Omnibar は Omnibar LLC の商標です。このユーザー ガイドの中ですべての画像とテキストの著作権は Omnibar のものです。このガイドの写真やイラストは実際の製品と異なる場合があります。

この装置は、一般的な無線周波数の暴露要件を満たすように評価されています。この装置は、任意の制限を受けずに使用できます。携帯型の暴露条件で使用することができます。

WEEE情報

警告：分解、粉砕、火や高温への曝露はしないでください。著しい膨張が起こった場合は、直ちに使用を中止してください。水に浸した後は絶対に使用しないでください。

非熱帯気候での安全な使用にのみ適しています
中国製

LIST OF TOXIC AND HAZARDOUS SUBSTANCES IN ELECTRONIC PRODUCTS

Part Name	Poisonous Or Harmful Substance Or Element				
	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)
Internal Components	X	O	O	O	O	O
Shell	X	O	O	O	O	O
Other	X	O	O	O	O	O

This form is prepared in accordance with SJ/T 11364

O: Indicates that the content of the hazardous substance in all homogeneous materials of the component is below the limit requirements stipulated in GB/T 26572.

X: Indicates that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit requirements stipulated in GB/T 26572.

For the parts marked "X" in the table, the replacement of hazardous substances cannot be realized due to the limitation of global technological development level.

The product you purchase may not contain all of the above components.

10 The number in this label indicates that the product has an environmental protection service life of 10 years under normal use conditions. Some parts may also have an environmental service life label, and the number in the label shall prevail.

WARRANTY

This device has a 1-year warranty, covering 12 months from the date of purchase (the "warranty period"). During the warranty period, if a device failure occurs under normal use due to a manufacturing defect, Omnibar will repair or replace the device. The company reserves the right to verify that proper use and maintenance guidelines were followed.

CONDITIONS THAT VOID THIS WARRANTY:

1. Unauthorized repair, disassembly, or alteration of any kind.
2. Evidence of abnormal usage or misuse.
3. Damage from dropping, abuse, or negligence.
4. Damages caused by failure to follow the operating instructions.
5. Tampering with the product's original serial number label and other similar markings.
6. Fake products, including those indicated by a missing product serial number or nonconformity between the product model and serial number.
7. Improper storage, such as long-term exposure to humidity or temperatures outside the parameters specified in the technical specifications of this user's guide.
8. Expiration of the product warranty.

FORCE MAJEURE: Omnibar shall not be liable for any failure or delay in performing any of its obligations under this warranty if such failure or delay is caused by or results from events beyond its reasonable control, including, but not limited to:

A. Natural disasters (e.g., earthquakes, floods, hurricanes, wildfires)
B. Acts of God
C. War, invasion, or acts of terrorism
D. Civil unrest, riots, or strikes
E. Government actions, regulations, or restrictions
F. Pandemics, epidemics, or quarantines
G. Power outages or electrical failures
H. Supply chain disruptions

Dear user, this warranty card is your future warranty application voucher, please cooperate with the seller to fill in and properly keep it for later!

Your Information			
User name		E-mail	
Contact Number		Zip code	
Address of correspondence			
Product Information			
Product name		Model number	
Product barcode/number/batch number			
Seller Information			
Name			
Address			
Contact Number		Zip code	
Date of sale		Invoice number	
Remarks			

The above information shall be filled in by the buyer

+1(208)252-5229　www.omnibar.com

OMNIBAR

9900 ALLSHIRE AVE,STE 100
SANDPOINT, 99999003, 208-888-99
(208) 252-5229

OMNIBAR.COM