说明书尺寸：70*90MM

PANTONE 2297C　PANTONE Black 3C

OMNIBAR

5000mAh

MAGFAST POWER BANK USER GUIDE

2向磁吸快充移动电源操作指南

マグネットポルタブックチャージパワーバンクユーザーガイド

MBMW

IMPORTANT SAFETY INSTRUCTIONS

Before using this power bank, thoroughly read all warnings and instructions. To avoid risks like explosions, fires, electric shocks, or personal injury, adhere strictly to these guidelines and those from the manufacturers of any equipment you use with the power bank. Omnibar may update this information without prior notice. For the latest updates and the most recent User Manual, visit www.omnibar.com.

WARNINGS

INSTRUCTIONS PERTAINING TO RISK OF FIRE, ELECTRIC SHOCK, OR PERSONAL INJURY.

With great power comes great responsibility!

When using this power bank, basic safety precautions should always be followed. Please read all the instructions before using the product.

- **KEEP AWAY FROM CHILDREN:** Don't allow children to operate or play with the power bank.
- **ALWAYS KEEP DRY:** Protect the power bank from rain, snow, and any form of liquid. Do not charge or use the power bank if it's exposed to liquid. If internal components get wet, your power stalker MUST be disposed of. Isolate it in a fire safe location before disposal. Failure to comply with these guidelines could cause serious damage, injury, or worse. Contact your local fire department if you see any sparks or smell burning.
- **FLAME-FREE ZONE:** Avoid smoking, sparks, and flames away from the power bank.
- **AVOID STATIC:** Do not expose the device to strong electrostatic or electromagnetic interference.
- **HANDLE GENTLY:** Avoid dropping or severe impacts to ensure the power bank works properly.
- **NO TAMPERING:** Do not attempt to open the power bank casing. Never allow foreign objects to enter ventilation holes, outputs or ventilation holes.
- **NO BATTERY REPLACEMENT:** Do not try to replace or alter the power bank battery. It is rechargeable but not replaceable.
- **PROFESSIONAL SERVICING ONLY:** Only a qualified repair person should service the device using the correct parts to ensure continued safety.

TECHNICAL SPECIFICATIONS

MODEL: YB6040
CAPACITY: 5000mAh (3.7V 18.5Wh)
RATED CAPACITY: 2500mAh (5V⎓2.4A)
USB-C INPUT: 5V⎓3A 9V⎓2A (18W Max)
USB-C OUTPUT: 5V⎓2.4A 9V⎓2.22A 12V⎓1.67A (20W Max)
WIRELESS OUTPUT: 5W / 7.5W / 10W / 15W
TOTAL OUTPUT: 5V⎓3.4A
MATERIALS: Fireproof PC+ABS Plastic
SIZE: 95*58.9*13.3mm
WEIGHT: 131g

IN THE BOX

Power Bank X 1
2ft USB-C to USB-C Charging Cable X 1
Instruction Manual X 1

PRODUCT OVERVIEW

Recharging Power Bank



Charging Your Phone or Tablet Using Charging Cables

Charging Other Devices

Charging an iPhone and Other Devices Wirelessly

OPERATING GUIDELINES

- **AVOID WATER:** When traveling, take care to keep it dry; avoid rain, snow and any water. It's also best to keep it cool and shaded from direct sunlight.
- **KEEP IT COOL:** Give your power bank some breathing room. Don't stack things on it or block its ventilation while in use or in storage.
- **COOL DOWN BEFORE CHARGING:** After a full discharge, let your power bank chill for 1-2 hours before recharging. It's like letting it take a nap and prolongs the life of your battery!
- **RECHARGE REGULARLY:** To preserve the battery, use and recharge the power bank at least once every 3 months.
- **ONE PORT, ONE DEVICE:** Don't overload it! Only power one device per port or socket on the power bank. Never connect a multi-outlet power strip, surge protector or extension cord.
- **USE CERTIFIED ACCESSORIES ONLY:** Ensure all accessories, attachments and appliances used with the power bank are safety certified to avoid potential hazards.
- **PULL THE PLUG:** When disconnecting, pull the plug not the cord. It's less likely to break into an accidental tug-of-war, damaging your cables or power bank.
- **INSPECT CORDS:** Ensure that cords, plugs, and cables are not damaged before using with the power bank.
- **CHECK FOR DAMAGE:** If you spot any cracks or damage, stop using the power bank immediately. Avoid contact with any leaked liquid. The battery acid can be irritating or worse. If it touches skin or eyes, flush with water and seek medical attention.
- **AVOID USING DAMAGED UNITS:** Do not operate the power bank or any connected devices if they are damaged or altered.

OPERATION INSTRUCTIONS

- **To check battery status:** Press the button once to check the battery status (remaining power). The indicator will light up about 30s before it automatically turns off.
- **When charging using a cable:** The power bank will automatically starts to output when you connect a charging cable to it. However, due to compatibility issues, some phones you need to press the power button once to start charging. The output mode will stay for 30s after you press the button, during which if there's no new connected device, the mode will automatically shut down.
- **When charging wirelessly:** This product has an auto-wake function for wireless charging, just place your phone onto it, and it will automatically start charging. But for some phones, due to compatibility issues, the wireless charging function needs to be activated by pressing the button. Press it once, the battery indicator will light up and the wireless charging is turned on, and you can place your device on. If there's no load connected for the wireless charging in 30s, the product will automatically shut off the wireless charging function.

WIRELESS CHARGING TIPS

Place your phone onto the wireless charging area (as it shows in the picture) for wireless charging. The distance between the charging phone and the power bank must be within 8mm for wireless charging to work. If not it will stop charging, and you need to adjust the phone's position.

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: (1) Reorient or relocate the receiving antenna. (2) Increase the separation between the equipment and receiver. (3) Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. (4) Consult the dealer or an experienced radio/TV technician for help.

Omnibar is a trademark of Omnibar LLC. All the images and text in this user guide are the copyright of Omnibar. The photos and illustrations in this guide may differ from the actual product.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

WEEE INFORMATION

Disposal and recycling information This product and battery should not be used as household garbage or thrown into the fire. When you decide to dispose of the product and battery, please handle the battery according to the local environment all laws to avoid explosion.

WARNING: Do not disassemble, crush, or expose to fire or high temperatures. If significant swelling occurs, discontinue use immediately. Never use after submersion in water.

Only suitable for safe use in non-tropical climates.
Made in China

重要安全说明

使用此移动电源之前，请仔细阅读所有警告和说明。为避免爆炸、火灾、触电或人身伤害等风险，请严格遵守这些准则以及您与移动电源一起使用的任何设备制造商的准则。Omnibar 可能会在不事先通知的情况下更新此信息。如需最新更新和最新的用户手册，请访问 www.omnibar.com。

警告

有关火灾、触电或人身伤害风险的说明。

能力越大，责任越大！

使用此移动电源时，应始终遵循基本的安全预防措施。使用产品前，请阅读所有说明：

- **请远离儿童：**请勿让儿童操作或使用移动电源。
- **始终保持干燥：**保护移动电源免受雨水、雪水和任何形式的液体的侵扰。如果移动电源接触到液体，请勿充电或使用。如果内部组件被浸泡，您的充电宝将必须报废。报废前请将其隔离在防火位置。不遵守这些准则可能会导致严重损坏、受伤或更糟的情况。如果您看到任何火花或闻到烧焦味，请联系当地消防部门。
- **无火区：**请将烟雾、火花和火焰远离移动电源。
- **避免静电：**请勿将设备暴露在强静电或电磁干扰下。
- **轻拿轻放：**请勿掉落或严重撞击，以确保移动电源正常工作。
- **禁止篡改：**请勿尝试打开移动电源外壳。切勿让异物进入输入、输出口。
- **不可更换电池：**请勿尝试更换或改装移动电源电池。
- **仅限专业维修：**只有合格的维修人员才能使用正确的零件维修设备，以确保安全。

技术规格

型号：YB6040
电池容量：聚合物锂电池
额定容量：2*10%
容量：5000mAh (3.7V 18.5Wh)
额定容量：2500mAh (5V⎓2.4A)
USB-C输入：5V⎓3A 9V⎓2A (18W Max)
USB-C输出：5V⎓2.4A 9V⎓2.22A 12V⎓1.67A (20W Max)
无线输出：5W / 7.5W / 10W / 15W
总输出：5V⎓3.4A
材料：防火PC+ABS塑料
尺寸：95*58.9*13.3mm
重量：131g
执行标准：GB 4943.1-2022;GB 31241-2022
制造商：深圳市凯斐琪科技有限公司

包装内容

移动电源 X 1
2英尺双向USB-C充电线 X 1
使用说明书 X 1

产品概述

使用充电线为手机或平板电脑充电

为其他设备充电

为iPhone和其他设备无线充电

操作指南

- **初始电池状态：**按一下按钮检查电池状态（剩余电量）。指示灯将约30秒后自动熄灭。
- **有线充电时：**连接充电线后，移动电源会自动开始输出。但由于兼容性问题，部分手机需要按一下电源键才能开始充电。按一下按钮后输出模式会持续30秒，期间若无任何设备连接，则自动关闭。
- **无线充电时：**本产品具有无线充电自动唤醒功能，将手机放置于其上，即可自动开始充电。但由于兼容性问题，部分手机需要按一下按钮才能开启无线充电功能。按一下按钮，电池指示灯亮起，开启无线充电。即可放置设备。若30秒内无任何负载连接进行无线充电，则该产品将自动关闭无线充电功能。

操作说明

- **检查电池状态：**按一下按钮检查电池状态（剩余电量）。指示灯将约30秒后自动熄灭。
- **有线充电时：**连接充电线后，移动电源会自动开始输出。但由于兼容性问题，部分手机需要按一下电源键才能开始充电。按一下按钮后输出模式会持续30秒，期间若无任何设备连接，则自动关闭。
- **无线充电时：**本产品具有无线充电自动唤醒功能，将手机放置于其上，即可自动开始充电。但由于兼容性问题，部分手机需要按一下按钮才能开启无线充电功能。按一下按钮，电池指示灯亮起，开启无线充电。即可放置设备。若30秒内无任何负载连接进行无线充电，则该产品将自动关闭无线充电功能。

无线充电技巧

将手机放置在无线充电区域（如图所示）即可进行无线充电。充电手机与移动电源之间的最大间距不得超过8毫米以方才能进行无线充电。否则将止充电，您需调整手机的位置。

FCC符合性声明

本设备符合 FCC 规则第 15 部分的规定。操作应遵守以下两个条件：(1) 本设备不得造成有害干扰，(2) 本设备必须接受任何收到的干扰，包括可能导致意外操作的干扰。

警告：未经合规方负责方明确批准的更改或修改可能会使用户无权操作该设备。
注意：本设备已通过测试，符合 FCC 规则第 15 部分对 B 类数字设备的限制。这些限制旨在为住宅安装提供合理的保护，防止有害干扰。本设备会产生、使用并辐射射频能量，如果不按照说明进行安装和使用，可能会对无线电通信造成有害干扰。但是，不能保证在特定安装中不会发生干扰。如果该设备确实对无线电或电视接收造成有害干扰（可通过关闭和打开设备来确定），则建议用户尝试通过以下一种或多种措施来纠正干扰：(1) 重新调整或重新放置接收天线。(2) 增加设备与接收器之间的距离。(3) 将该设备连接到与接收器所连接电路不同的电路插座上。(4) 咨询经销商或经验丰富的无线电/电视技术人员寻求帮助。

Omnibar 是 Omnibar LLC 的商标。本用户指南中的所有图片和文字均为 Omnibar 的版权所有。本指南中的照片和插图可能与实际产品不同。

该装置已经证评估，可满足一般射频暴露要求。本装置可在便携式暴露条件下使用，不受任何限制。

电子废弃物说明

处置或回收本产品电池不应作为家庭垃圾或切达式小。为正决定处置本产品电池时，请根据当地环境法规处理电池，以避免爆炸。

警告：禁止拆解、碾压、挤压或投入火中。若出现严重鼓胀，切勿继续使用。切勿置于高温环境中，避免后禁止使用。

仅适用于非热带气候下安全使用
中国制造

Lvsin-00

重要及安全注意事项

此Pbpowerpc多使用方法的，请仔细阅读所有警告和指示。为了避免爆炸、火灾、触电、人身伤害等风险，请严格遵守这些准则以及您与移动电源一起使用的任何设备制造商的准则。Omnibar 可能会在不事先通知的情况下更新此信息。如需最新更新和最新的用户手册，请访问 www.omnibar.com。

警告

火灾、感电、或人身伤害的危险说明。

强力电源，责任重大！

使用此移动电源时，应始终遵循基本的安全预防措施。请阅读所有说明。

- **远离儿童：**请勿让儿童操作或使用移动电源。
- **始终保持干燥：**保护移动电源免受雨水、雪水和任何形式的液体的侵扰。如果移动电源接触到液体，请勿充电或使用。如果内部组件被浸泡，您的充电宝将必须报废。报废前请将其隔离在防火位置。不遵守这些准则可能会导致严重损坏、受伤或更糟的情况。如果您看到任何火花或闻到烧焦味，请联系当地消防部门。
- **无火区：**请将烟雾、火花和火焰远离移动电源。
- **避免静电：**请勿将设备暴露在强静电或电磁干扰下。
- **轻拿轻放：**请勿掉落或严重撞击，以确保移动电源正常工作。
- **禁止篡改：**请勿尝试打开移动电源外壳。切勿让异物进入输入、输出口。
- **不可更换电池：**请勿尝试更换或改装移动电源电池。
- **仅限专业维修：**只有合格的维修人员才能使用正确的零件维修设备，以确保安全。

技术规格

型号：PBK5KB
电池容量：聚合物锂电池
额定容量：2*10%
容量：5000mAh (3.7V 18.5Wh)
额定容量：2500mAh (5V⎓2.4A)
USB-C输入：5V⎓3A 9V⎓2A (18W Max)
USB-C输出：5V⎓2.4A 9V⎓2.22A 12V⎓1.67A (20W Max)
无线输出：5W / 7.5W / 10W / 15W
总输出：5V⎓3.4A
材料：防火PC+ABS塑料
尺寸：95*58.9*13.3mm
重量：131g
执行标准：GB 4943.1-2022;GB 31241-2022
制造商：深圳市凯斐琪科技有限公司

箱の中

電力提行 X 1
2ft USB-C to USB-C 充電ケーブル X 1
マニュアル X 1

製品概要

チャージ電力銀行

充電ケーブルを使用して携帯電話やタブレットを充電します

充電器の装置

iPhoneなどのデバイスをワイヤレスで充電する

運用ガイドライン

- **水を避ける：**旅行中は、雨や雪、水を避けて動いた状態を保つように注意してください。また、直射日光を避けて涼しい場所に置くのがベストです。
- **涼しく保つ：**パワーバンクに余裕を持たせてください。使用中や保管中に、上に物を積み重ねたり、通気口をふさいだりしないでください。
- **充電前に冷やす：**完全に放電した後、パワーバンクを 1～2 時間冷やしてから充電してください。お風呂で冷えるのと同じで、パワーバンクの寿命が延びます！
- **定期的に充電する：**バッテリーを長持ちさせるには、少なくとも 3 か月に 1 回はパワーバンクを使用して充電してください。
- **1 つのポートに 1 つのデバイス：**過負荷をおかけなくてください！パワーバンクのポートまたはソケットごとに 1 つのデバイスのみに電源を供給してください。マルチコンセントの電源タップ、サージプロテクター、延長コードを接続しないでください！
- **認定アクセサリのみを使用してください：**安全のため、パワーバンクで使用するすべてのアクセサリ、アタッチメント、および機器が安全認定されていることを確認してください。
- **プラグを抜く：**取り外すときは、コードではなくプラグを抜いてください。そうすることで、誤って引っ張ってケーブルやパワーバンクが損傷する可能性が低くなります。
- **コードを検査する：**パワーステーションで使用する前に、コード、プラグ、ケーブルの損傷していないことを確認してください。
- **損傷がないか確認する：**ひび割れや損傷を見つけた場合は、パワーバンクの使用を直ちに中止してください。漏れた液体に触れないようにしてください。バッテリーの酸は刺激性があり、さらに悪い場合があります。皮膚や目に触れた場合は、水で洗い流し、医師の診断を受けてください。
- **損傷したユニットの使用を避ける：**パワーバンクまたは接続されたデバイスが損傷または改造されている場合は、操作しないでください。

操作手順

- **バッテリーの状態を確認するには：**ボタンを短押しして、バッテリーの状態（残量）を確認します。インジケーターは約30秒後に消えます。
- **ケーブルを使用して充電する場合：**充電ケーブルを接続すると、パワーバンクは自動的に出力を開始します。ただし、互換性の問題により、一部の電話では、充電を開始するために電源ボタンを短押すず必要があります。出力モードはボタンを押してから30秒間続きます。その間にデバイスが接続されていない場合、モードは自動的にシャットダウンします。
- **ワイヤレス充電する場合：**この製品にはワイヤレス充電用の自動ウェイク機能がありますが、携帯電話を置くだけで自動的に充電を開始します。ただし、一部の電話では、互換性の問題により、ボタンを押してワイヤレス充電機能を有効にする必要があります。短押すと、バッテリーインジケーターがともり、ワイヤレス充電がオンになり、デバイスを置くことができます。ワイヤレス充電用の負荷が30秒間接続されていない場合、製品はワイヤレス充電機能を自動的にオフにします。

無線充電のヒント

携帯電話をワイヤレス充電エリアに置いてください（写真に示すように）。ワイヤレス充電を行います。ワイヤレス充電を行うためには、携帯電話と電源バンクの間の距離は8ミリメートル以内でなければなりません。そうでなければ充電が停止し、携帯電話の位置を調整する必要があります。

FCC適合宣言です

このデバイスは、FCC 規則のパート 15 に準拠しています。操作には、次の 2 つの条件が適用されます：(1) このデバイスは有害な干渉を引き起こしてはなりません。(2) このデバイスは、望ましくない操作を引き起こす可能性のある干渉を含め、受信した干渉を受け入れられる必要があります。

警告：承認責任者によって明示的に承認されていない変更または修正を行うと、ユーザーの機器操作権限が無効になる場合があります。
注：この機器は、FCC 規則のパート 15 に従って、クラスBデジタル デバイスの制限に準拠していることがテストで確認されています。これらの制限は、住宅への設置において有害な干渉に対する適切な保護を提供するように設計されています。この機器は、無線周波数エネルギーを生成、使用、および放射する可能性があり、指示に従って設置および使用されない、無線通信に有害な干渉を引き起こす可能性があります。ただし、特定の設置で干渉が発生しないという保証はありません。この機器がラジオやテレビの受信に有害な干渉を引き起こしていると判断した場合（機器の電源のオンとオフによって確認できます）、ユーザーは次の 1 つ以上の対策を実行して干渉を修正することをお勧めします。(1) 受信アンテナの向きを変えるか、場所を変えます。(2) 機器と受信機の間の距離を増やします。(3) 受信機が接続されている回路とは別の回路のコンセントに機器を接続します。(4) 販売店または経験豊富なラジオ/テレビ技術者に相談してください。

Omnibar は Omnibar LLC の商標です。このユーザー ガイドのすべての画像とテキストの著作権は Omnibar が所有します。このガイドの写真やイラストは実際の製品と異なる場合があります。

この装置は、一般的な無線周波数の露出要件を満たすように評価されています。この装置は、任意の制限を受けることなく、携帯型の露出条件で使用することができます。

WEEE情報

廃棄およびリサイクルに関する情報 この製品およびバッテリーは、家庭ごみとして使用したり、火の中に投げ込んだりしないでください。製品およびバッテリーを廃棄する場合は、爆発を防ぐために、地域の環境法に従ってバッテリーを取り扱ってください。

警告：分解、粉砕、または高温への曝露はしないでください。重い膨張が起こった場合は、直ちに使用を中止してください。水に浸した後は絶対に使用しないでください。

非熱帯気候での安全な使用にのみ適しています
中国製

LIST OF TOXIC AND HAZARDOUS SUBSTANCES IN ELECTRONIC PRODUCTS

Part Name	Poisonous Or Harmful Substance Or Element				
	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB)	(PBDE)
Internal Components	X	O	O	O	O	O
Shell	X	O	O	O	O	O
Other	X	O	O	O	O	O

This form is prepared in accordance with SJ/T 11364-
O: Indicates that the content of the hazardous substance in all homogeneous materials of the component is below the limit requirements stipulated in GB/T 26572.
X: Indicates that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit requirements stipulated in GB/T 26572.
For the parts marked "X" in the table, the replacement of hazardous substances cannot be realized due to the limitation of global technological development level.
The product you purchase may not contain all of the above components.

10 The number in this label indicates that the product has an environmental protection service life of 10 years under normal use condition. Some parts may also have an environmental service life label, and the number in the label shall prevail.

高原使用
"GAO YUAN SHI YONG"

WARRANTY

This device has a 1-year warranty, covering 12 months from the date of purchase (the "warranty period"). During the warranty period, if a device failure occurs under normal use due to a manufacturing defect, Omnibar will repair or replace the device. The company reserves the right to verify that proper use and maintenance guidelines were followed.

CONDITIONS THAT VOID THIS WARRANTY:

1. Unauthorized repair, disassembly, or alteration of any kind.
2. Evidence of abnormal usage or misuse.
3. Damage from dropping, abuse, or negligence.
4. Damages caused by failure to follow the operating instructions.
5. Tampering with the product's original serial number label and other similar markings.
6. Fake products, including those indicated by a missing product serial number or nonconformity between the product model and serial number.
7. Improper storage, such as long-term exposure to humidity or temperatures outside the parameters specified in the technical specifications of this user's guide.
8. Expiration of the product warranty.

FORCE MAJEURE: Omnibar shall not be liable for any failure or delay in performing any of its obligations under this warranty if such failure or delay is caused by or results from events beyond its reasonable control, including, but not limited to:

A. Natural disasters(e.g., earthquakes, floods, hurricanes, wildfires)
B. Acts of God
C. War, invasion, or acts of terrorism
D. Civil unrest, riots, or strikes
E. Government actions, regulations, or restrictions
F. Epidemics, pandemics, or quarantines
G. Power outages or electrical failures
H. Supply chain disruptions.

Dear user, this warranty card is your future warranty application voucher, please cooperate with the seller to fill in and properly Keep it for later!

User information			
User name		E-mail	
Contact Number		Zip code	
Address of correspondence			
Product information			
Product name		Model number	
Product barcode/number/batch number			
Sale information			
Name			
Address			
Contact Number		Zip code	
Date of sale		Invoice number	
Remarks			

The above information shall be filled in by the buyer

+1(208)252-5229　www.omnibar.com

OMNIBAR

2520 E AVONDALE AVENUE, STE 102
SUITE A, IDAHO SPRINGS, CA 95670
(208) 252-5229

OMNIBAR.COM