TOUCH+

StarTab 715

User Guide

StarTab 715

User Guide

Contents

English

01 Foreword 10

1.1 Acknowledgements 10
1.2 Announcements 10
1.3 Safety Tips 11
1.4 Acronym/terms 12

02 Brief Description of MID Series of Products 13

2.1 MID Overall Drawing 13
2.2 MID Accessories Introduction 15
2.3 MID Use and preparation 15
2.4 MID State and information 16

03 Quick start 18

3.1 Button function 18
3.2 Boot and shut down 19
3.3 Screen of opening and closing 20
3.4 The use of touch screen 21
3.5 Page interface 21
3.6 Status bar describe 24

3.7 Use touch panel 24
3.8 Equipment basic settings 25
3.8.1 Silent mode, volume, notification, ringtone, audible selection, screen lock sounds 27
3.8.2 Application 28
3.8.3 Privacy 29
3.8.4 Storage 30
3.8.5 Language & Keyboard 31
3.8.6 Date & time setting 32
3.8.7 USB Mode Select 32
3.9 APPS install and uninstall 33
3.9.1 APPS install 33
3.9.2 APPS uninstall 34

04 Establish connections 34
4.1 USB connection 34
4.1.1 Copy files to memory cards. 36
4.1.2 Content of MID Storage Device 36
4.1.3 Storage card 36
4.1.4 Input text 37
4.2 WIFI connection 38
4.3 3G connection 40

05 Communication 40
5.1 E-MAIL 40

06 Multimedia 43
6.1 Support the file format 43
6.2 Music 43
6.3 Camera 46
6.4 Gallery 47

07 Internet 50
7.1 Browser 50

08 Other applications 52
8.1 Alarm clock 52
8.2 Calculator 53
8.3 Explorer 54

09 Troubleshooting 55

Annex 1 Specifications 57

01 Foreword

1.1 Acknowledgements

Thank you for choosing our products. Product MID (Mobile Internet Device) is a kind of mobile Internet equipment, delicate and cabinet, easy to carry. Equipped with a high resolution 800x480 capacitive 5- touch screen, this MID supports high-definition videos and images, installation of multiple Office Micro Software, entertainment and other applications.

The dazzle cruel interface can provide you new user experience.

This manual introduces the various functions, using skills and announcements.

Please read the manual carefully before using MID.

1.2 Announcements

Maintenances

- Please keep MID dry. Keep the equipment and battery charger away from water, vapor and wet hand in case of short circuit, corrosion or equipment failure.
- Keep the equipment, battery and charger away from strongly impact or vibration in case of equipment/battery/charger fault, fire or explosion.
- Keep the equipment, battery and charger away from very high/low temperature region in case of equipment/battery/charger