RECHARGEABLE 2.4GHz - DX-2 STUNT DRONE

14+

Getting to Know Your Drone

PLEASE READ ALL WARNINGS AND INSTRUCTIONS PRIOR TO USE. KEEP THIS DOCUMENT AS IT CONTAINS IMPORTANT INFORMATION ABOUT YOUR DRONE.

1. PREPARE FOR FLIGHT
- Drone must be charged before each use (Cable included)
- Indicator light will turn off once fully charged
- Install batteries in remote

2. PAIR YOUR DRONE
Before each flight pair the remote with the drone.
1. Turn your drone on and place on a flat, level surface
2. Turn on the remote on and move the left joystick down, then up, then down again
3. The beep will indicate successful pairing

3. DIRECTIONAL LIGHTS
1. Turn your drone on and place on a flat, level surface
2. Turn on the remote on and move the left joystick down, then up, then down again
3. The beep will indicate successful pairing

4. REMOTE CONTROL OVERVIEW
Practice flying your drone below 10 feet and at low speeds until comfortable with all controls to avoid unnecessary damage or injury
- Left joystick:
  - Forward/Backwards controls elevation
  - Left/Right controls spin
- Right joystick: controls flight direction
- Direction trim: use to eliminate drift

To cut power to drone, move left joystick to down position

QUESTIONS OR CONCERNS?
PLEASE GIVE US A CALL... WE'RE HERE TO HELP

CUSTOMER SERVICE
(800) 374-2744
Before calling please locate the 10-digit code printed on the back of your remote

ADULT ASSEMBLY, CHARGING, AND BATTERY INSTALLATION IS REQUIRED. ADULT SUPERVISION IS REQUIRED.

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years.

Product specifications and features may be changed without notice. Hexbug®, Hexbug® Nano®, Hexbug® Micro®, Hexbug® Nanobot®, Hexbug® Spin Master®, Hexbug® Spin Control®, Hexbug® Spin Stunt®, Hexbug® Spin Chaser®, Hexbug® Spin Racer®, Hexbug® Spin Combat