75

80

Skullcandy

HESH 540 ANC

USER GUIDE

SCAN TO GET STARTED

SCANNEZ POUR COMMENCER

Power - On
Off Mode
(Main Button)

00:01

Power • On • On • Encendido • Accensione • Ligar • Еін • Aan • • Taran • Virta Päälle • Strom Av • Strøm Av • Włączony • Güç Açık • 打開 • 打开 • 電源 - On • 전원 켜기 • تشغيل

Power - Off
On Mode
(Main Button)

00:03

Power • Off • Off • Apagado • Spegnimento • Desligar • Aus • Uitzetting • Slår For Strøm • Pois • Pois • Wyłączony • Tamawa • Güç Kapalı • 關閉電源 • 关闭电源 • 電源 - Off • 전기 • إيقاف

Pairing Mode
Off Mode
(Main Button)

00:03

Pairing Mode • Mode Couplage • Modo De Vinculación • Modalità Di Accoppiamento • Modo Emparejamiento • Koppelmodus • Parmodus • Pardannelsesvilkland • Lahtiparin • Modus Sparowania • Sammenkoblingsmodus • Parningsläge • Eşleme Modu • Спряжение • Eşleştirme Modu • 配對模式 • 配对模式 • ペアリング・モード • 페어링 모드 • وضع الاقتران

Pairing Mode
On Mode
(Main Button)

00:03

Pairing Mode • Mode Couplage • Modo De Vinculación • Modalità Di Accoppiamento • Modo Emparejamiento • Koppelmodus • Parmodus • Pardannelsesvilkland • Lahtiparin • Modus Sparowania • Sammenkoblingsmodus • Parningsläge • Eşleme Modu • Спряжение • Eşleştirme Modu • 配對模式 • 配对模式 • ペアリング・モード • 페어링 모드 • وضع الاقتران

Pair New Device
Voice Prompt - "Ready to Pair"
Available Device - "HESH 540 ANC"

1x

LED Pulses Blue

Pair New Device • Coupler Nouvel Appareil • Vincular Nuevo • Dispositivo • Accopia Nuovo Dispositivo • Emparejar Nuevo Dispositivo • Mit neuem Gerät koppeln • Nauw Apparat Paren • Parotan Sy Enhed • Muodosta Uusi Laitepari • Sammenkoble • Lahtiparin • Modus Sparowania • Sammenkoblingsmodus • Parningsläge • Yeni Cihazı Eşleştir • Спряжение • Eşleştirme Modu • 配對模式 • 配对模式 • ペアリング・モード • 페어링 모드 • وضع الاقتران

Play / Pause - Answer Call
(Joystick)

1x

Play/Pause•Answer • Lecture/Pause•Répondre • Reproducir/pausar•Responder • Riproduci/pausa•Risponda • Reproducir/colocar •En Pausa • Antwort • Afspil • Spil/pause•Svare • Pelaa/Tauko•Vastaa • Spille/Pause•Svar • Odtwarzanie/Pauza•Odpowiedz • Afspille/pause•Svar • Spela/Pausa•Svar • Çalma/Duraklat • Svar • Play/Pause•Svaret • Oynat/Duraklat • 播放/暫停•接聽 • 播放/暫停•接听 • 再生／一時停止•応答 • 재생/일시 정지•전화 받기 • تشغيل/إيقاف مؤقت•الرد

Next Track
(Joystick)
Press Right

1x

Track Forward • Piste Suivante • Adelantar • Brano successivo • Faixa Seguinte • Nächster Titel • Volgend Nummer • Skift Til Næste Musiknummer • Kappe seuraan • Neste Spor • Nästa Ljudspår • Następowanie • Tamawa • Ileri • Track • 下一曲目 • 下一曲目 • 次のトラックを再生する • 다음 트랙으로 • التقدم للأمام

Previous Track
(Joystick)
Press Left

1x

Track Back • Piste Précédente • Retroceder • Brano Precedente • Faixa Anterior • Vorangehender Titel • Vorig Nummer • Musiknummer Tilbage • Kappe taaksepäin • Forrige Spor • Byta Till Föregående Spår • Poprzedzanie • Ta • Tipsi • Track • 上一曲目 • 上一曲目 • 前のトラックを再生する • 이전 트랙으로 • التقدم للخلف

Volume Up
(Joystick)
Press Up

1x

Volume Up • monter le son • subir el volumen • alza il volume • aumentar o volume • lauter • volume omhoog • Øgledyde op • lämi kovemmalle • volum opp • Hög volymen • увеличить громкость • 增高音量 • 增加音量/广播 • 音量 +• 볼륨 높이기 • رفع الصوت

Volume Down
(Joystick)
Press Down

2x

Volume Down • baisser le volume • bajar volumen • volume basso • volume baixo • Lautstärke runter • volume verminderen • skrue ned for lyden • Äänenvoimakkuus alemmaksi • volum ned • Sänk volymen • skrue ned for lyden • 音量減少 • 音量减少/广播 • 音量 - • 볼륨 낮추기 • خفض الصوت

Reject / End Call
(Joystick)
Call Mode

1x

Reject/End Call • Rechter/Terminer Espoir • Rechazar / Finalizar Llamada • Respingere/terminare chiamata • Rifiuta/Termina chiamata • Avsluta / Avslå • Gespreek Weigeren/beëindigen • Afvuit uitschakelen/beëindigen • Avsluta/avslå samtale • Avslutte/avslutte • Odrzucenie/Koniec • Avsluta/Avvisa • Reddetmek • Avslutt/Avslutt samtale • 結束/拒絕 • 结束/拒绝 • 通話を拒否する • 수신 거부/끊기 • إنهاء/رفض المكالمة

Stay-Aware - On/Off - Activate ANC
Main Button

2x

Stay Aware On/Off • Restez informé marche/arrêt • Manténgase alerta activado/desactivado • Rimani consapevole attivo/disattivato • Fique alerto ligado/desligado • Aufmerksam bleiben ein/aus • Vågend Nummer • Skift Til Nåde • Valpuolisen • Nåde • Nåde • Nästa Ljudspår • Tryb Czuwania • Dikkat • Stay • 保持警醒 • 保持警醒开/关 • 次のトラックを再生する • 다음 트랙으로 • وضع الانتباه

Spotify Tap™
(Joystick)
Spotify App Required

00:01

Plug in to Charge

1) LED Pulsing Amber - 0-41%
2) LED Pulsing White - 41 - 90%
3) LED Solid White - 91-100%

Plug in USB-C to Charge • Branchez USB-C pour charger • Enchufe USB-C para cargar • Collega USB-C per caricare • Conecte o USB-C para carregar • Sortlades Sie USB-C zum Aufladen an • Sluit USB-C aan om op te laden • Tilkalt USB-C for at oplade • Liitä USB-C ladataksesi • Koble til USB-C for å lade • Anslut USB-C för att ladda • Подключите USB-C для зарядки • Şarj etmek için USB-C'yi takın • 插入 USB-C 充电 • 插入USB-C充电进行 • 연결하여 충전 • توصيل USB-C للشحن

Activate Assistant
(Joystick)

2x

Activate Voice Assistant • Activer l'Assistant Vocal • Activar el Asistente de Voz • Attivare Assistente Vocale • Aktiver Assistente Ser Ut • Sprachassistenten Aktivieren • Stemmigt Activeren • Aktivoi Tekstinä • Aktivere talemotjen • Aktiver Talassistent • Aktivera Röstassistent • Активировать голосовой помощник • Sesli asistanı etkinleştir • 激活語音助理 • 语音助手激活 • 활성화하기 • تفعيل المساعد

Reset / Clear Paired Device List
(Joystick)
On Mode
Bluetooth Connected or Disconnected

00:06

Reset Device • Réinitialiser l'Appareil • Reiniciar el Dispositivo • Ripristina Dispositivo • Reinicie o Dispositivo • Kopplung zurücksetzen • Reset het Apparaat • Nulstil Enhed • Nollaa Laite • Nullstill Enhet • Återställ Enhet • Cihaz sıfırlama • Eşleştirilmiş Aygıt Listesini Sileb • 重置设备 • 重置设备 • デバイスをリセット • 기기 재설정 • إعادة ضبط الجهاز

HESH 540 ANC
MODEL: SBH540
FCC ID: 2ABCB-SBH540
IC: 10466A-SBH540

R-C-Sku-SBH540

UK CA CE

NOM

EN Made in Vietnam.
FR Fabriqué au Vietnam.
ES Hecho en Vietnam.
ZH 越南制造。
AR صنع في فيتنام.

EN Contains Lion battery. Battery must be recycled or disposed of properly.
FR Contient une batterie Lion.La batterie doit être recyclée ou mise à correctement.
ES Contiene una batería Lion. La batería debe ser recicilada o desechada adecuadamente.
AR يحتوي على بطارية ليون. يجب تدوير البطارية أو التخلص منها بشكل صحيح.

EN Skullcandy and other marks are registered trademarks of Skullcandy, Inc. All rights reserved. FR Skullcandy et les autres marques sont des marques déposées de Skullcandy, Inc.Tous droits réservés. ES Skullcandy y los demás marcas son marcas registradas de Skullcandy, Inc.Todos los derechos reservados.

Users can open the ear cushion themselves to view the compliance marking information.

EN Maximum operating temperature 40°C.
FR Température maximale de fonctionnement 40°C.
ES Temperatura máxima de funcionamiento 40°C.
AR الحد الأقصى لدرجة حرارة التشغيل 40°C.
ZH 最高工作温度 40°C。

75

80

FCC Compliance Statement
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

— Reorient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver.
— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
— Consult the dealer or an experienced radio/TV technician for help.

ISED Compliance Statement
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference,(2)This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:(1)L'appareil ne doit pas produire de brouillage, (2)L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

FCC SAR statement
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions to satisfy RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
The portable device is designed to meet the requirements for exposure to radio waves established by the Federal Communications Commission (USA). These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the head.

ISED SAR Compliance Statement
This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions to satisfy RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
The portable device is designed to meet the requirements for exposure to radio waves established by the ISED. These requirements set a SAR limit of 1.6 W/kg averaged over one gram of tissue. The highest SAR value reported under this standard during product certification for use when properly worn on the head.

Cet équipement est conforme aux limites d'exposition aux rayonnements ISED établies pour un environnement non contrôlé. L'utilisateur final doit suivre les instructions spécifiques pour satisfaire les normes. Cet émetteur ne doit pas être installé ou fonctionner en conjonction avec toute autre antenne ou transmetteur.
Le dispositif portatif est conçu pour répondre aux exigences d'exposition aux ondes radio établie par le développement énergétique DURABLE. Ces exigences ont un SAR limite de 1.6 W/kg en moyenne pour un gramme de tissu. La valeur SAR la plus élevée signalée en vertu de cette norme lors de la certification de produit à utiliser lorsqu'il est correctement porté sur la tête.

产品名称说明(适用于电子电气产品)						
	有毒有害物质或元素					
部件描述	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
PCB板电路板	X	O	O	O	O	O
金属部件	X	O	O	O	O	O
外壳部件	O	O	O	O	O	O
表格依据 SJ/T11364-2014 的规定编制						
O：表示该有毒有害成分所含均在该部件相关均质材料中的含量在 GB/T 26572-2011 规定的限量要求以下。						
X：表示该有毒有害成分至少该部件的均质材料中的含量在 GB/T 26572-2011 规定的限量要求。						
注：这表格是根据供应商的信息或在现有科学和技术干预现在可得情况，是得到最佳的解释。						

CAUTION
Risk of explosion if the battery is replaced by an incorrect typedisposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosionLeaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
PRÉCAUTION
Risque d'explosion si la batterie est remplacée par un type incorrect dèmination d'une batterie dans le feu ou un four chaud, ou écrasement ou découpage mécanique d'une batterie, pouvant entraîner une explosion ; laisser une batterie dans un environnement à température extrêmement élevée qui peut entraîner une explosion ou une fuite de liquide ou de gaz inflammable ; une batterie soumise à une pression d'air extrêmement faible pouvant entraîner une explosion ou une fuite de liquide ou de gaz inflammable.
PRECAUCIÓN:
Riesgo de explosión si la batería se reemplaza por una del tipo incorrecto, Eliminación de una batería en el fuego o en un horno caliente, o aplastamiento o corte mecánico de una batería, que puede resultar en una explosión; Dejar una batería en un ambiente circundante de temperatura extremadamente alta que puede provocar una explosión o la fuga de líquido o gas inflamable.
VORSICHT:
Explosionsgefahr, wenn die Batterie durch unsachgemäße Entsorgung einer Batterie in Feuer oder einen heißen Ofen oder Schneiden einer Batterie erwärmt wird, was zu einer Explosion führen kann; eine Explosion oder das Austreten von brennbarem Flüssigkeiten oder Gasen verursachen; eine Batterie, die einem extrem niedrigen Luftdruck ausgesetzt ist, der zu einer Explosion oder zum Austreten von brennbaren Flüssigkeiten oder Gasen führen kann.
警告
バッテリーを誤ったタイプでプラグを差すと火災及びオーブンへの爆破、または圧バッテリーの機械的破砕または切断によって爆発の原因となる可能性があるため注意。爆発または可燃性液体または可燃性ガスの漏洩を引き起こす可能性があるバッテリーは極端に高い温度の環境に放置しないでください。爆発または可燃性液体または可燃性ガスの漏洩を引き起こす可能性があります。
警告
如果更換電池型號不正確，將會造成爆炸；或將電池丟進火中或熱烘箱中，或機械壓碎或切割電池，可能會造成爆炸；將電池置放在極高溫環境中，可能會造成爆炸或易燃液體或氣體洩漏。
警告
如果電池受到極低的氣壓，可能會造成爆炸或易燃液體或氣體洩漏