THUNDERTUMBLER™

RADIO CONTROL 360° RALLY CAR

OPERATING INSTRUCTIONS

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

Operation requires 4 "AA" 1.5V alkaline batteries (not included) for car and one 9V battery (not included) for remote control.

1. Carefully remove items from package.
2. Locate the battery compartment on the back of each item (see diagram on right).
3. Swivel catches on bottom of car to release battery pack and insert batteries.
4. Switch both car and remote buttons to "ON" position.
5. For best result use the car on hard surfaces such as wood or tile.

REMOTE CONTROL ASSEMBLY

BATTERY DIAGRAM

USE ALKALINE BATTERIES FOR BEST PERFORMANCE

GENERAL CONTROLS

Reverse — Press both control sticks backward.

Forward — Press both control sticks forward.

Spinning Action — Press and hold the control sticks in opposite directions to make the car spin.

Action Button — Press and hold the action button to have the car stand up on its back wheels and move forward.

SPINNING ON REAR WHEEL (ACTION BUTTON)

1) Spin the car by pressing and holding the control sticks in opposite directions.

2) Press and hold the action button while the car is spinning.

SAFETY PRECAUTIONS

- Do not operate during thunderstorms or rain.
- Avoid water, sand and snow when operating car.
- Do not submerge car or controller in water.
- Never operate your car on the street or highway.
- Never operate car in a confined or crowded area, and do not use people or animals as obstacles.
- If a part not shown on this manual, diagram or insert is lost or broken, do this will cause damage to both the objects and the car.
- Keep fingers, hair or loose clothing away from the tires, gears and motor while car is in motion or operation.
- Do not leave car or transmitter near sources of heat or under direct sunlight for long periods of time.
- Do not leave car or transmitter outside overnight. Dampness is harmful to interior components.
- Remove all batteries when not in use to avoid accidental operation.
- Adult supervision is recommended when operating this car.

BATTERY WARNING:

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Insert batteries along the correct polarity. Do not short circuit the supply terminal.
- Remove batteries when not in use. Regular or alkaline or rechargeable batteries should be removed from the toy if not used for a long period of time, as it may cause damage to the toy due to leakage.
- Remove batteries from the toy when it is being charged.
- Always use batteries of the same type and capacity, charged to exactly the same voltage, if applicable, specified by the manufacturer.
- Always use, replace, and recharge (if applicable) batteries under adult supervision.

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

164133 (xxxxx)

Made in China

©2011 Mattel/Bandai. LLC. Blue Box Toy Company, the Blue Box Toy Company logos, and Thunder Tumbler are trademarks and/or registered trademarks of Mattel/Bandai, LLC. All rights reserved.

Distributed by Mattel/Bandai, LLC, Fredrick Maryland, CA 93910.

The artwork and design of this package are protected by US copyright law and other intellectual property laws. Unauthorized use of the artwork and design may violate copyright, trademark, and other laws. Such unauthorized use may be subject to civil and criminal prosecution and penalties.

Mexico Export No. 2U4000-MX-01. Mexico: permanecer para posterior consulta. Conservar para referencia futura.

- Spinning Stunt Vehicle with LED Lights
- Full-Function Wireless Radio Control
- Available in 2 Frequencies For Racing Against Each Other

- Perform Stunts and Wheelies and Ikea LED Lights
- Full-function Radio Control with Special Action Button
- Available in Two Frequencies for Racing Against Each Other