







Installation & Instructions

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC RF exposure statement:
The equipment complies with FCC Radiation exposure limit set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

IMPORTANT! *DO NOT RETURN PRODUCT TO RETAILER!*

IF YOU NEED WARRANTY SERVICE OR REPLACEMENT PARTS, PLEASE REACH OUT TO US DIRECTLY! **(805) 214-1815**

2. Mag Flex Plate Installation tool
has guide lines, ABCDE and 123.

Note: Mag Safe Cases and Phones will magnetically position center. Non Mag Safe devices will require alignment template.

1. Attach charger to mount before plugging in.

A black and white line drawing showing a hand holding a cable with a circular connector. The hand is positioning the connector to attach to a circular mount that has a stylized 'M' logo on its top surface. The mount is shown in a three-quarter view, revealing its base and the top face.

WARNING:

It is possible for the Wireless Charger / Transmitter to interfere with some wireless systems within a car. Specifically, key fobs with immobilizers, keyless start systems or tire pressure monitors. It is recommended to test the location of your transmitter before deciding on final placement. Most interference issues will be minimized by locating the transmitter before deciding on final placement.

placement guidelines:

- Install transmitter a minimum of 12 inches away from the ignition lock, key fob docking station or any location where the key fob might be stored while driving. If the transmitter cannot be located a sufficient distance away as described above, please use the following suggestions whenever possible:
- Insert the key fob into the docking slot whenever possible while operating the transmitter.
- Connect the transmitter to a 12-volt accessory port that is powered only while the vehicle's ignition is in the "ACC" position.
- Place phone on transmitter after vehicle is started.