

Vehicle Device Installation



The Vehicle Device requires a vehicle manufactured for sale in North America in the year 2008 and onwards.

1. **Start the engine of the vehicle.** It is important to start the vehicle before installing the vehicle device.
2. Determine the location of the Onboard Diagnostics Port (OBD-II port) in the vehicle. It is usually below the steering wheel in the driver's compartment and is within 2 feet of the steering wheel. If your OBD-II port is not there, look under the dash and behind ashtrays. Here is a web site that might be helpful in locating your OBD-II port:
<http://obdclearinghouse.com/>
3. **Plug the vehicle device into the OBD-II port.** Apply pressure to ensure that the device has made a good connection.
4. Once you see a red flashing light, the device installation is complete. If you don't see the red flashing light, unplug the Vehicle Device and replug it.
5. **Ensure that 2 minutes have elapsed before turning the engine off for full initialization.**
6. If installing multiple vehicle devices, repeat steps 1 – 6 until all vehicle devices are installed.

THIS EQUIPMENT COMPLIES WITH FCC RADIATION EXPOSURE LIMITS SET FORTH FOR AN UNCONTROLLED ENVIRONMENT. THIS EQUIPMENT SHOULD BE INSTALLED AND OPERATED WITH A MINIMUM DISTANCE OF 20CM BETWEEN THE RADIATOR AND YOUR BODY. THIS TRANSMITTER MUST NOT BE CO-LOCATED OR OPERATING IN CONJUNCTION WITH ANY OTHER ANTENNA OR TRANSMITTER. THE VEHICLE DEVICE IS INTENDED TO BE USED WITH A PCB ANTENNA.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

NOTE: BRIGHTLOT IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.