

## 1.1 Set-up for Conducted Emissions



## 1.2 Set-up for Conducted RF test at Antenna Port



## 1.3 Set-up for Spurious Emissions below 1GHz



Below 1 GHz

## 1.4 Set-up for Spurious Emissions above 1GHz



Above 1GHz