




02 Frame Installation

1. Push the build platform to the front of the printer, then place the gantry frame vertically on the base.
2. Fix the gantry frame and base with the No. 1 bag screws in the accessory box.





M5*25 H3.0 M5*60 H4.0

*It is recommended to use allen key with short sides to secure the screws.

03 Support Rod Installation

Use the screws in the No.2 bag to install the support rods.

*We recommend installing the base screws first.



Note: Please pay attention to the left and right distinction when installing the support rod.

