

TEST AND ADJUSTMENT PROCEDURES

Test procedure for changing channels, power levels, and modulation

Important Steps:

- (1) Enter Menu Screen
- (2) Select Mode (Analog /Digital)
- (3) Enter Suspend Mode & AMPS /CDMA Test menu

A. Entering Menu Screen:

- (i) Press [PWR] button to turn on the phone.
- (ii) Press menu button to browse Menu Screen

B. Selecting Mode:

- (i) Enter Menu Screen, select *System Menu* Option (7)
- (ii) Select Mode Option (2)
- (iii) Scroll to *Analog* Trans Mode
- (iv) Press [OK] to accept selection.
- (v) Press [CLR] button on keypad to return to previous screen.

(NB: Same procedure holds for Digital Mode)

3

C. Entering Suspend Mode & AMPS/CDMA Test Menu:

- (i) From Main Menu, Select *Maintain Menu* Option (8)
- (ii) Press [1] to enter suspend mode
- (iii) Press [OK] to accept selection.
- (iv) Press [2] to enter AMPS Test Menu.

*(Ensure that Mode selection is Analog before Phone can be put into AMPS test. For CDMA test, Ensure that mode is set to Digital)

D. Changing Power Levels (AMPS)

- (i) Ensure Mode Selection is Analog, then put phone into Suspend Mode, and AMPS Test Screen if you have not already done so.
- (ii) Press number keys on keypad to enter [07], then push soft-key OK to turn Carrier ON
- (iii) Press number keys on keypad to enter [09], then push soft-key OK
- (iv) Press number keys on keypad to set RF channel, then push soft-key RUN
- (v) Push phone keypad CLR key
- (vi) Push number keys on keypad to enter 10, then push soft-key OK
- (vii) Push 0 and then softkey **Run** to set power level 0.
- (viii) Push sofkey **NEW**
- (ix) Push 1 and then softkey **Run** to set power level 1.
- (x) Repeat steps (viii) & (ix) for subsequent power levels.

E. Changing Power Levels (CDMA)

- (i) Ensure Mode Selection is Digital, then put phone into Suspend Mode, and CDMA Test Screen if you have not already done so.
- (ii) Press number keys on keypad to enter 07, then push soft-key OK to turn Carrier ON
- (iii) Push sofkey **NEW**
- (iv) Press number keys on keypad to enter 09, then push soft-key OK
- (v) Press keys on keypad to set RF channel, then push soft-key RUN
- (vi) Push sofkey **CLR**
- (vii) Push number keys on keypad to enter 10, then push soft-key OK
- (viii) Push sofkey **NEW**
- (ix) Push number keys on keypad and then softkey **Run** to set desired digital TX power (dBm)
- (x) Push sofkey **NEW**
- (xi) Repeat steps (viii thru. viii) to set other desired digital TX power.
(Note: Press “*” key to insert minus(-), & “#” key for point (.))

F. Changing Channels

- (i) Enter Menu – Described in (A) above
- (ii) Select desired mode – Described in (B) above
- (iii) Enter suspend mode and desired test screen - Described in (C) above
- (iv) Press number keys on keypad to enter [09], then push soft-key OK
- (v) Push sofkey **NEW**
- (vi) Press number keys on keypad to set RF channel, then push soft-key RUN
- (vii) Push sofkey **CLR**
- (viii) Press number keys on keypad to enter 07, then push soft-key OK to turn Carrier ON
- (ix) Push softkey **NEW** and repeat steps (iv through vii) to change to other desired channels.