

PROGRAMMING ADDITIONAL REMOTES REQUIRE AT LEAST ALREADY PROGRAMMED REMOTE

Programming Instructions:

1. Get into vehicle with existing key, new keys and programmer.
2. Leave driver's door open.
3. Press start/stop button to the ON position.
4. Plug programmer into OBD port (located under drivers side kick panel)
5. After 10 seconds programmer will beep indicating you have entered programming mode.
6. Using an existing already programmed remote, touch the back of the remote to the start/stop button. You should hear a beep. Place remote on passenger seat.
7. Using a new remote to be programmed, touch the back of the remote to the start/stop button. You should hear a beep.
8. Press start/stop button to OFF position and remove programmer.
9. Put foot on brake pedal and start vehicle.
10. Turn vehicle OFF and test all buttons on the new remote.
11. If programming fails, repeat the process.

FCC WARNING

Statement 15.19(a)(3): This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by Dorman Products Inc. could void the user's authority to operate the equipment.

IC WARNING

FVIN 6313702IC

PROGRAMMING ADDITIONAL REMOTES REQUIRE AT LEAST ALREADY PROGRAMMED REMOTE

The term IC before the Certification/Registration number only signifies that the Industry Canada technical specifications were met.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference including interference that may cause undesired operation of the device.