

TRAC Back™ User's Manual

Voice command thru your radio!

Vehicle Alignment Instructions

1. Align vehicle about 9 feet from trailer.
2. Raise trailer so coupler is 2" above hitch ball.
3. Attach TRAC Back to hitch ball (parallel to bumper).
4. Remove rubber ball, place in coupler (pull ball and cord out slowly)
5. Tune vehicle's radio to 1640 AM.
6. Back vehicle following TRAC Back's voice commands.
7. When alignment is achieved, set parking brake.
8. Remove TRAC Back and attach trailer.

TRAC Back will automatically turn off when the ball is returned.

CAUTION - Modifications to this device not expressly approved by TRAC Outdoor Products could void user's authority to operate it.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference and
(2) this device must accept any interference received, including interference that may cause undesired operation.

TRAC Outdoor Products Co