

# Quick Start Guide

52WM-3T



## Installing Wireless Modules

Attach the Sensor String to the inside middle of the rack door. Start 6" from the bottom and work up. Refer to the "Wireless System Startup Guide" for additional information.

1. Use at least one cable fastener to secure each sense point on the Sensor String. Multiple cable ties may be used to secure the sense points both above and below the Sensor housings.
2. Keep cable straight and tight while securing Sensors.
3. Trim excess cable tie material and discard.



## Configuring Wireless Modules

1. Verify that the Emerson Smart Wireless Gateway is turned on. Refer to the "Wireless System Startup Guide" for additional information.
2. Turn on the Wireless Module by pressing and holding the Config button B1 until LEDs L1 and L2 light up momentarily.



3. Wireless Modules are shipped with a factory default Net-ID and Join Key already programmed. The factory default NetID and Join Key are listed below:

**NetID:** 1229

**Join Key:** 445553544e4554574f524b53524f434b

4. If the NetID and Join Key of the Wireless Module and Smart Wireless Gateway do not match, reprogram the Wireless Module to match the NetID and Join Key of the Smart Wireless Gateway. Refer to the "Wireless System Startup Guide" for additional information.



**Therm-O-Disc, Inc.**  
1320 South Main Street  
Mansfield, OH 44907  
(419)-525-8500  
[www.thermodisc.com](http://www.thermodisc.com)

  
**EMERSON**