SKTFCE-050411-023 FCC ID :S2MLIVE120



SK TECH CO., LTD.

Page 1 of 2

Operational Description

| . Installation

<Main Program Installation>

Insert SmartDVR Formula CD into CD-ROM drive or run DvrSetup.exe

file;the following installation screen will appear.

Click the icon below and Main Program installation will automatically proceed.

Installation Step: Apache HTTP Server(Web Server)->WebClient->SmartDVR

Formula

- 1. SmartDVR Apache HTTP Server(Web Server) Installation
 - 1-1 Installation wizard tool will appear. Click<Next>
 - 1-2 Read the License Agreement and if you agree to the contents, select <| accept...>and click<Next>
 - 1-3 Click <Next> after checking server information of Apache HTTP Server.
 - 1-4 Insert Network Domain, Server Name, Administrator's E-mail Address.
 (This procedure is only a formality. In general cases, follow example)
 Select<Run as a service for All Users-Recommended>and click<Next>.
 - 1-5 Select Setup Type as<Complete> and click<Next>.
 - 1-6 Click<Next> without change of setting. Note:Do not change the directory!
 - 1-7 After the setting is finished, click <Install> and start installation.
 - 1-8 After the installation is done, click<Finish>.
 - 1-9 After the installation is finished, a message confirming the change of the Server port of Apache will appear.

SKTFCE-050411-023 FCC ID :S2MLIVE120



SK TECH CO., LTD.

Page 2 of 2

- 2. SmartDVR Web Client Installation
 - 2-1 After the Installation Wizard Tool is appeared, click<Next>.
 - 2-2 Check the contents of License Agreement; if you agree to the contents, click<Yes>.
 - 2-3 Afger the installation is done, click<Finish>.
- 3. SmartDVR Formula Installation
 - 3-1 After Installation Wizard Tool is appeared, Click<Next>.
 - 3-2 Check the details of License Agreement; if you agree to the contents, click
 Yes>.
 - 3-3 After choosing<Destination Folder> for installation, click <Next>.
 - 3-4 After the installation is done, click<Finish>.
 - 3-5 Driver Installation:Wizard automatically installs drivers according to each board type.
 - 3-6 Reboot PC after all the installation.