

## Assembly Instruction, Wireless wECG Module, RoHS

### 4. Apply Overlays

#### 1.0 MR200 989803183661 and 453564390601

*For Expression*

- 2.0 Remove paper backing, orient, and install 453564381661 Back Housing Label within the ridges of the Back Housing.



*End Expression*

#### 3.0 End Assembly Process

- 4.0 Perform full final functional and RF Tests of unit per A-989803163121-90001 (Wireless wECG 2<sup>nd</sup> Gen Module Functional Test Procedure) and package for shipping or stocking to finished goods