

Turn On Procedure of V3338 GSM Module

For test the V3338 module, you need solder the V3338 to your application board or our EVB. The basic procedure of turn on V3338 need these steps :

1. Install a Dual band or Quad band GSM RF antenna
2. Insert SIM Card
3. Power on pin 35,53,54 of V3338 with 3.8V
4. Connect pin 44 to GND not less than 3 second then disconnect
5. After the V3338 power on, you could do test on the module