

TRUDEFENDER FTI

Label Locations





Picture of Labels installed on bottom of TruDefender FTi system

Thermo Scientific TruDefender FTi

Scanning Procedure



Press POWER key to turn on unit.



Press SCAN key.



Clean sampling tip.



Press SCAN; wait for background sweep to complete.




Position sample and hold unit still.



Press SCAN key again to begin scan.

Location of FCC and IC ID Label (116-00190-01)



Thermo Fisher Scientific **Customer Support 24/7** U.S.: 1-800-374-1992

Intl: 1-978-642-1100 www.thermoscientific.com/ahura

CSA C22.2 No. 61010-1



ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

WARNING: RF exposure. Keep at least 20 cm (7.9 in) separation distance from the antenna and the human body.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This product is protected by one or more of the following U.S. patents and other patent applications pending: 7,062,133; 7,254,501; 7,548,673; 7,409,125; 7,698,080; 7,675,611.

Label PN: 116-00089-05

FCC ID: Z4HTDFTI IC: 9812A-TDFTI Model No: TruDefender FTi

Label PN: 116-00190-01