



## 如视云台 产品说明书

Realsee Gimbal Product Manual

Realsee ジンバル 製品説明書



三脚架是辅助云台拍摄的附件，不属于云台部件；手机请用户自备。

## 声明

贝壳技术有限公司对本手册有最终解释权。

本公司对于本说明书的安装错误、操作错误不作任何形式的担保，对于偶发或必然损坏不承担任何法律责任。

本说明书所包含的内容受版权法保护。版权为本公司所有，未经本公司事先书面许可，不得对本说明书任何部分进行复制、照相、复印或翻译成其他语言。

贝壳技术有限公司有权利在不提前通知的情况下对本的内说明书容进行修改。对本说明书内容的修改将体现在新出版的版本中。

贝壳技术有限公司对非本公司提供以及分销商提供的软件和设备不承担任何责任。

贝壳技术有限公司仅在下列情况下认为应该对如视云台的可靠性、安全性及性能负责。即：装配、扩充重新调整、性能改进和维修均由本公司授权的人员或机构操作；随产品附带的所有维修及更换部件以及配件均为本公司生产。

请您先阅读本说明书，熟悉产品功能后再使用本产品。本产品不适合儿童使用。为保证能正确、安全地使用本产品，请您在进行安装、设置和使用之前请务必仔细阅读本说明书所有内容，且严格按照说明书内容安装和使用。

## 产品介绍

如视云台是如视 VR 采集套装的核心产品，双轴设计，配合三脚架使用，使手机可以稳定旋转 360 度拍摄，完成 VR 采集。



### 【如视 VR APP 下载】

请前往官网 (xxxxxxxxx)，或添加如视 VR 服务公众号下载安装如视 VR app，并按照公众号 VR 拍摄教学视频进行拍摄使用。



# 安全操作指引

## 【警告】

- 1、如视云台不防水。请勿让云台接触到任何液体，建议使用柔软的干布清洁。
- 2、禁止以任何方式拆解产品。云台电池为不可拆卸状态，若拆解过程中刺破电池，将会导致电池内部电解液泄露，甚至引起起火，爆炸。
- 3、云台为高精度产品，禁止机械撞击、碾压或抛掷。请勿在产品上放置重物。
- 4、禁止手动拧动云台上轴。
- 5、使用云台时禁止给云台充电。
- 6、请在温度为 0-40 度之前的环境中使用产品。

## 【注意】

- 1、云台配备了 type-C 充电线，请使用符合相关国际和地区的法规和安全性标准的其他第三方适配器给云台充电。使用不符合相关安全性标准的适配器充电时可能会有死亡或受伤的风险。使用损坏的线缆或适配器，或者在潮湿环境下充电，会导致火灾、电击、受伤等，可能会损坏云台或其他财物。当您使用电源适配器给云台充电时，将适配器电源插头插入电源插座之前，请确保交流插头或交流电源线已完全插入电源适配器。
- 2、如果云台需要维修、已损坏、出现故障或者接触到液体，请联系贝壳或贝壳授权的维修中心，如贝壳授权服务商。如果您尝试拆开云台，有可能造成损坏，且这种损坏不包括在云台的有限保修范围内。

## 【特殊物质申明】

| 部件名称  | 产品中有害物质的名称及含量 |       |       |             |           |             |
|-------|---------------|-------|-------|-------------|-----------|-------------|
|       | 有害物质          |       |       |             |           |             |
|       | 铅(Pb)         | 汞(Hg) | 镉(Cd) | 六价铬(Cr(VI)) | 多溴联苯(PBB) | 多溴二苯醚(PBDE) |
| 外壳、构造 | ○             | ○     | ○     | ○           | ○         | ○           |
| 主板    | ○             | ○     | ○     | ○           | ○         | ○           |
| 电机    | ×             | ○     | ×     | ○           | ○         | ○           |
| 电池组   | ○             | ○     | ○     | ○           | ○         | ○           |
|       |               |       |       |             |           |             |

本表格依据 SJ/T11364 的规定编制。

○：表示该有害物质在该部件所有均质材料中的含量均在 GB/T26572 规定的限值量要求下。

×：表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T26572 规定的限值量要求。

对于表"×"的情况，属于欧盟 RoHS 指令的豁免项目



在本指南中所述的正常使用条件下，本产品（除电池外）环保使用期限为 10 年



## 规格参数

| 如视云台     |   |
|----------|---|
| 型号       | RS5YT01                                   |
| 适用手机宽度   | 65-88mm                                   |
| 尺寸       | 长×宽×高 = 145mm(L)× 38mm(W)× 152mm(H)       |
| 重量 (含电池) | 约 381g                                    |
| 颜色       | 黑色  |
| 规格       | 5V 1.5A 7.5W                              |
| 电池       | 锂离子电池 型号: N031-1S1P (3000mAh 3.7V 11.1Wh) |
| 无线模式     | 低功耗蓝牙(BLE) 5.0                            |
| 工作频率     | 2400-2483.5MHz                            |
| EIRP     | < 5dbm                                    |
| 工作环境温度   | 0°C 至 40°C (32°F 至 104°F)                 |
| 充电环境温度   | 10°C 至 45°C (50°F 至 113°F)                |
| CMIIT ID | xxxxxxxxxx                                |

## Statement

Beike Technology Co., Ltd. ("the company") has the final right to interpret the Manual. The company neither makes any form of guarantee for installation or operation errors in the Manual, nor bears any legal responsibilities for incidental or inevitable damage. The content contained in the Manual is protected by copyright law. The copyright is owned by the company. Without the prior written permission of the company, no part of the Manual may be copied, photographed, duplicated or translated into other languages.

Beike Technology Co., Ltd. has the right to modify the Manual without prior notice. The modification of the Manual will be embodied in the new version.

Beike Technology Co., Ltd. doesn't bear any responsibility for the software and devices not provided by the company.

Beike Technology Co., Ltd. only believes that it should be responsible for the reliability, safety and performance of the Realsee Gimbal in the following situations. These include: assembly, expansion, re-adjustment, performance improvement and maintenance which are operated by personnel or organizations authorized by the company. All maintenance and replacement parts and accessories attached or built into the Realsee Gimbal are produced by the company.

Please read the manual, and familiarize yourself with the product features before using this product. This product is not intended for children. To ensure proper and safe use of this product, please read all contents of this manual carefully. Set up and operate the device in strict accordance with this manual.

# Product Introduction

Realsee Gimbal is the core product of Realsee VR Acquisition Kit. dual-axis design, with tripod use, so that the phone can be fitted for stable rotation 360 degrees shooting, complete VR acquisition.



A switch for loading and unloading Mobile phone holder

Please turn slowly (fragile)

Touch and hold the switch button for 3s for Power On

Green light: Full battery

Red light: Low battery

Blue light: Bluetooth connection

Yellow light: Power off charging (steady on means

Adjust the camera up and down


Phone lens alignment logo

Adjust the camera left and right

Attach firmly to accompanying tripod.

## 【Realsee VR APP download】

Please go to the official website (<https://realsee.ai>), download and install Realsee VR app, and use the Realsee Gimbal in accordance with instructional video content which is available on the website, or through a Realsee representative.



Install the phone's main camera lens at the junction of the red dot extension line

Attach firmly when affixing to the tripod



The tripod is 1.3 meters high

# Safety Guidelines

## **[Warning]**

- 1、Realsee Gimbal is not waterproof, do not let it come into contact with any liquid, it is recommended cleaning the device with a soft dry cloth.
- 2、Do not disassemble the product in any way outside of steps outlined in this manual or in company instructional material . The battery is non-removable, if the battery is punctured during dismantling, it will cause the internal electrolyte of the battery to leak, and even cause a fire and explosion.
- 3、Realsee Gimbal is a high-precision product. Handle with care, crushing or throwing will damage the product. Do not place heavy objects on the product.
- 4、Manuel rotation of the shaft of the Realsee Gimbal will damage the product
- 5、Do not charge the Realsee Gimbal while operating the device
- 6、Use the Realsee Gimbal in an environment with a temperature of between 0-40 degrees.

## **[Notice]**

- 1、The Realsee Gimbal is equipped with a type-C charging cable. Charge the Realsee Gimbal using a third-party adapter that meets relevant international and regional regulations and security standards. There may be a risk of death or injury when charging with an adapter that does not meet the relevant safety standards. Using a damaged cable or adapter, or charging in a humid environment may cause fire, electric shock, injury, etc., and may damage the Galois camera or other belongings. When you charge the Realsee Gimbal with the power adapter, please make sure that the AC plug or AC power cord is fully inserted into the power adapter before the power plug of the adapter is inserted into the power socket.
- 2、If the Realsee Gimbal needs to be serviced should it be damaged, unable to be normally operated , or comes in contact with liquids. Should this occur please contact Beike or maintenance centers authorized by Beike, such as service providers authorized by Beike. If you try to disassemble the Realsee Gimbal, it may cause damage, and this damage is not covered by the Realsee Gimbal's limited warranty.

# Specifications

| Realsee Gimbal         |   |
|------------------------|---|
| Model                  | RS5YT01   |
| Compatible phone width | 65-88mm   |
| SIZE                   | Length×Width×Height = 145mm(L)X 38mm(W)X 152mm(H)                               |
| Weight                 | About 381g  |
| colour                 | Black   |
| specification          | 5V 1.5A 7.5W  |
| battery                | Li-ion Cylindrical Rechargeable Battery Model : N031-1S1P (3000mAh 3.7V 11.1Wh) |

|                   |                               |
|-------------------|-------------------------------|
| wireless mode     | Low power Bluetooth (BLE) 5.0 |
| Working frequency | 2400-2483.5MHz                |
| EIRP              | < 5dbm                        |
| Working temp      | 0°C-40°C (32°F - 104°F)       |
| Charging temp     | 10-至 45°C (50°F - 113°F)      |

## Compliance Information

### EU Compliance Statement

"Hereby, [Beike Technology Co., Ltd.] declares that the radio equipment type [RS5YT01] is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: (<https://realsee.ai>)"

### FCC Compliance Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**IMPORTANT:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### IC Compliance Statement:

This device complies with Industry Canada license-exempt RSS standard(s).

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

**EMF:**

To maintain compliance with the RF exposure requirement, a separation distance of 20 cm between the device and the human should be maintained.

**Alarm information in France (IC)**

Déclaration d'exposition Attention: Cet émetteur doit être installé pour fournir une distance de séparation d'au moins 20 cm de toute personne.

**Thailand Warning Message**

เครื่องโทรศัพท์มือถือและอุปกรณ์ที่มีความสอดคล้องตามมาตรฐานหรือข้อกำหนดทางเทคนิคของ กสทช.

## 免責声明

本説明書の最終的な解釈権は Beike にあります。

当社は本説明書のインストール、操作の誤りについては一切保証せず、偶発的および必然の損壊についても法的責任を一切負いません。

本説明書に含まれる内容は著作権法で保護されています。著作権は当社に帰属し、事前に書面にて当社の許可を得ていないものについては、本説明書のいかなる部分も、複製、撮影、複写及び他の言語に翻訳することを禁じます。

Beike は予告なく本説明書の内容を変更することができます。本説明書の変更箇所は新しいバージョンの説明書にてご確認ください。

当社が提供していないもの及び代理店によるアプリケーションや製品については一切の責任を負いません。

Beike は以下の事柄について、Realsee ジンバルの信頼性、安全性及び性能について責任を負います。すなわち、組み立て、拡張、再調整、性能改善、修理は全て当社が指定するスタッフまたは機関が行います。製品に付帯する修理や交換を行う際の部品や付属品は全て当社が生産します

本製品をご使用になる前に、本書をお読みください。この製品は子供には適していません。  
本製品を正しく安全にご使用いただくために、ご使用の前に本書の内容をよくお読み頂く上、  
本書に従ってセッティング・ご使用ください。

## 製品紹介

Realsee ジンバルは、Realsee VR 取得キットのコア製品です。2 軸設計で三脚と併用することで、スマホを 360 度安定的に回転し、VR 撮影にサポートします。



### スマホ取付ホルダー

折れやすため、ゆっくり回してください

### 長押しで電源

緑ライト: バッテリー正常

赤ライト: バッテリー不足

青ライト: Wi-Fi 接続

黄色ライト: 電源 OFF で充電中

### スマホカメラの垂直調


スマホカメラマーキングライン

### スマホカメラの水平

### 三脚との接続部分

#### 【Realsee VR APP ダウンロード】


Realsee 本社、或いはローカルの代理店にご連絡ください。



スマホのメインカメラを左図通りに、二つの赤い線の交差点にセッティングしてください。



セッティングする時、ゆるめがないかを確認してください。



三脚の高さを 1.3 メートル程度にセッティングしてください

# 安全ガイドライン

## 【警告】

- 1、ジンバル本体は防水しません。ジンバルに液体を接触させないでください。整理する時、柔らかいかつ乾いた布で拭くことを勧めます。
- 2、いかなる方法で製品を分解してはいけません。ジンバル電池は取外しが不可能であり、分解中に電池を破った場合、電池内部の電解液が漏れ、発火、爆発を起こす恐れがあります。
- 3、ジンバルは高精度の製品で、機械的な衝撃、転がり、投げは禁止です。製品の上に重いものを置かないでください。
- 4、ジンバルの上部シャフトを手動でねじ込むことは禁止されています。
- 5、ジンバルを使用する際にジンバルを充電することは禁止されています。
- 6、製品は0~40°の環境で使用してください

## 【注意事項】

- 1、ジンバルにはタイプCの充電ケーブルが付属されています。ジンバルの充電には、関連する国際および地域の規制と安全基準に準拠した他のサードパーティ製アダプターを使用してください。関連する安全基準を満たしていないアダプターで充電すると、負傷または死亡する危険性があります。破損したケーブルやアダプターを使用したり、湿気の多い環境で充電したりすると、火災、感電、けがなどの原因となり、ジンバルなどの物が破損する恐れがあります。電源アダプターを使用してジンバルを充電する場合は、アダプターの電源プラグを電源コンセントに差し込む前に、ACプラグまたはAC電源コードが電源アダプターに完全に差し込まれていることを確認してください。
- 2、ジンバルの修理が必要な場合、損傷した場合、誤動作した場合、または液体と接触した場合は、Realsee本部またはRealsee認定サービスプロバイダーなどのRealsee認定修理センターに連絡してください。ジンバルを分解しようとすると破損する恐れがあり、この場合にはジンバルが保証対象外となります

# 仕様

| Realsee ジンバル |   |
|--------------|---|
| 型名           | RS5YT01                                   |
| スマホ幅の対応範囲    | 65-88mm                                   |
| 寸法           | 幅×奥行き×高さ = 145mm(L)×38mm(W)×152mm(H)      |
| 重さ           | 約 381g                                    |
| 色            | 黒い  |
| 電源仕様         | 5V 1.5A 7.5W                              |
| 電池タイプ        | リチウムイオン電池 N031-1S1P (3000mAh 3.7V 11.1Wh) |
| ワイヤレス モード    | 低電力 Bluetooth (BLE) 5.0                   |
| 作業周波数        | 2400-2483.5MHz                            |
| EIRP         | < 5dbm                                    |

|        |                            |
|--------|----------------------------|
| 作業環境温度 | 0°C 至 40°C (32°F 至 104°F)  |
| 充電環境温度 | 10°C 至 45°C (50°F 至 113°F) |