

QUICK START GUIDE

VENTURE

ZIZO

BUILT FOR ADVENTURE

PACKAGE CONTENTS

IN THE BOX

4x Earbuds (L, R)

1x Charging Case

1x USB-C Charging Cable

1x Quick Start Guide

LAYOUT

Touch-sensitive sensor

Charging contact

Earbud tip

Directional indicator

Microphone

GETTING STARTED

Before using your earbuds the first time, fully charge the earbuds.

CHARGING

1 Ensure both buds are securely placed in the charging case

LED Indicator

2 Close lid and connect included cable to power source

USING YOUR DEVICE

BLUETOOTH® PAIRING

1 Tap and hold earbuds simultaneously to enter True Wireless Mode

2 You will hear voice feedback confirming left and right channels

3 Navigate to your device's Bluetooth settings and select "ZIZO VENTURE" from the available device list

CONTROLS

Single Tap

Double Tap

Triple Tap

Tap & Hold

ZIZO

JOIN THE ADVENTURE

ZIZOWIRELESS.COM

f

@

t

@ZIZOWIRELESS

MUSIC

Left (L)

Single Tap (L or R)

Play / Pause Music

Press & Hold for 2 seconds (L or R)

Activate your phone's voice assistant

Right (R)

Double Tap (L or R)

Previous Song

Triple Tap (L or R)

Next Song

ADDITIONAL FEATURES

PHONE CALLS

Double tap either Venture Bud to answer incoming calls

LAUNCHING VOICE ASSISTANT

Press and hold either earbud for 2 seconds to activate your phone's voice assistant

TECHNICAL SPECIFICATIONS

SPECIFICATIONS

Model: Venture

Bluetooth® Wireless Technology: V 5.0

Wireless Transmission Distance: Up to 30 ft

Battery Capacity (Earbuds): 50 mAh

Battery Capacity (Charging Case): 300 mAh

Frequency: 2.4 GHz

Frequency response: 50Hz-20KHz

Sensitivity: 100 dB

Vocal Track System: True Stereo (TWS)

SNR: > 85dB

IMPORTANT SAFEGUARDS:

1. Do not allow water to spill onto the surface or into the product.

2. Children should be supervised while operating this device.

3. If the product surface is damaged or if there is a mechanical or electrical malfunction, do not use the unit. Contact ZIZO customer support.

4. Do not place the unit in water.

5. Do not place the product in direct heat. This unit is to be placed in a dry and ventilated place.

6. Do not place heavy objects on the unit.

CE

FC

RoHS

REACH

WEEE

WARRANTY INFORMATION

At ZIZO, we are 100% committed to your satisfaction. We stand behind our products and offer a 1-year manufacturer warranty against defects in materials or workmanship of your new ZIZO earbuds.

Should you find your item to be defective, simply visit [zizowireless.com/warranty](https://www.zizowireless.com/warranty) to submit a brief Warranty Service Request form. Warranty applies to products purchased from ZIZO Authorized resellers. International product registration is not available at this time. U.S. Customers Only.

CONTACT US

ZIZO CUSTOMER SERVICE

EMAIL

info@zizowireless.com

TELEPHONE

+1 (909) 444-7992 (English)

WEBSITE

[zizowireless.com/support](https://www.zizowireless.com/support)

#ZIZOWIRELESS

f

@

t

#ZIZOWIRELESS.COM

© 2021 ZIZO. All rights reserved. This document and all other documents are registered trademarks or service marks of ZIZO Inc. and any use of such marks by other parties without the express written consent of ZIZO Inc. is strictly prohibited. All other marks are the property of their respective owners. Images are for illustrative purposes only. All trademarks are the property of their respective owners.

ZIZO Inc. is a registered trademark of ZIZO Inc.

GUIDE DE DÉMARRAGE RAPIDE

VENTURE

ZIZO

CONSTRUIT POUR L'AVENTURE

CONTENU DU COLIS

DANS LA BOITE

2x écouteurs Venture (L, R)

1x cas de charge

1x câble de charge USB-C

1x Guide de démarrage rapide

DISPOSITION

Toucher sensible

Contact de charge

Embout intra-auriculaire

Directionnel indicateur

Microphone

COMMENCER

Avant d'utiliser vos écouteurs pour la première fois, chargez-les complètement.

CHARGE

1 Assurez-vous que les deux écouteurs sont bien placés dans le coffre

Indicateur LED

2 Fermez le couvercle et connectez le câble fourni à la source d'alimentation

UTILISER VOTRE APPAREIL

BLUETOOTH® APPARIEMENT

1 Appuyez et maintenez enfoncés les écouteurs simultanément pour passer en mode True Wireless

2 Vous entendrez un retour vocal confirmant les canaux gauche et droit

3 Accédez aux paramètres Bluetooth de votre appareil et sélectionnez "ZIZO VENTURE" à partir de la liste des appareils disponibles

LES CONTRÔLES

Unique T Touche

Double T Touche

Triple T Touche

T Touche & Tenir

REJOIGNEZ L'AVENTURE

ZIZOWIRELESS.COM

f

@

t

@ZIZOWIRELESS

MUSIQUE

Gauche (G)

Unique T Touche (G or D)

Jouer / Pause La Musique

T Touche & Tenir pour 2 secondes (G or D)

Activer votre téléphone's Voice Assistant

Droit (D)

Double T Touche (G or D)

Chanson Précédente

Triple T Touche (G or D)

Prochaine Chanson

CARACTÉRISTIQUES SUPPLÉMENTAIRES

APPELS TÉLÉPHONIQUES

Appuyez deux fois sur Venture Bud pour répondre aux appels entrants

LANCER L'ASSISTANT VOCAL

Appuyez sur l'une des oreillettes pendant 2 secondes pour activer l'assistant vocal de votre téléphone

SPECIFICATIONS TECHNIQUES

CARACTÉRISTIQUES

Bluetooth® Wireless Technology: V 5.0

Distance de transmission sans fil: Jusqu'à 30 ft

Capacité de la batterie (Oreillettes): 50 mAh

Capacité de la batterie (Boîtier de charge): 300 mAh

Fréquence: 2.4 GHz

Réponse en fréquence: 50Hz-20KHz

Sensibilité: 100 dB

Système de piste vocale: True Stereo (TWS)

SNR: > 85dB

GARANTIES IMPORTANTES:

1. Ne laissez pas l'eau se répandre sur la surface ou dans le produit.

2. Les enfants doivent être surveillés.

3. Si la surface du produit est endommagée ou s'il existe un problème mécanique ou électrique, dysfonctionnement, n'utilisez pas l'appareil. Contactez le support client ZIZO.

4. Ne placez pas l'appareil dans l'eau.

5. Ne placez pas le produit à la chaleur directe. Cette unité doit être placée dans un endroit sec et endroit ventilé.

6. Ne placez pas d'objets lourds sur l'appareil.

CE

FC

RoHS

REACH

WEEE

INFORMATIONS DE GARANTIE

Chez ZIZO, nous nous engageons à 100% pour votre satisfaction. Nous garantissons nos produits et offrons une garantie du fabricant d'un an contre les défauts de matériel ou de fabrication de vos nouveaux écouteurs ZIZO.

Si vous trouvez que votre article est défectueux, visitez simplement [zizowireless.com/warranty](https://www.zizowireless.com/warranty) pour envoyer un bref formulaire de demande de service de garantie. La garantie s'applique aux produits achetés auprès de revendeurs ZIZO agréés. L'enregistrement international du produit n'est pas disponible pour le moment. Clients américains uniquement.

CONTACTEZ NOUS

SERVICE CLIENT ZIZO

ADRESSE ÉLECTRONIQUE

info@zizowireless.com

SITE INTERNET

[zizowireless.com/support](https://www.zizowireless.com/support)

#ZIZOWIRELESS

f

@

t

#ZIZOWIRELESS.COM

© 2021 ZIZO. Tous droits réservés. Ce document et tous autres documents sont des marques déposées ou des marques de ZIZO Inc. et toute utilisation de ces marques par d'autres parties sans la permission écrite de ZIZO Inc. est strictement interdite. Toutes les autres marques sont la propriété de leurs propriétaires respectifs. Images à des fins illustratives uniquement. Tous les droits de propriété intellectuelle sont réservés à ZIZO Inc.

ZIZO Inc. est une marque déposée de ZIZO Inc.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.