

用户指南 Q79

真无线立体声耳机


Table of Product Contents



充电盒*1



无线耳机*2



Type-c 充电线*1



说明书

产品规格

蓝牙版本:	5.4
支持:	HFP/A2DP/HSP/AVRCP
充电端口:	Type-C

电池寿命:

充电盒约68小时
(实际电池寿命根据歌曲类型和音量要求而有所不同)


充电时间:

耳机1小时/充电盒1小时

传输范围

15米(无障碍)

介绍



如何将两个耳机与手机配对?

- 第一次使用前, 请确保耳机和充电盒都充满电。

- 第一步


打开充电盒盖, 两个耳机将自动开机并开始配对。【如果耳机与设备断开连接超过5分钟, 耳机将自动关闭。在提示“开机时, 按下MFB按钮约3秒, 以手动打开耳机。

- 第二步

在手机设备上启用蓝牙配对模式, 搜索并选择“Q79”进行连接。(戴上耳机时, 你会听到语音提示“连接”)。

- 如果耳塞指示灯关闭, 则表示电话已连接自动连接默认情况下, 耳机会在通电时自动连接上次配对的手机。

充电器提供的功率必须在无线电设备所需的最小0.1瓦和最大2.75瓦之间, 以实现最大充电速度。



• 提示

- 1.如果在将两个耳机与手机配对时有任何问题，请将耳机放回充电盒，并重复上述步骤。
- 2.这些耳机不仅可以一起使用，还可以单独使用。如果您想使用单个耳机，只需将一个耳机从盒中取出并连接到您的手机上。或者在使用两个耳机时，手动关闭一个耳机或将一个放回充电盒，您就可以单独使用另一个耳机。

功能

• 电话通讯

接听电话:	点击1次
挂断:	按住键2秒
拒绝来电:	按住键2秒

• 音乐

播放/暂停	轻触2次
上一曲	按住“L”键2秒
下一曲	按住“R”键2秒
激活 Siri	快速点击三次
降低音量	单击左耳塞
增大音量	单击右耳塞

充电

• 耳塞充电

耳机只有在正确放入充电槽时才会充电。(您可以同时给充电盒和耳机充电，也可以先给充电盒充电，然后再给耳机充电。


充电时指示灯会显示为白色。

充电箱会自动停止充电，耳机上的指示灯在充满电后熄灭。


当耳塞在充电电盒充电时，充电盒数字显示条持续闪烁，充电盒数字显示始终开启，直到耳机完全充电后关闭。

箱子充电

● 包装内有一根 Type-Cuab 充电线，请直接用它给充电盒充电。充电过程中，数字显示屏会闪烁并实时显示电池电量。充满电后，数字显示100。



Earbuds Charging



Case Charging

充电警报 ①

- 长时间使用后，由于磁铁连接器氧化，耳机可能无法充电甚至无法开启。
- 你可以用酒精擦拭耳机和充电盒上的磁铁连接器来解决这个问题。
- 将耳机放入充电盒中，耳机会立即关闭，充电盒会自动开始充电。
- 耳机会自动连接最后一个配对的手机。

储存与维护

- 如果耳机超过3个月没有使用，我们建议您给它充电。
- 请使用经FCC(联邦通信委员会)批准的充电器。
- 不要弄脏耳机。
- 12岁及以下的儿童需要成人监护。
- 不要将耳机暴露在高温或低温下，也不要雷雨时使用耳机。
- 避免自由落体或剧烈震动装置，使装置远离火源，不要将装置放置在水中。

常见问题

问:为什么这些耳机不和我的手机配对?

答:确保耳机已充满电并开启。

确保你手机的蓝牙已启用

如果上述两点没有问题，请在连续快速点击5次后关闭开启式耳机。将它们放回充电盒并合上，等待1分钟，然后打开充电盒，重新将耳机连接到手机。

问:为什么音乐会切入或切出?

答:首先,耳机距离手机不超过**15米**(无障碍),如果距离小于**15米**,请按照以下步骤操作:

1.1.将耳机放回箱内并合上盖子,手动点击手机上的“**Q79**”

2.10秒后,打开充电盒,将耳机与手机重新连接问:如何重置耳机?

A:开机时快速点击耳机**5次**(同时操作左右耳机),重启后耳机和手机之间的配对信息将被清除。

问:为什么我把耳机放进机壳并合上盖子后,耳机仍然无法充电或与手机断开连接?

答:确保充电盒没有处于低电池状态。

如果充电盒处于低电池状态,耳机既不会充电也不会断开。

在这种情况下,请使用**C型**充电线给机仓充满电。

问:这些耳机是防水防汗的吗?

A:这些耳机是防汗和**IPX7**防水的。对于电子产品,我们不建议将耳机浸入水中。耳机不耐热水,水蒸气会进入耳机并损坏组件。

如需更详细的产品常见问题,请联系我们的客服。

激活和保修

激活和保修

30天内无理由退换货,180天内提供售后服务。请在15天内通过以下电子邮件激活。earbudsvip26@gmail.com

"该设备符合加拿大工业部免许可的RSS标准。操作需符合以下两个条件:

(1)本装置不得引起干扰;

(2)本装置必须接受任何干扰, 包括可能引起本装置不期望的操作的干扰。


'本设备符合加拿大工业部适用于无许可证无线电设备的CNR。

在以下两个条件下允许进行操作:(1)设备不得产生干扰, 和

(2)设备的使用者必须接受所遭受的任何无线电干扰, 即使干扰有可能损害其功能”。

该装置经过评估, 已满足一般的射频曝光要求, 可在便携式曝光条件下不受限制地使用。

该设备经过评估, 符合一般射频暴露要求。该设备可在便携式暴露条件下使用, 不受限制。



User Guide for Q79

True Wireless Stereo Earphones


Table of Product Contents



Charging Case*1



Wireless Earbud*2



Type-C Charging Cable*1




Instruction Book

Product Specification

Bluetooth Version:	5.4
Support:	HFP/A2DP/HSP/AVRCP
Charging Port:	Type-C

Battery life:	about 68 hours with charging case (actual battery life varies with song type and volume requirements)
Charging time:	1 hour for earbuds / 1 hour for charging case
Transmission range:	15 meters (without obstacles)

Introduction



How do I pair two headphones with my phone?

- Please make sure both the earbuds and the charging case are fully charged before first use.

- Step 1

Open the charging case lid and both earbuds will power on and start pairing automatically.[If the earbuds are not connected to your device for more than 5 minutes, the earbuds will automatically turn off. Press the MFB button for about 3 seconds to manually turn on the earbuds when prompted "Power on".

- Step 2


Enable the Bluetooth pairing mode on your phone device, search and select "Q79" to connect. (You should hear a voice prompt "connected" when wearing earbuds.)

- If indicator light of earbud is off,it means the phone is connected

- Automatic connection

By default, the earbuds will connect the last paired phone automatically when power on.

The power delivered by the charger must be between min 0.1 Watts required by the radio equiprient, and max 2.75 Watts in order to achieve the maximum charging speed.



- Prompt

1. If you have any problem pairing the two earbuds with your phone, put the earbuds back in the charging case and repeat the above steps.
2. These earbuds can be used not only together, but also individually
If you want to use single earbud, just take one earbud out of the case and connect it to your phone. or when using two earbuds, manually turn off one earbud or put one back in the charging case and you'll be able to use the other one earbud alone.

Functions

- Telephone Communication 📞

Answer call:	single tap
Hang up:	press and hold the key for 2s
Refuse incoming call:	press and hold the key for 2s

- For Music 🎵

Play/pause	tap twice
Previous track	press and hold "L" for 2s
Next track	press and hold "R" for 2s
Activate Siri	quickly tap for three times
Turn down volume	single tap on left earbud
Turn up volume	single tap on right earbud

Charging

● Earbuds Charging

The earbuds will only be charged when you place them in the charging slots correctly. (You can charge the charging case and the earbuds at the same time, or you can charge the charging case first and then the earbuds.)


The indicator light will show **white** while charging.

The charging case will stop charging automatically and the indicator light on earbuds will go out when fully charged.


When the earbud is charging in the charging compartment, the charging compartment digital display bar remains flashing and the charging compartment digital display is always on until the earbuds are fully charged and then goes off.

● Case Charging

There is a Type-C usb charging cable in the package, please use it to charge the case directly. During charging, the digital display will flash and display the battery level in real time. When fully charged, the number shows 100.



Earbuds Charging



Case Charging

Charging Alerts

- After using it for a long period of time, due to the oxidation of the magnet connector, the earbuds might not be charged or even turned on.
- You can fix this problem by cleaning the magnet connectors on the earbuds and charging case with an alcohol wipe
- Put the earbuds in the charging case, the earbuds will turn off immediately and the charging case will start to charging automatically.
- The earbuds will connect the last paired phone automatically.

Storage and Maintenance

- If the earbuds have not been used for more than 3 months, we recommend that you charge it.
- Please use an charger approved by FCC (Federal Communications Commission).
- Do not disassemble the earbuds.
- Children aged 12 and under require adult supervision.
- Do not expose the earbuds to high or low temperatures, and do not use the earbuds during a thunderstorm.
- Avoid free fall or violent shock to the device. Keep the device away from sources of fire and do not place the device in water.

Frequently Asked Questions

Q : Why don't these earbuds pair with my phone?

A : Make sure the earbuds are fully charged and powered on.

Make sure your phone's Bluetooth is enabled

If there is no problem with the two points stated above, turn off the powered-on earbuds after 5 continuous and quick clicks.

Put them back into the charging case and close the lip, wait for 1 minute, then open the charging case and reconnect the earbuds to the phone.

Q : Why does the music cut in or out?

A : First, keep the earbuds no more than 15m away from your phone (no obstacles).

If the distance is less than 15m, follow these steps:

1. Put the earbuds back into the case and close the lid, manually click the "Q79" on your phone.
2. After 10 seconds, open the charging case and reconnect these earbuds with your phone

Q : How do I reset the headset?

A : Click the headset 5 times quickly when it is powered on (operate both left and right earphones at the same time), and the pairing information between the headset and mobile phone will be cleared after restarting.

Q : Why the earbuds still won't be charged or disconnect from the phone after I put them in the case and close the lid?

A : Make sure the charging case is not in a low battery state.

If the charging case is in a low battery state, the earbuds will neither be charged nor disconnected.

In this case, please use a type-c charging cable to fully charge the case.

Q : Are these earbuds sweat- and water-resistant?

A : These earbuds are sweatproof and IPX7 waterproof. For electronics, we do not recommend submerging the earbuds in water. The earphones are not resistant to hot water, and water vapor will enter the earphones and damage the components.

For more detailed product FAQs, please contact our customer service.

Activation & Warranty

No reason to return or exchange within 30 days, and provide after-sales service within 180 days. Please activate via email below within 15 days. earbudsvip26@gmail.com

"This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device."

« Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. »

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

L'appareil a été évalué pour répondre aux exigences générales en matière d'exposition aux RF. L'appareil peut être utilisé en condition d'exposition portable sans restriction.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.