

Welcome to AirBank



Power On
Press the power button
once to activate AirBank.




Ideal Placement
Adhering AirBank in any direction on back of smartphone will work. However, the most comfortable direction is to place AirBank in line and up straight with smartphone, where the logo "AirBank" will be horizontally in line with your smartphone. Furthermore, in this direction, AirBank's power button will be in line with the right hand sided power button of your smartphone.



Cleanliness
Suction cups will not get dirty if AirBank is adhered on proper surfaces with the right intention of using AirBank. If AirBank suction cups do get dirty, take a piece of tissue and damp the corner of tissue slightly in water. Then, dab the damp tissue on each suction cup. The process will take less than 10 seconds and suction cup will return back to it's full adhering strength.



Fast Wireless Charging
True fast wireless charging starts with AirBank. AirBank will fast wireless charge your smartphone up to 10w.



USB A Port
Plug magnetic USB A adapter attached to one end of magnetic cable to USB A port of AirBank. Then, use desired smartphone magnetic (lightning / micro usb / usb c) adapter attached to the other side of the magnetic cable to plug inside of smartphone port.

Fast Wired Charging
Once USB A and desired input port of smartphone has been plugged, AirBank will fast wire charge your smartphone of up to 10w.



USB C Port
Plug magnetic USB C adapter attached to one end of magnetic cable to USB C port of AirBank. Then, use magnetic USB A adapter attached to the other side of the magnetic cable to plug inside 10w fast charging wall adapter.

Fast Wire Charge AirBank
Once USB C and USB A ports have been plugged, AirBank will be fast wire charged of up to 10w.

C// ' †0ΩΩ° {ú†ú\$Ψ\$Ωú

71°Ω°Σσ ΨΨΣΩΩΩΩΩΩΩσ ΩΨΨ ΣβμοΣσσπβι †μμωφΣΣΣ Ωβι Ω1Σ μ†ωβι οΣσμΨΩΩΩΩΨΩ ΨΨω ΩΨΨμμ†ΩΩΣ ΩΨΩΨΣ
ΦΨΩΣ Ω1Σ ΨσΣσ σ †ΨΩ1ΨΩΩβι

[illegible]

μῖθος ἰάνυ ὑπὸ τῶν
 ὑπὸ τῶν C / / wῖπς σ εἰς σς pῖψῖς τὸς ἑξῆς ὡς σς μὲν σς ος τὸ σὺν ἰσῖς μὲν ὑπὸ τῶν
 τὸ τῶν σς τὸ τῶν wῖπς

[illegible][illegible]

I ÛXŞøŞo ù'İŞoŞ İσ ΩÙ °İ†o†ΩùŞŞ ù'İ†ù İΩùŞoŞùŞoŞΩÖŞ XİPP Ωùù ÙÖÖİİo İΩ † μ†oùÖÖİ†İo İΩsù†PP†ùùÙΩ LÙ ù'İİσ
 ŞΞİİμΨŞΩù ŚùŞσ Ö†İσŞ

110Ψ0ΠP 120Σ0ΠΣ0Σ0Ω0Σ 00 01Σ0Π 00 0ΣPΣΦ120Π 0Σ0Σμ0Π0 X1201 01Ω 0Σ ΣΣ0Σ0Ψ120Σ 0b1 0Π0120° 01Σ
ΣΣΠμΨΣ00 0Π 1ΩΣ 00 01Σ

ЙѡSo 1σ SΩ0ΰЙѡ° SЅ ЫЎ ѡbl ЫЎ 0Ў00S0Ѕ Ы'1Ѕ 1Ω2S0ЅS0SΩ0Ѕ ѡbl ЫΩS Ы0 ΨЎ0S ЫЎ Ы'1S ЫЎPPЎXΩ° ΨS†σЙѡSσ

- ԿՏԻՆԱՅԻՆ ԵՄ ՕՏԻՆԱՅԻՆ ՍՆՆՈՒՄՆԵՐԻ ՕՏԻՆԱՅԻՆ ԻՆՏԵՆՏԻՎ
- ԼՈՐԵՆՏԻՍ ՍՆՆՈՒՄՆԵՐԻ ԾՆՆՈՒՄՆԵՐԻ ՍՆՆՈՒՄՆԵՐԻ ՏՆՆՈՒՄՆԵՐԻ
- /ԵՄՆԱՅԻՆ ՍՆՆՈՒՄՆԵՐԻ ԾՆՆՈՒՄՆԵՐԻ ԵՄ ԵՄՆԱՅԻՆ ՏՆՆՈՒՄՆԵՐԻ ԵՄՆԱՅԻՆ ՍՆՆՈՒՄՆԵՐԻ

Ωσ ΘΰΩΩΣΘύΣΣ

- - / ð̥Ωσῑṽ ḡ'1\$ S\$†PSo ḡo †Ω \$bμ\$Oη\$QĐ\$S o†Šū £³ ḡ\$Ō'1ΩŋŊ†Ω ḡḡo '1\$ρμ

Ε'11σ ΣΣΦ10Σ 0ΰΨμ11σ Χ11'1 μ10ΰ 0ΰ 0'1Σ C// wΨ1σ hμSo1010ΰ11σ σ10ΛΣ0ΰ 0ΰ 0'1Σ 0ΰPP0Χ11° two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.