


SNAIL WATERPROOF WIRELESS SPEAKER



HAUT-PARLEUR SANS FIL
RÉSISTANT À L'EAU
ESCARGOT

SPECIFICATIONS

Product Size: 81 x 50 x 70mm
Weight: 92g
Loudspeaker: 40mm
Rated Power: 3W
Interface: Micro USB


Bluetooth® Specifications:
Operation Frequency: 2.400GHz-2.480GHz
Power Output (Peak): Class 2/4 dbm
Receiving Sensitivity: -88db, @ 0.1% BER
Operating Range: Up to 10m

Battery Specifications:
Capacity: 600mA, 3.7V, Polymer Li-ion Battery
Music Playback Time: 3-4hours at 70% volume
Charging Standard: DC 5V, 500mA
Charging Time: 2-3 hours

Accessories:
USB Cable: 1pc
User Guide: 1pc
Speaker: 1pc

OPERATION

- Interface dust cover: protects switch and Micro USB port
- Power switch: Switches the unit On/Off
- Micro USB: Charging port
- Press + Next song; Press and hold to increase volume
- Press - Previous song; Press and hold to decrease volume
- Press ► to Play/Pause under playback mode
- Press ► to Answer/Hang up during phone calls in Bluetooth® mode. Press and hold this button to disconnect the Bluetooth® connection
- Mic: Serves as microphone during hands-free calling
- Suction Cup: Capable of sticking to any smooth surface (glass, glossy areas, flat walls, ceramic, etc.)
- LED indicator: Built-in battery indicator
*Red light on:in charging mode
*Blue light on: fully charged
*Blue light flashing quickly: in Bluetooth® pairing mode
*Blue light flashing slowly: Bluetooth® pairing successfully



USAGE

- Switch on the speaker
- Activate the connecting devices' Bluetooth®
- Turn speaker to pairing model (blue light flashing quickly)
- Search "BT speaker" and pair
- Connect and play

NOTES

- Hands-free call is only available when in Bluetooth® connected status. Phone calls can be interfered with high frequency electromagnetism. People should not try to use this product in high frequency environments.
- Bluetooth® transmits bi-directionally, the transmitting distance is highly related to the audio player. Compatible Bluetooth® devices are recommended.
- Some players will not automatically switch during play function, in this case, a 'pop' noise may be heard between songs.

- When Bluetooth® transmitting devices cannot be connected, please delete the last Bluetooth® receiving devices name on the list. Re-activate the speaker, then try re-searching and re-pairing.
- Audio quality can be affected when the Bluetooth® transmitting devices have a poor signal or low battery capacity.
- Waterproof: Only the silicone gel housing is waterproof, do NOT expose the inner structure and components to water, liquid or dampness.

SPÉCIFICATIONS

Taille du produit: 81 x 50 x 70mm
Poids: 92g
Haut-parleur: 40mm
Puissance nominale: 3W
Interface: Micro USB


Spécifications BluetoothMD:
Fréquence de fonctionnement: 2.400 GHz-2.480 GHz
Puissance de sortie (crête): classe 2/4 dbm
Sensibilité de réception: -88 db, à 0,1 % BER
Portée de fonctionnement: jusqu'à 10m

Spécifications de la batterie:
Capacité: 600 mA, 3.7V, batterie lithium-ion polymère
Temps de lecture de musique: 3-4 heures à 70 % de volume
Norme de charge: 5V CC, 500mA
Temps de charge: 2-3 heures

Accessoires:
Câble USB: 1 pc
Guide de l'utilisateur: 1 pc
Haut-parleur: 1 pc

OPÉRATION

- Couvercle anti-poussière d'interface : Protège le commutateur et le port Micro USB
- Interrupteur d'alimentation: Allume/Éteint l'appareil
- Micro USB: port de charge
- Appuyez sur + Chanson suivante; Appuyez et maintenez pour augmenter le volume
- Appuyez sur - Chanson précédente; Appuyez et maintenez pour diminuer le volume
- Appuyez sur ► pour lire/pause en mode lecture
- Appuyez sur ► pour répondre/raccrocher pendant les appels téléphoniques en mode BluetoothMD Appuyez sur ce bouton et maintenez-le enfoncé pour déconnecter la connexion BluetoothMD
- Mic: sert de microphone pendant les appels mains libres
- Ventouse: Capable de coller à n'importe quelle surface lisse (verre, zones brillantes, murs plats, céramique, etc.)



USAGE

- Allumez le haut-parleur
- Activer le BluetoothMD des appareils connectés
- Mettez le haut-parleur sur le modèle d'appariement (le voyant bleu clignote rapidement)
- Recherchez "BT speaker" et associez-le
- Connectez-vous et jouez

REMARQUES

- L'appel mains libres n'est disponible que lorsque le statut de connexion BluetoothMD est connecté. Téléphone les appels peuvent être perturbés par l'électromagnétisme haute fréquence. Les gens ne devraient pas essayer d'utiliser ce produit à haute fréquence environnements.
- BluetoothMD transmet de manière bidirectionnelle, la transmission la distance est fortement liée au lecteur audio. Appareils BluetoothMD compatibles sont recommandés.

- Certains joueurs ne changeront pas automatiquement pendant le jeu fonction, dans ce cas, un bruit "pop" peut être entendu entre les chansons.
- Lorsque les appareils de transmission BluetoothMD ne peuvent pas être connectés, veuillez supprimer le dernier nom des appareils de réception BluetoothMD sur la liste. Réactivez le haut-parleur, puis essayez recherche et ré-appariement.
- La qualité audio peut être affectée lors de la transmission BluetoothMD les appareils ont un signal faible ou une faible capacité de batterie.
- Imperméable: Seul le boîtier en gel de silicone est étanche, ne l'exposez PAS la structure interne et les composants à l'eau, au liquide ou à l'humidité.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.