



## Product

# E600 Field Controller

## Quick start guide

This manual is for reference only.  
There might be subtle differences between actual product and picture.  
Please refer to actual product.

Please read this manual before using product.



## Installation of SIM card and SD Card

Please pay attention to the direction of slot when inserting the card.  
Inserting a non-standard card may cause damage to the SIM card holder of the device.

Open the SIM/ SD plug first and take out the card tray with the PIN, then you can insert the SIM and SD card.

