

3 IN 1 MAGNETIC WIRELESS CHARGER
USER MANUAL



Note:
To ensure safe and efficient charging of 3 devices, you must use a 9V/2A adapter (Qualcomm Quick Charge 2.0 or 3.0) and fast charging cable (if you don't use a suitable adapter and fast charging cable, the charger may not be able to charge the phone or may not charge 3 devices at the same time or may even damage the charger).

CE FC RoHS MADE IN CHINA

PRODUCT INTRODUCTION

The 3 in 1 Wireless Charger is a multi-function charging station, you can charge 3 smart devices (iPhone 12/13/14 series, iWatch and earbuds) on our product at the same time. It is compatible with iPhone 12/13/14 series, iWatch, AirPods, and most of TWS.

It is unique design with elegant appearance, and perfect to use at office or at home. It is very convenient to charge your smart devices on our product especially for Apple user. There is protection of over-charge and FOD function, you can enjoy your charging experience.

APPEARANCE INTRODUCTION



CHARGING METHOD
Flat / Foldable



COMPATIBLE DEVICES

1. iPhone
iPhone 14, 14 Pro, 14 Pro Max, 14 Plus
iPhone 13, 13 Pro, 13 Pro Max, 13 mini
iPhone 12, 12 Pro, 12 Pro Max, 12 mini
iPhone 11 Series Case with MagSafe
iPhone 10 Series Case with MagSafe
iPhone 12 Series Case with MagSafe

2. Apple Watch
Apple Watch S8/ Ultra/ Hermès/ S7/ S6/ S5/ S4/ S3/ S2/ SE

3. Earbuds
AirPods Pro 2/AirPods (2nd generation) / AirPods Pro / AirPods (3rd generation)
The others Qi enable earbuds

PRODUCT SPECIFICATION

| | |
|---|--|
| Input: 9V/2A Output(Phone): 15W(Max)/10W/7.5W/5W Output(Watch): 2.5W(Max) Output(Earbuds): 3.0W(Max) | Input Port: Type-C Conversion Rate: ≥73% (Phone) Product Size: 97.0*72.4* 25mm (old) |
|---|--|

PACKING LIST
1. Magnetic wireless charging X 1 2. User manual X 1 3. Type-C quick charging cable X 1

FAQ

4. If you're failing to charge your device, please try out the following:
(1) Please restart your cell phone and test with other Type-C charging cable.
(2) Please check whether the indicator turns on or not.
(3) Please check whether the QC3.0 Adapter is connected to the charger (Output 9V/2A) or not. iPhone original adapter does not match the wireless charger.
(4) Please check your Phone case thickness(<5mm), Metal ring or Magnetic Pad will not be available.

5. If the LED light flashes and the wireless charging stand cannot charge your device, how can I deal with this problem?
(1) Before using this wireless iPhone charger, please make sure that your device supports Qi wireless charging function.
(2) Reconnecting the cable connecting your wireless charger.
(3) Rebooting the phone.
(4) Unplug the adapter and reinsert.

6. The phone is charging intermittently, or the indicator light flashes.
If the charging current is not enough, please use a adapter with sufficient power 9V/2A or 12V/2A above.

7. Charging fever.
It is normal for the receiving coil or transmitter board to generate heat during wireless charging. If the wireless charger is too hot, please take your phone off it, when the wireless charger is cooled down, please charge it again.

8. The charger does not work.
Do not put metal debris or magnetic cards on the charging area. If the product does not work due to overheating, please take off the phone and charge it again when it is cooled down.

9. For iPhone 14/13/12 series phone can not be charging?
1. If you are using iPhone 14 / 13 / 12 series, but you can't charge it, please try restarting your phone and charging again.
2. If your Phone cannot be charged, it may be due to the iOS Version, Please try restarting your phone to solve this problem.

10. If there are another problems, please contact our after-sales for solution.

TIPS

1. This 3-in-1 wireless charging station only supports Apple watch S8/ Ultra/ Hermès/ S7 / SE / S6 / S5 / S4 / S3 / S2. (Note: Apple watch series 1 is not supported)
2. Do not charge the charging station of Apple products from the computer USB interface or other power converters.
3. During charging, please the Qi enabled device in the center of each wireless charging area.
4. Make sure the device is in the middle of the cordless charger area.
5. The silicone shell of Watch and AirPods may cause abnormal charging. It is best to take it off before charging.

WARNING

1. Avoid using the product at places that are wet, humid or have high temperature.
2. Avoid dropping the product from high places.
3. Do not disassemble the product by yourselves, Please contact us if necessary.
4. Do not clean the product unless the unit is powered off.
5. It is recommended to use 18W or above adapter to charge 3 smart devices at the same time.

All products brands and trademarks are property of their respective owners.

CHARGING METHOD
Flat / Foldable



COMPATIBLE DEVICES

1. iPhone
iPhone 14, 14 Pro, 14 Pro Max, 14 Plus
iPhone 13, 13 Pro, 13 Pro Max, 13 mini
iPhone 12, 12 Pro, 12 Pro Max, 12 mini
iPhone 11 Series Case with MagSafe
iPhone 10 Series Case with MagSafe
iPhone 12 Series Case with MagSafe

2. Apple Watch
Apple Watch S8/ Ultra/ Hermès/ S7/ S6/ S5/ S4/ S3/ S2/ SE

3. Earbuds
AirPods Pro 2/AirPods (2nd generation) / AirPods Pro / AirPods (3rd generation)
The others Qi enable earbuds

PRODUCT SPECIFICATION

| | |
|---|--|
| Input: 9V/2A Output(Phone): 15W(Max)/10W/7.5W/5W Output(Watch): 2.5W(Max) Output(Earbuds): 3.0W(Max) | Input Port: Type-C Conversion Rate: ≥73% (Phone) Product Size: 97.0*72.4* 25mm (old) |
|---|--|

PACKING LIST
1. Magnetic wireless charging X 1 2. User manual X 1 3. Type-C quick charging cable X 1

FAQ

4. If you're failing to charge your device, please try out the following:
(1) Please restart your cell phone and test with other Type-C charging cable.
(2) Please check whether the indicator turns on or not.
(3) Please check whether the QC3.0 Adapter is connected to the charger (Output 9V/2A) or not. iPhone original adapter does not match the wireless charger.
(4) Please check your Phone case thickness(<5mm), Metal ring or Magnetic Pad will not be available.

5. If the LED light flashes and the wireless charging stand cannot charge your device, how can I deal with this problem?
(1) Before using this wireless iPhone charger, please make sure that your device supports Qi wireless charging function.
(2) Reconnecting the cable connecting your wireless charger.
(3) Rebooting the phone.
(4) Unplug the adapter and reinsert.

6. The phone is charging intermittently, or the indicator light flashes.
If the charging current is not enough, please use a adapter with sufficient power 9V/2A or 12V/2A above.

7. Charging fever.
It is normal for the receiving coil or transmitter board to generate heat during wireless charging. If the wireless charger is too hot, please take your phone off it, when the wireless charger is cooled down, please charge it again.

8. The charger does not work.
Do not put metal debris or magnetic cards on the charging area. If the product does not work due to overheating, please take off the phone and charge it again when it is cooled down.

9. For iPhone 14/13/12 series phone can not be charging?
1. If you are using iPhone 14 / 13 / 12 series, but you can't charge it, please try restarting your phone and charging again.
2. If your Phone cannot be charged, it may be due to the iOS Version, Please try restarting your phone to solve this problem.

10. If there are another problems, please contact our after-sales for solution.

TIPS

1. This 3-in-1 wireless charging station only supports Apple watch S8/ Ultra/ Hermès/ S7 / SE / S6 / S5 / S4 / S3 / S2. (Note: Apple watch series 1 is not supported)
2. Do not charge the charging station of Apple products from the computer USB interface or other power converters.
3. During charging, please the Qi enabled device in the center of each wireless charging area.
4. Make sure the device is in the middle of the cordless charger area.
5. The silicone shell of Watch and AirPods may cause abnormal charging. It is best to take it off before charging.

WARNING

1. Avoid using the product at places that are wet, humid or have high temperature.
2. Avoid dropping the product from high places.
3. Do not disassemble the product by yourselves, Please contact us if necessary.
4. Do not clean the product unless the unit is powered off.
5. It is recommended to use 18W or above adapter to charge 3 smart devices at the same time.

All products brands and trademarks are property of their respective owners.



70 mm

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.