



Pairing Indicator
 Battery Indicator Light

①Charging Port (Type-C/iOS)







When pairing is successful, the microphone pairing indicator and the noise reduction indicator are


Connection Method

3 Plug the receiver into the socket of the phone port, the pairing indicator flashes to enter the pairing status. (Note: Some phones need to turn on the "OTG" power supply to work properly)

Set the microphone fixing point and attach the magnetic

then align the microphone with the magnetic microphone powers off and charges automatically. fixing.

Directions for Use



button to the fixing ② Magnetic Clip

Clip the magnetic clip onto the fixing point and Return the microphone to the charging box, the

Microphone



Power On (Not Connected)	Pairing light flash blue
Power On (Connected)	Pairing and noise reduction lights blue on
Low Battery	Pairing light red light on
Power Off	All lights off
Charging	Pairing light red light on
Charging Complete	Pairing light red light off
Noise Reduction On	Noise reduction blue light on
Reverberation On	Reverberation blue on

Receiver



Click - Adjust Volume (small-medium-large adjustable in three levels)

Status Indicator Lights Power On (Not Connected) Power On

(Connected)

Charging Box



Status Low Battery

Charging Complete Tx1 and Tx2 lights flash blue ⚠ WARNING – LITHIUM BATTERY HAZARD Tx1 blue light on (1 microphone connected) BATTERY RULES: TX1 and TX2 blue lights on



Click - View Remaining Battery Level (Each white light represents 25% of the battery) Indicator Lights White light flashes

White light flashes Charging 4 white lights on Risk of fire/explosion if misused. Keep away from children. Do not disassemble, crush, or expose to heat (>60°C/140°F).

Use only manufacturer-approved charger (5V ≤ output).

Charge in well-ventilated area. Stop charging if hot/swollen.

Charge in well-ventilated area. Stop charging if hot/swollen.
 DISPOSAL: Recycle (Call2Recycle). CA: Contains Prop 65

Phone Charging

Can charge

port on the

Specifications Product Size : 61.5x54x20mm Main Material : ABS Product Weight : 71g Wireless Transmission : 2.4GHz Sound Delay phones through Sampling frequency and depth: 48KHz 24Bit the charging Signal-to-Noise Ratio : -94dB Transmission Distance : 100m (Visual & receiver side

No Signal Interference) Microphone : 360° omni-directional Working Time : Approx. 6h (one microphone) : Approx. 24h (with charging box) Battery Capacity : 70mAh (Microphone) : 600mAh (Charging box) : DC4.8-5.2V

Input Voltage Adapter : 5V/1A Caution

1.The product contains strong magnetism, in order to avoid magnetisation effect, please keep it away from magnetic cards, IC cards, implantable medical devices (such as pacemakers), hard drives, RAM chips and other easily 2. It is strictly prohibited to make the product come into

Caution

product is exposed to water, which may lead to spontaneous combustion or even explosion of the batter 3. If the product catches fire, please use water, water mist, sand, fire blanket, powder or carbon dioxide fire select the fire extinguishing method in the above recommended order according to the actual situation. 4. Please use the product in an environment where the temperature is between -10°C and 45°C, and the ambient temperature for charging the product is between 5°C and

5. Do not disassemble the product in any way. If the battery is punctured during disassembly, it will lead to the leakage of the electrolyte inside the battery, or even cause a fire or

6. Do not hit, crush or throw the product mechanically. Do not place heavy objects on the product. 7. Do not place the product in the heating equipment, cooking equipment, high-pressure containers, etc. (such as microwave ovens, battery stoves, electric ovens, electric heaters, pressure cookers, hot water heaters, gas stoves, etc.) attached to or inside, in order to prevent the battery from overheating and exploding.

(stoves or heaters, etc.) and to place the product in a car on FCC Radiation Exposure Statement:

contact with any liquid, do not immerse the product in water or make it wet. Do not use the product in the rain or in a humid environment. Corrosion may occur when the in a humid environment. Corrosion may occur when the

FCC Statement

protection against harmful interference in a residential

radio frequency energy and, if not installed and used in

guarantee that interference will not occur in a particular

nstallation. If this device does cause harmful interfere

correct the interference by one or more of the following

• Consult the dealer or an experienced radio/television

Caution: Changes or modifications not expressly approved by

granted by the Federal Communications Commission, to

that to which the receiver is connected.

technician for help.

accordance with the instructions, may cause harmful

This device complies with Part 15 of the FCC Rules. Operation Thank you for purchasing our product. We provide comprehensive after-sales service to ensure you have an excellent user experience. To safeguard your rights, please read the following warranty instructions carefully: is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that 1. This product offers a one-year warranty service under may cause undesired operation. This device has been tested and found to comply with the (1) Returns and Exchanges: Supported within one month limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable

The warranty does not cover:
 (1) Damage caused by improper use or unauthorized disassembly of the product.

(2) Product malfunctions caused by repairs not (3) Damage or malfunctions caused by external forces or

Warranty & Customer Service

interference to radio communications. However, there is no (3) Damage or manufactoris caused by external forces or other human factors.

The warranty period starts from the date of purchase. Please provide proof of purchase when seeking repairs. If proof of purchase is unavailable, the warranty period will be calculated from the radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to

manufacturing date.
This product is applied for LOCAL WARRANTY ONLY (valid only in the country/region where you purchase this product), for any warranty services please contact your local dealers • Increase the separation between the device and receiver. Connect the device into an outlet on a circuit different from

only in the country/region where you purchase this product), for any warranty services please contact your local dealers 3. For repairs and related inquiries, please contact our

材质: 128g铜板纸

Model:H01