

acer

OHR503

TWS Wireless headset

Customer Services: (978)230-8895(US)

Mon-Fri: 9am-6pm(EST)

User Manual

Product Specifications
Material: ABS
Product Weight: 35g
Charging port: type-c
Earphones Size: 22*24*33mm
Charging case size: 54*54*30mm

Please read this user manual carefully when using this product.

Preface
 Thank you for purchasing Acer products. For optimum operation, please read this manual carefully before using.

Model OHR503

Item Name TWS Wireless Earphones

Product List

Headphones x2pcs

Charging case x1pcs

Type-C charging cable x1pcs

Instruction manual x1pcs

Product Description

This TWS earphone is a wireless connectivity-enabled audio product, which is compatible with Android and iOS smartphones, tablets, and other portable electronic devices. By eliminating the constraints of wired connections, it offers users enhanced convenience and unrestricted mobility, catering to a wide range of application scenarios.

Please read this user manual carefully when using this product.

Preface
 Thank you for purchasing Acer products. For optimum operation, please read this manual carefully before using.

Model OHR503

Item Name TWS Wireless Earphones

Product List

Headphones x2pcs

Charging case x1pcs


Type-C charging cable x1pcs

Instruction manual x1pcs

Product Description

This TWS earphone is a wireless connectivity-enabled audio product, which is compatible with Android and iOS smartphones, tablets, and other portable electronic devices. By eliminating the constraints of wired connections, it offers users enhanced convenience and unrestricted mobility, catering to a wide range of application scenarios.

Product structure diagram



1.The TYPE-C charging port

2.LED pilot lamp

3.Silicone ear cap

4.MIC

5.Multi-function touch

6.LED pilot lamp

7.The headphones have an echo

8.The headphones are from the ear

9.The other party's voice is quiet

10.The signal is intermittent

11.The headphones go off

12.The left and right headphones go off

13.The left and right headphones are on

14.The left and right headphones are on

15.The left and right headphones are on

16.The left and right headphones are on

17.The left and right headphones are on

18.The left and right headphones are on

Introduction to product operation

function	operate	Light	Tone
Pair name	OHR503	/	mobile phone ringtone

Boot When the charging compartment is charged, the headset is taken out from the charging compartment and the headset is automatically turned on. When the headset is turned off, long press and touch for 3 seconds to turn the headset off.

Shutdown When the charging compartment is charged, the headset is put into the charging compartment and the headset is automatically turned off. Touch and press for 5 seconds when the power is off. The headset is not connected to the device for 3 minutes, and the headset is turned off.

Automatic power off Automatic low battery

Automatic power on The headphones are put into the charging case, and the power is charged to 3.3V, prompt it once in 30 seconds

Connect Turn off Bluetooth for a remote or smart device

Automatic back Close or open phone Bluetooth (smart device does not delete connection)

Headphone charging When the charging compartment is charged, the earphone is put into the charging compartment, the white light of the earphone is on, and the blue light of the warehouse is on

Charging compartment Double-click the left and right headphones without connecting to the device Any headphones into the switch prompt voice (the system default Chinese / Switch in English).

Smart device connectivity When the ear team is successful, automatically enter the intelligent Bluetooth list search click "OHR503" to connect the headset. After the successful connection with the smart device, there is a prompt sound.

Toggle Music/ Game mode Long press R again for 2 seconds, back to the normal music mode

Play/Pause Connect and play in the music state, click any headset Touch

Previous song Connect and play music state, click the right headset three times

Next song Connect and play music state, click the right headset three times

Increase the volume Connect connection, double click the right headset to touch

Reduce the volume When connection, double click the left headset to touch

Voice assistant When connected, long press the left headset for 2 seconds

Answer calls Connect the device call state, click any headset touch

Refuse to answer the call In the call state, long press any headset for 2 seconds

Charge the headphones Charge the headphones

Charge the headphones Charge the headphones