

整张尺寸: 100*375 mm 单页尺寸: 100*75mm
材质: 128g铜版纸 2色印刷 正反面印刷 风琴折


正面

100MM

75MM

acer Gadget

Selfie Stick Gimbal Stabilizer



反面

100MM

Remote Control

Note: The phone's camera must be on the same side as the power button in order not to interfere with the shooting.

Click: Change Landscape Mode&Portrait
Long Press: Right SpinShot Mode
Double-click: Jumping SpinShot Mode

Click: POV Mode
Long Press: Right SpinShot Mode
Double-click: 260°SpinShot Mode

Long Press: Turn on/off the remote control
Click: Take a photograph & Shoot

DREAMSPACE MODE(UPSIDE-DOWN MODE)


Jumping Dreamsphere Mode:
When the phone is landscape mode, levorotation 40°, dextrorotation 230°, levorotation 230°, dextrorotation 20° (back to the original position);
When the phone is portrait mode, dextrorotation 125°, levorotation 125° and 145°, dextrorotation 145° (back to its original position)

260°Dreamspace Mode(Left/Right):
When the phone is landscape mode, dextrorotation 50° to levorotation 310°, start shooting with a delay of 1s;
When the phone is portrait mode, levorotation 310° to dextrorotation 50°, start shooting with a delay of 1s.

FUNCTION DISPLAY DIAGRAM




How to use the Gimbal



(Please make sure the gimbal is fully unlocked before using it to avoid damaging the gimbal motors)

Pull the ring of the manual lock outwards. Slide up to lock the gimbal as a selfie stick; (Note that the lock ring is pressed down and locked) Swipe down to unlock the gimbal as a stabilizer.

How to charge the Gimbal



When the gimbal battery is too low, there will be a red light flashing reminder. At this time, the Type-C charging cable should be used to charge. The red light is always on when charging, and the light is off when fully charged.

Specification

Remote Model: Q09	Product Size: 158.5x75x61mm	Working current: Max1300mA
Main Material: ABS+Aluminum Alloy	Product Weight: 235g	Charging voltage: DC5V
Mount Holder: 37-90mm	Remote Control Battery: CR1632/replaceable	Charging current: 400mA
Folded Length: 158.5mm	Gimbal Battery: 500mAh	
Extended Length: 700mm	Working voltage: 3.7V	

(Batteries must not be exposed to sunlight, fire or similar overheating)

REMIND

Selfie Stick compatible with Android4.4 and above&iOS 5.1 and above (if you change the system's "volume button function" under your phone's camera option, be sure to change it to default, or "take apiture" to make the selfie stick work)
The clip must be held tightly when the phone is clamped.
1.Gimbal Stabilizer Mode: the best use in the 3 rods
2.Selfie Stick Mode: 6 rods are recommended

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the device and receiver.
• Connect the device into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/television technician for help.
Caution: Changes or modifications not expressly approved by the manufacturer could void the user authority, which is granted by the Federal Communications Commission, to operate this product.
• Consult the dealer or an experienced radio/television technician for help.
Caution: Changes or modifications not expressly approved by the manufacturer could void the user authority, which is granted by the Federal Communications Commission, to operate this product.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

Warranty & Customer Service

Thank you for purchasing our product. We provide comprehensive after-sales service to ensure you have an excellent user experience. To safeguard your rights, please read the following warranty instructions carefully:

- This product offers a one-year warranty service under non-human factors:
 - Returns and Exchanges: Supported within one month of purchase.
 - Free Repairs: Supported within one year of purchase.
- The warranty does not cover:
 - Damage caused by improper use or unauthorized disassembly of the product.
 - Product malfunctions caused by repairs not authorized by our company.
 - Damage or malfunctions caused by external forces or other human factors.

The warranty period starts from the date of purchase. Please provide proof of purchase when seeking repairs. If proof of purchase is unavailable, the warranty period will be calculated from the manufacturing date.

This product is applied for LOCAL WARRANTY ONLY (valid only in the country/region where you purchase this product), for any warranty services please contact your local dealers directly.

3. For repairs and related inquiries, please contact our service email: support@szjtt.com

375MM

Removable fill light

