

G

Δ

I

N

Z

Y

MAG BANK

MAGNETIC POWER BANK

移动电源磁吸无线快充

Instruction Manual

使用说明

支持磁吸*快充

无线峰值10W

(均速7.5W)

PD双向输入输出

横向使用不挡手

创新设计工学

附带支架模式

INSTRUCTION FOR USE

MAG BANK is designed by GAINZY’s specialist, optimized for its wireless charging capability with an average charging speed reaching 7.5W*.

Status	Use	LED
On	Shake MAG BANK to activate the product.	GREEN Stable
Discharging (Wireless)	Place MAG BANK at the wireless charging area of electronic device.	GREEN Breathing
Discharging (Wired)	Connect MAG BANK to the electronic device with a Type-C USB cable (Included).	GREEN Breathing
Sleep	MAG BANK will go into sleep mode after 5 seconds of inactive use.	-
Warning	Low battery /unsupported magnetic surface triggers safe mode of MAG BANK.	RED Flashing

*For iPhone 12 series

BATTERY LEVEL INDICATOR

3 lights:
60-100% of battery

2 lights:
40-60% of battery

1 light:
20-40% of battery

1 light Flashing:
Battery level < 20%

To fulfill different users’ needs, there are three ways to use the MAG BANK :

iPhone 12 Series : Ready to use

Phones that support wireless charging with no Magsafe: Stick the magnetic ring at the back of the phone pair to use with the MAG BANK

Phones without wireless charging: Type-C USB cable charging with PD

Please choose whichever is the most suitable way to you to use!

操作

MAG BANK由GAINZY的专业团队设计，特别针对无线充电技术加以优化，使其极大程度上达到功率均衡，均速达7.5W*.

状态	操作	指示灯
开机	摇一摇MAG BANK,启动智能摇感开关。	绿色稳定
无线充(输出)	将MAG BANK磁吸/放在兼容无线充电的电子设备。	绿色呼吸
有线充(输出)	将MAG BANK用配送的Type-C USB线连接到电源适配器。	绿色呼吸
休眠	MAG BANK静止状态下，5秒自动进入休眠模式。	-
警告	低电量/非磁场，自动进入安全模式。	红色闪烁

*苹果12系列

电量提示灯

3灯:
电量介于60-100%之间

2灯:
电量介于20-60%之间

1灯:
电量介于20-40%之间

1灯闪烁:
电量低于20%

因每一位体验者手机品牌不一致，以下为用户可能遇到的情况及其解决方案：

苹果12系列支持磁吸，可直接连接使用；

如手机不支持磁吸但支持无线充电，可先安装圆形引磁环后再连接；

如手机不支持无线充电，可使用数据线PD连接。

请您在使用前花一点时间匹配到适合自己的方式！

MODEL: GZ005

SPECIFICATION:

Input : 5/9/12V; 2A (Type-C dual PD)

Output : 5/9/12V; 2A (10W Max.)(Wireless)

Size : 70 x 70 x 18 mm

Weight : 110g

CONTAINS:

1. MAG BANK - magnetic wireless fast charging power bank

2. Type-C to Type-C USB cable (0.5m)

3. Round magnetic ring (with adhesive tape)

4. Protective bag (GAINZY – white)

5. Instruction manual and warranty card

型号: GZ005

产品规格:

输入 : 5/9/12V; 2A (Type-C dual PD)

输出 : 5/9/12V; 2A (10W Max.)(Wireless)

尺寸 : 70 x 70 x 18 mm

重量 : 110g

包装内容:

1. MAG BANK - 移动电源磁吸无线快充

2. Type-C 至 Type-C USB 连接线 (0.5 米)

3. 圆形引磁环 (附带强力胶贴)

4. 保护袋 (GAINZY – 白色)

5. 操作说明书及保用证

www.gainzy.net

WARNING

1. Do not dismantle or modify the product.

2. Do not store the product in wet conditions.

3. Do not keep or use the product near heat sources.

4. Do not let water or any other liquid flows into the inside part of the product’s interface. This would cause damages to the product.

5. Make sure to remove metallic protective case of your device when charging.

6. While charging, MAG BANK may heat up. This is normal and should not affect MAG BANK’s performance. If the battery feels not to the touch during this charging process, remove the MAG BANK from the charger and allow it to cool down before resuming the charging process.

7. Avoid using bent or damaged USB cable.

DISPOSAL OF ELECTRONIC PRODUCTS

1. Do not place the product as household waste;

2. Please dispose of discarded electronic products properly, according to local regulations.

3. We encourage you to participate in relevant electronics recycling programme.

WARRENTY

1. For any defect, in the judgement of our technician, caused under normal use, we are responsible for repairing free of charges 12 months commencing from the date of purchase at the discretion of our company;

2. A valid warranty card and original purchase invoice must be presented upon request of warranty service;

3. This warranty card shall not apply to the product if:

(a) It has explicitly modified or repaired in any way by persons other than technicians of this company; or;

(b) It has been damaged through misuse, malicious acts, negligence, inflow of any liquid, or;

(c) Losses or damages are caused by force majeure or natural disasters.

4. No alteration t this warranty card will be allowed;

5. The warranty terms and conditions are subject t change without prior notice;

6. Our company will bear no responsibility over misuse of our products which cause any damage to your cell phones or any other electronic products;

7. Please consult the dealer about the product compatibility with your cell phone/PDA before purchase. Product specifications are subject to change without prior notice.

8. Please visit www.gainzy.net for the latest product information.

警告

1. 请勿自行拆开或改装本产品.

2. 请勿将本产品存放在潮湿环境中.

3. 请勿将产品靠近热源或于热源附近充电.

4. 请勿将水或其他液体流入本产品介面内部，导致本产品损坏.

5. 如您由额外使用包含金属的保护壳，请确保充电前移除.

6. 充电时，MAG BANK可能产生热力，此乃正常现象，并不会影响产品表现。但如果感到手机电池或MAG BANK过热，请断开电源供应，待冷却后，再尝试充电.

7. 避免使用屈曲或损坏的USB线材.

如何处理废弃电子产品

1. 请勿将电子产品当成家庭废弃物丢弃.

2. 请依当地的法规处理废弃的电子产品.

3. 我们鼓励您积极参与电子产品回收计划.

FC

PS

CE

RoHS

保养条款

1. 由购买日期起12个月内，如产品由损坏或故障，经本公司技术人员证实为在正常使用之情况下发生，本公司将提供免费维修服务；

2. 维修时必须出示本保用证及购买商号之发票正本，如果用户不能提供，本公司有权不提供维修服务。用户可能需要支付相关维修费用；

3. 保用期内，出现以下条款产品保用证自动失效：

(a) 非本公司人员恣意拆解或维修产品之任何部分；

(b) 错误的操作如：非法接驳电源，以及水、污秽物渗入产品内导致产品损坏；

(c) 不可抗拒之意外事件或天然灾害导致产品损坏.

4. 此保用证如经涂改，保用证自动失效；

5. 本公司有权增删任何维修及保用条款而不作通知；

6. 如因错误使用本公司产品而导致手提电话或其他电子产品有任何损坏，本公司不会承担任何责任；

7. 有关GAINZY原装产品和您的手机或电子产品的相容性，请在购买时向经销商确认。此产品规格随时可能变更，恕不另行通告；

8. 请浏览www.gainzy.net了解最新产品资讯。

WARRANTY CARD / 保用证

Model / 型号: _____

Date of Purchase / 购买日期: _____

Remarks / 备注: _____

CUSTOMER SERVICE / 客户服务

Hong Kong and Macau:

Linpo Industrial Ltd.

Unit 607-9, 6/F, Block 2, Nan Fung Industrial City

18 Tin Hau Road, Tuen Mun, N.T., Hong Kong

香港及澳门:

英宝实业有限公司

香港屯门天后路18号南丰工业城2座6楼607-9室

服务热线: 852-2455 0448 电邮: info@gainzy.net

中国内地:

东莞荣宝电子有限公司

广东省东莞市大朗镇石厦村金沙岗一路8号

邮编: 523792 全国服务热线: 86-769-3885-6833

电邮: info@gainzy.net

Copyright © 2021 Linpo Industrial Ltd. All rights reserved. GAINZY is registered trademark of Linpo Industrial Ltd. All other trademarks are the property of their respective owners.

版权所有 © 2021 英宝实业有限公司保留所有权利。GAINZY 是英宝实业有限公司的注册商标。所有其他商标均为其各自所有者的财产。

