




# Air Purifier

Model: PKJ0011 | Product User Manual



- To fully utilize the product's performance, please read this manual before use to understand the correct usage method. Keep this manual properly for future reference.

# ■ Notices & Warnings

---

## Power Notice

- ◆ Only use a power adapter that matches the specifications on the nameplate and in the manual;
- ◆ If the power cord, plug, or socket is damaged, do not use the product. It must be replaced by the manufacturer or a professional repair person;
- ◆ When unplugging the power cord, always grip the plug, not the cord. Gripping the plug may result in electric shock or fire due to short-circuiting.

---

## Notice when using the machine

- ◆ Do not use this machine without the filter installed;
- ◆ Do not insert fingers or other objects into or block the air intake/exhaust vents;
- ◆ Do not place near or on heat sources;
- ◆ If smoke, strange odors, or other malfunctions occur, immediately unplug the power cord.

---

## Usage Restrictions

- ◆ Do not use this machine in environments with flammable gases such as hydrogen, natural gas, or propane to avoid electric shock, fire, or other damage;
- ◆ Do not use this machine when using aerosol insecticides;
- ◆ Do not use in unstable places prone to tipping, or in high-temperature, humid, or water-exposed areas such as bathrooms to avoid electric shock, fire, or other damage.

---

## Cleaning Notice

- ◆ Do not wash the composite filter;
- ◆ Clean the machine's surface only with a soft cloth. Failure to do so may damage or crack the machine and cause sensor malfunctions;
- ◆ Do not clean the machine with alcohol or organic solvents, as this may damage the machine and increase the risk of electric shock, injury, or fire;
- ◆ When cleaning or not using this machine, unplug the power cord from the socket. Failure to do so may result in electric shock or fire due to short-circuiting.

---

## Notice when moving the machine

- ◆ When moving, ensure the power plug is unplugged and the machine has stopped running;
- ◆ When moving, please firmly grasp the top sides of the main unit and lift directly. Do not hold the front panel to avoid dropping the main unit and causing injury.

---

## Installation

- ◆ The main unit will not start if the filter cover is not properly installed;
- ◆ Do not install near objects that may come into contact with the air intake or exhaust vents (such as curtains), as this may pollute the objects or cause machine malfunctions;
- ◆ Do not install in places where the machine may be directly exposed to condensation. Use in room temperatures between 0 and 40 degrees Celsius;
- ◆ Do not install in places where black smoke is generated (such as kitchens), as this may cause surface corrosion or reduce sensor lifespan.

---

## Warm Tips

- ◆ Ensure there is sufficient space around the air purifier to allow natural airflow and negative ion circulation, thereby enhancing purification effectiveness;
- ◆ This machine is not suitable for operation by disabled individuals, those with sensory/intellectual disabilities, or children without supervision.


# ■ Product Introduction

---


## Unpacking

Open the packaging, take out the manual and accessories, take out the entire unit from the box, and remove the plastic bag. (Keep the outer packaging for future transportation needs)

## Main Unit and Accessories




Air Purifier Main Unit




Composite Filter × 1


(The filter is placed inside the main unit. Before use, please remove the filter's packaging bag from the machine.)



Pre-filter Electrostatic Cotton



User Manual




Pet Sticker

(For the installation procedure of the Pre-filter Electrostatic Cotton, refer to the Pre-filter Electrostatic Cotton Replacement Guide.)

# ■ Product Introduction

## Components


Note: The images in the manual are for reference only. The actual items in the box may vary.



(Please maintain a distance of at least 30 cm from walls when using the air purifier.)

# ■ Operation Instructions

## Touch Button Schematic Diagram



## ■ Connect to App

---

### Note:

- To ensure a successful connection and optimal experience, please download the latest version of the App.
- The App is continually being improved and may change over time. If there are any differences, follow the in-App instructions.

## Download App


Scan the QR code below or search for "YaberPets" on the Google Play or App Store to download YaberPets App.



## Connect to App

### Step 1: Reset device to WiFi pairing mode

With the device turn on, press and hold the WiFi button for 3 seconds, and confirm that the WiFi indicator light flashes. Once the WiFi indicator light flashes, it indicates a successful reset.



# ■ Connect to App


---

## Step 2: Add device

### Note:

- To ensure connection is successful, please turn on Wi-Fi and Bluetooth on your phone. Besides, please authorize the App with Nearby Devices permission.
- The device only supports 2.4GHz Wi-Fi, please do not connect to 5GHz Wi-Fi.

- 1) Open the App and log in, then navigate to the "Home" page.
- 2) The App will automatically search for nearby devices.
- 3) If the device cannot be automatically discovered, tap the "Add Device" or " + " button to enter the "Add Device" page.
- 4) Tap the device you want to connect to network and follow the in-App instructions to complete the connection.




## ■ Filter Replacement




When the filter's service life expires, the LED filter life indicator light turns red, indicating that the filter needs to be replaced.


① Gently press the [Power Button] to turn off the machine and cut off the main power.



② Open the filter cover, remove the old composite filter, and wrap the discarded filter in a garbage bag to prevent pollutants on the filter material from dispersing indoors.



③ After installing the new filter: Grasp both sides of the filter cover, align it with the lower card slot of the machine, and the magnet will automatically attach.



④ After completing the filter replacement, plug in the power and turn on the machine. Press and hold the [Filter Reset Button] for 3 seconds to reset the filter, and then it can be used normally.

⚠ Please read the filter replacement instructions carefully to ensure the purifier's cleaning effectiveness.



⚠ If the machine is already powered on, the power button will put the purifier into standby mode. To replace the filter, you need to unplug the power cord to cut off the main power.

⚠ Keep the inside of the purifier dry to prevent damage to the circuit.

⚠ When dust accumulates on the product surface, clean it with a vacuum cleaner to extend the filter's service life.

## ■ Pre-filter Electrostatic Cotton Replacement

- 1 Remove the filter with the dirty pre-filter electrostatic cotton.
- 2 Locate the Velcro where the pre-filter electrostatic cotton adheres to the filter perimeter, and tear off the dirty electrostatic cotton along the Velcro.
- 3 Wrap the filter perimeter with new pre-filter electrostatic cotton, align the Velcro positions, and complete the installation.
- 4 After replacement, reinstall the filter and the entire machine.




When installing, ensure the electrostatic cotton's fleece side faces outward and the grid side faces inward.


## ■ Disassemble the Cat Platform



- 1 Rotate the cat platform clockwise to unlock it.



- 2 The cat platform can then be removed.



- 3 Rotate the cat platform counterclockwise until the latch clicks into place, securing the installation.

# ■ Cleaning and Maintenance

Before maintaining the machine, the power plug must be unplugged.

## 1. Cleaning the Body:

- 1) Wipe stains with a soft cloth.
- 2) For stubborn stains that cannot be easily removed, wipe with a soft cloth dipped in a moderate amount of neutral cleaner.



During maintenance, avoid scratching the machine's exterior with hard objects. When removing the front and rear covers, follow the instructions in the manual to avoid damaging machine components.

## 2. Cleaning and Replacing the Filter:

- 1) Filter replacement is reminded by the built-in program, but due to varying pollution levels in actual application environments, the service life of each filter will differ. Replace promptly based on the machine's noise level and odors.
- 2) When dust accumulates on the surface of the composite filter, clean the surface dust with a vacuum cleaner to extend the filter's service life. (It is recommended to clean once a month)



※ It is recommended to clean once a month, and increase the cleaning frequency if the usage environment is poor. ※

Name	Replacement Period	Conditions
Composite Filter	Filter replacement is approximately every six months	Absorbs the emissions of 3 cigarettes daily

\* Depending on the usage location and method (e.g., households with many smokers), the filter replacement cycle may be shortened. In any case, replace the filter promptly when the effect is not good.

\* Please dispose of used filters as non-combustible waste.

## ■ Common Issues

If your purifier is not functioning properly, please check the following items before repair:

Phenomenon	Possible Cause	Solution
Machine Does Not Start	a. Power plug not installed b. Machine not turned on	a. Reinsert the power plug properly b. Press the Power On" button to start the machine"
Strange Odor from Air Outlet	a. Many pollution sources in the room b. Filter severely polluted	a. Open windows for ventilation b. Replace with a new filter
Excessive Operating Noise	a. Machine not installed securely b. Foreign objects inside the machine	a. Contact after-sales service center b. Remove foreign objects
Insignificant Purification Effect, No Obvious Improvement in Air Quality	a. Machine without filter installed b. Machine placed in a cramped space with obstacles affecting purification effects. c. Filter too dirty	a. Install filter b. Remove blockages c. Clean or replace filter

Error Code: EE	Machine placed horizontally or tilted	Place the machine upright
Error Code: E1	Filter life expired	Please replace the filter and reset (Reset operation: In the powered-on state, touch the "Filter Reset" button for 3 seconds)

### Warning

If the fault cannot be resolved after the above checks, please contact our company's service center, repair website, or technical service center. Do not disassemble and repair the machine yourself to avoid danger and damage to the machine.

## ■ Technical Specifications

---

### Main Technical Parameters

Product Name	Yaber Pets Purifier 05
Product Model	PKJ0011
Rated Input (US)	110 - 120V~, 60 Hz
Rated Input (EU/UK)	220 - 240V~, 50 / 60 Hz
Rated Power	55W
Noise (Sleep Mode)	25 dB (A)
Applicable Area	35m <sup>2</sup> ~ 60m <sup>2</sup>
Product Dimensions	300 × 300 × 652 mm
Net Weight	6.5 kg

# ■ Warranty Information

---

## The 2 Year Warranty

Our Yaber machine has a 2 year warranty against original defects in material and workmanship, when used for private household purposes in accordance with the Yaber Instruction Manual.

This warranty provides, at no extra cost to you, all labor and parts necessary to ensure your machine is in proper operating condition during the warranty period.

## What is Covered?

Only applies to purchases made from authorized retailers of Yaber.

This warranty will only be valid if the machine is used in the country in which it was sold.

## What's Not Covered?

The following scenarios are not covered under warranty, and repair costs shall be borne by the user:

- Human-induced damage (e.g., drops, water exposure, unauthorized disassembly, misuse).
- Malfunctions caused by failure to follow the product manual.
- Damage due to natural disasters or force majeure (e.g., fire, earthquake, abnormal voltage).
- Natural wear and tear of consumable components (e.g., batteries, filters, external accessories).
- Lack of valid purchase proof or tampered/removed product serial numbers.
- Repairs or modifications performed by unauthorized third parties.

## How to Claim?

1. Make sure your product is within the 2 year warranty period.
2. Make sure you have a copy of the invoice and order ID or proof-of-purchase.
3. Make sure you have your product. DO NOT dispose of your product before contacting us.
4. Contact our Customer Support Team via [support@yaberpets.com](mailto:support@yaberpets.com)
5. Once our Customer Support Team has approved your request, please return the product with a copy of the invoice and order ID.

## ■ Customer Service

---

We value your feedback. If you have any questions or concerns about your new product, please contact our Customer Support Team.

 Email us at [support@yaberpets.com](mailto:support@yaberpets.com)

 Call us at **+1 (888) 708-9990**

### Support Hours

**Mon-Fri, 9:00am-6:00pm EDT**

“Please have your order invoice and order ID ready before contacting Customer Support.”

---

## FCC Statement :

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

## FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.



 support@yaberpets.com

**Ekoo Electronic Co., Ltd.**

**B09, Block B, F2, Bldg.B, Runfeng Pioneer Park, No.973, Minzhi Avenue, Minzhi St.,  
Longhua, Shenzhen, CHINA 518000**