









<p><b>Smart Watch</b> <b>TGW006</b></p> <p><b>User Manual</b></p>	 <p><b>1. Preface</b></p> <p>Thank you for choosing Smart Watch TGW006. For your safety, please read this user manual carefully before use. We recommend that you keep this user manual properly for further reference.</p>	<p><b>2. Product Information</b></p>  <p>Buttons define: UP button</p> <table border="1"> <tr> <td>Long press</td> <td>-In the shutdown state, long press to turn on. -In the boot state, long press to shutdown/restart. -In sports mode, long press to end the sport. -Long press for 3 seconds to force restart.</td> </tr> </table>	Long press	-In the shutdown state, long press to turn on. -In the boot state, long press to shutdown/restart. -In sports mode, long press to end the sport. -Long press for 3 seconds to force restart.	<p><b>Click</b></p> <ul style="list-style-type: none"> <li>-When screen is shutdown, click the up button to light up the screen.</li> <li>-When the watch displays dial interface, click the up button to enter the application list interface.</li> <li>-When the watch displays a non-dial interface, click the up button to return to the dial interface (if there is a three-level menu, click again to return to the dial interface).</li> <li>-In sports mode, click the up button to pause.</li> </ul> <p><b>Down button:</b></p> <table border="1"> <tr> <td>Click</td> <td>-When the screen is shut down, click down button to light up the screen.</td> </tr> </table> <p><b>Touch screen:</b></p> <table border="1"> <tr> <td>Long press</td> <td>In the main dial interface, long press to change the dial.</td> </tr> </table>	Click	-When the screen is shut down, click down button to light up the screen.	Long press	In the main dial interface, long press to change the dial.	<p><b>click</b> Choose/Confirm.</p> <table border="1"> <tr> <td>Swipe left</td> <td>Switch card streams to heart rate and sleep, etc.</td> </tr> <tr> <td>Swipe right</td> <td>Switch card streams to heart rate and sleep, etc.</td> </tr> <tr> <td>Swipe up</td> <td>-Return to the upper level interface.</td> </tr> <tr> <td>Swipe down</td> <td>-In the dial interface, swipe up to view messages. -Change pages.</td> </tr> </table> <p><b>3. In the box</b></p> <ul style="list-style-type: none"> <li>Smart Watch TGW006(Built-in Polymer Lithium Battery)</li> <li>User Manual</li> <li>The Charger</li> </ul> <p><b>4. Instructions</b></p> <p><b>① Install App and Pair up</b></p> <p>Your Smart Watch TGW006 will turn on automatically while charging. You can search &amp; download "TouchLink" App on App Store / Google Play to update your personal information (name, gender, height, age, weight, etc.)</p> <p><b>② E Label</b></p> <p>To view E Label on your watch: go to Settings page --&gt; System --&gt; Regulatory Information.</p>	Swipe left	Switch card streams to heart rate and sleep, etc.	Swipe right	Switch card streams to heart rate and sleep, etc.	Swipe up	-Return to the upper level interface.	Swipe down	-In the dial interface, swipe up to view messages. -Change pages.	<p><b>③ Wear properly</b></p> <p>Keep the touch button facing the user, make sure the bottom sensor is clung to the skin. Keep the wristband 2 cm or more from the wrist.</p>  <p><b>④ Low battery</b></p> <p>When the battery remains less than 10%, your watch will vibrate once and display the following prompt, touch "V" back to the latest mode.</p>   <p>The screen will show below page while charging.</p> <p>The screen will show below page when it is fully charged.</p>	<p><b>⑤ Charging</b></p> <ul style="list-style-type: none"> <li>Please connect charging cable to the watch as follow:</li> <li>Use a regular USB charger with output voltage of 5.0V and output current of 0.5A and above to connect your charging line.</li> </ul>  <p><b>⑥ FAQ</b></p> <table border="1"> <thead> <tr> <th>Issue description</th> <th>Possible cause</th> <th>Solution</th> </tr> </thead> <tbody> <tr> <td rowspan="3">Incorrect step counting</td> <td>Abnormal wagging or vibration of device</td> <td>Wear the watch properly to avoid abnormal vibration</td> </tr> <tr> <td>Walked less than 15 steps</td> <td>Walk more than 15 steps continuously</td> </tr> <tr> <td>Sliding or walking in slippers</td> <td>Walk with normal postures</td> </tr> <tr> <td rowspan="3">No display</td> <td>Low battery</td> <td>Connect to charge to charge the Watch.</td> </tr> <tr> <td>The mobile's Bluetooth is off</td> <td>Turn on your mobile's Bluetooth</td> </tr> <tr> <td>App is shut down or crashed</td> <td>Restart the "TouchLink" App</td> </tr> <tr> <td rowspan="2">Failed to sync up data with App</td> <td>Out of Bluetooth signal range</td> <td>Keep your device close to mobile device with Bluetooth on</td> </tr> </tbody> </table>	Issue description	Possible cause	Solution	Incorrect step counting	Abnormal wagging or vibration of device	Wear the watch properly to avoid abnormal vibration	Walked less than 15 steps	Walk more than 15 steps continuously	Sliding or walking in slippers	Walk with normal postures	No display	Low battery	Connect to charge to charge the Watch.	The mobile's Bluetooth is off	Turn on your mobile's Bluetooth	App is shut down or crashed	Restart the "TouchLink" App	Failed to sync up data with App	Out of Bluetooth signal range	Keep your device close to mobile device with Bluetooth on																						
Long press	-In the shutdown state, long press to turn on. -In the boot state, long press to shutdown/restart. -In sports mode, long press to end the sport. -Long press for 3 seconds to force restart.																																																													
Click	-When the screen is shut down, click down button to light up the screen.																																																													
Long press	In the main dial interface, long press to change the dial.																																																													
Swipe left	Switch card streams to heart rate and sleep, etc.																																																													
Swipe right	Switch card streams to heart rate and sleep, etc.																																																													
Swipe up	-Return to the upper level interface.																																																													
Swipe down	-In the dial interface, swipe up to view messages. -Change pages.																																																													
Issue description	Possible cause	Solution																																																												
Incorrect step counting	Abnormal wagging or vibration of device	Wear the watch properly to avoid abnormal vibration																																																												
	Walked less than 15 steps	Walk more than 15 steps continuously																																																												
	Sliding or walking in slippers	Walk with normal postures																																																												
No display	Low battery	Connect to charge to charge the Watch.																																																												
	The mobile's Bluetooth is off	Turn on your mobile's Bluetooth																																																												
	App is shut down or crashed	Restart the "TouchLink" App																																																												
Failed to sync up data with App	Out of Bluetooth signal range	Keep your device close to mobile device with Bluetooth on																																																												
	<p>IS 13253(PART 1) IEC 60950-1</p> <p></p> <p>R-XXXXXXX www.bis.gov.in FCC ID: XXXXXXXXX</p> <p></p> <p>TouchGFX CO.,LTD 40A, Building H, Baoneng City (East Zone), No.3288, Liuxian Road, Fuguang Community, Taoyuan Street, Nanshan District, Shenzhen, China Made in China</p>	<p><b>5. Overview</b></p> <p><b>① General description</b></p> <p>The new Smart Watch TGW006 can help you track activity data and health status. It supports 24/7 daily activity monitoring: steps, distance, consumed calories and dynamic heart rate. Users can update their personal information such as gender, height, age, weight, etc. from the "TouchLink" App. Data stored in the Smart Watch can be synced to the "TouchLink" App and cloud server through BLE 5.0.</p> <p><b>② Features:</b></p> <ul style="list-style-type: none"> <li>Bluetooth BLE5.0</li> <li>Full-screen touch</li> <li>1.75 TFT display 320*385 pixel</li> <li>Daily Tracking: Steps / Calories / Sedentary</li> <li>Dynamic heart rate monitoring</li> <li>Breathing training</li> <li>Sleep monitoring report</li> <li>Call notification</li> <li>Find your phone</li> <li>Music control (iPhone support Apple music only)</li> <li>Camera control(Android only)</li> </ul> <p><b>6. Specifications</b></p> <table border="1"> <thead> <tr> <th>Product Name</th> <th>Smart Watch</th> </tr> </thead> <tbody> <tr> <td>Product Model</td> <td>TGW006</td> </tr> <tr> <td>Screen</td> <td>1.75-inch TFT display</td> </tr> <tr> <td>Resolution</td> <td>320 * 385 pixel</td> </tr> <tr> <td>Sensor</td> <td>Accelerometer, Heart rate and SpO2 sensor Capacitive touch sensor</td> </tr> <tr> <td>Frequency Range</td> <td>2402MHz-2480MHz</td> </tr> <tr> <td>Bluetooth Version</td> <td>BLE5.0</td> </tr> <tr> <td>Weight</td> <td>proximately 43.8g (with strap)</td> </tr> <tr> <td>Battery Capacity</td> <td>220mAh</td> </tr> <tr> <td>Working Temperature</td> <td>50°F to 113°F(Fahrenheit)</td> </tr> <tr> <td>Storage Environment</td> <td>Temperature:-4°F to 140°F(Fahrenheit) RelativeHumidity:&lt;90%RH</td> </tr> </tbody> </table>	Product Name	Smart Watch	Product Model	TGW006	Screen	1.75-inch TFT display	Resolution	320 * 385 pixel	Sensor	Accelerometer, Heart rate and SpO2 sensor Capacitive touch sensor	Frequency Range	2402MHz-2480MHz	Bluetooth Version	BLE5.0	Weight	proximately 43.8g (with strap)	Battery Capacity	220mAh	Working Temperature	50°F to 113°F(Fahrenheit)	Storage Environment	Temperature:-4°F to 140°F(Fahrenheit) RelativeHumidity:<90%RH	<p><b>Product Information</b></p>  <p>Buttons define: UP button</p> <table border="1"> <tr> <td>Long press</td> <td>-In the shutdown state, long press to turn on. -In the boot state, long press to shutdown/restart. -In sports mode, long press to end the sport. -Long press for 3 seconds to force restart.</td> </tr> </table>	Long press	-In the shutdown state, long press to turn on. -In the boot state, long press to shutdown/restart. -In sports mode, long press to end the sport. -Long press for 3 seconds to force restart.	<p><b>Click</b></p> <ul style="list-style-type: none"> <li>-When screen is shutdown, click the up button to light up the screen.</li> <li>-When the watch displays dial interface, click the up button to enter the application list interface.</li> <li>-When the watch displays a non-dial interface, click the up button to return to the dial interface (if there is a three-level menu, click again to return to the dial interface).</li> <li>-In sports mode, click the up button to pause.</li> </ul> <p><b>Down button:</b></p> <table border="1"> <tr> <td>Click</td> <td>-When the screen is shut down, click down button to light up the screen.</td> </tr> </table> <p><b>Touch screen:</b></p> <table border="1"> <tr> <td>Long press</td> <td>In the main dial interface, long press to change the dial.</td> </tr> </table>	Click	-When the screen is shut down, click down button to light up the screen.	Long press	In the main dial interface, long press to change the dial.	<p><b>click</b> Choose/Confirm.</p> <table border="1"> <tr> <td>Swipe left</td> <td>Switch card streams to heart rate and sleep, etc.</td> </tr> <tr> <td>Swipe right</td> <td>Switch card streams to heart rate and sleep, etc.</td> </tr> <tr> <td>Swipe up</td> <td>-Return to the upper level interface.</td> </tr> <tr> <td>Swipe down</td> <td>-In the dial interface, swipe up to view messages. -Change pages.</td> </tr> </table> <p><b>3. In the box</b></p> <ul style="list-style-type: none"> <li>Smart Watch TGW006(Built-in Polymer Lithium Battery)</li> <li>User Manual</li> <li>The Charger</li> </ul> <p><b>4. Instructions</b></p> <p><b>① Install App and Pair up</b></p> <p>Your Smart Watch TGW006 will turn on automatically while charging. You can search &amp; download "TouchLink" App on App Store / Google Play to update your personal information (name, gender, height, age, weight, etc.)</p> <p><b>② E Label</b></p> <p>To view E Label on your watch: go to Settings page --&gt; System --&gt; Regulatory Information.</p>	Swipe left	Switch card streams to heart rate and sleep, etc.	Swipe right	Switch card streams to heart rate and sleep, etc.	Swipe up	-Return to the upper level interface.	Swipe down	-In the dial interface, swipe up to view messages. -Change pages.	<p><b>③ Wear properly</b></p> <p>Keep the touch button facing the user, make sure the bottom sensor is clung to the skin. Keep the wristband 2 cm or more from the wrist.</p>  <p><b>④ Low battery</b></p> <p>When the battery remains less than 10%, your watch will vibrate once and display the following prompt, touch "V" back to the latest mode.</p>   <p>The screen will show below page while charging.</p> <p>The screen will show below page when it is fully charged.</p>	<p><b>⑤ Charging</b></p> <ul style="list-style-type: none"> <li>Please connect charging cable to the watch as follow:</li> <li>Use a regular USB charger with output voltage of 5.0V and output current of 0.5A and above to connect your charging line.</li> </ul>  <p><b>⑥ FAQ</b></p> <table border="1"> <thead> <tr> <th>Issue description</th> <th>Possible cause</th> <th>Solution</th> </tr> </thead> <tbody> <tr> <td rowspan="3">Incorrect step counting</td> <td>Abnormal wagging or vibration of device</td> <td>Wear the watch properly to avoid abnormal vibration</td> </tr> <tr> <td>Walked less than 15 steps</td> <td>Walk more than 15 steps continuously</td> </tr> <tr> <td>Sliding or walking in slippers</td> <td>Walk with normal postures</td> </tr> <tr> <td rowspan="3">No display</td> <td>Low battery</td> <td>Connect to charge to charge the Watch.</td> </tr> <tr> <td>The mobile's Bluetooth is off</td> <td>Turn on your mobile's Bluetooth</td> </tr> <tr> <td>App is shut down or crashed</td> <td>Restart the "TouchLink" App</td> </tr> <tr> <td rowspan="2">Failed to sync up data with App</td> <td>Out of Bluetooth signal range</td> <td>Keep your device close to mobile device with Bluetooth on</td> </tr> </tbody> </table>	Issue description	Possible cause	Solution	Incorrect step counting	Abnormal wagging or vibration of device	Wear the watch properly to avoid abnormal vibration	Walked less than 15 steps	Walk more than 15 steps continuously	Sliding or walking in slippers	Walk with normal postures	No display	Low battery	Connect to charge to charge the Watch.	The mobile's Bluetooth is off	Turn on your mobile's Bluetooth	App is shut down or crashed	Restart the "TouchLink" App	Failed to sync up data with App	Out of Bluetooth signal range
Product Name	Smart Watch																																																													
Product Model	TGW006																																																													
Screen	1.75-inch TFT display																																																													
Resolution	320 * 385 pixel																																																													
Sensor	Accelerometer, Heart rate and SpO2 sensor Capacitive touch sensor																																																													
Frequency Range	2402MHz-2480MHz																																																													
Bluetooth Version	BLE5.0																																																													
Weight	proximately 43.8g (with strap)																																																													
Battery Capacity	220mAh																																																													
Working Temperature	50°F to 113°F(Fahrenheit)																																																													
Storage Environment	Temperature:-4°F to 140°F(Fahrenheit) RelativeHumidity:<90%RH																																																													
Long press	-In the shutdown state, long press to turn on. -In the boot state, long press to shutdown/restart. -In sports mode, long press to end the sport. -Long press for 3 seconds to force restart.																																																													
Click	-When the screen is shut down, click down button to light up the screen.																																																													
Long press	In the main dial interface, long press to change the dial.																																																													
Swipe left	Switch card streams to heart rate and sleep, etc.																																																													
Swipe right	Switch card streams to heart rate and sleep, etc.																																																													
Swipe up	-Return to the upper level interface.																																																													
Swipe down	-In the dial interface, swipe up to view messages. -Change pages.																																																													
Issue description	Possible cause	Solution																																																												
Incorrect step counting	Abnormal wagging or vibration of device	Wear the watch properly to avoid abnormal vibration																																																												
	Walked less than 15 steps	Walk more than 15 steps continuously																																																												
	Sliding or walking in slippers	Walk with normal postures																																																												
No display	Low battery	Connect to charge to charge the Watch.																																																												
	The mobile's Bluetooth is off	Turn on your mobile's Bluetooth																																																												
	App is shut down or crashed	Restart the "TouchLink" App																																																												
Failed to sync up data with App	Out of Bluetooth signal range	Keep your device close to mobile device with Bluetooth on																																																												

尺寸:80x110mm

材质:128g铜版纸 双面印刷

单黑印刷

9页8折