

SENSAiO Valve position – Side view 1



SENSAiO Valve position – *Side view 2*




Model shown : SENSaIO VALV-IMU-1-1-1-L-1-1-N

SENSAiO Valve position – *Top view*



Model shown : SENSa.VALV-IMU-1-1-1-L-1-1-N

SENSAiO Valve position – *Bottom view*



Model shown : SENSa.VALV-IMU-1-1-1-L-1-1-N

SENSAiO Valve position – *Perspective view*

