

HMN: SENSА.TEMP
SENSAiO Temperature – *Side view 1*



Model shown : SENSА.TEMP-RTD-1-1-1-L-1-1-N

HMN: SENSА.TEMP
SENSAiO Temperature – *Side view 2*



Model shown : SENSА.TEMP-RTD-1-1-1-L-1-1-N

HMN: SENSА.TEMP
SENSAiO Temperature – *Top view*



Model shown : SENSА.TEMP-RTD-1-1-1-L-1-1-N

HMN: SENSА.TEMP
SENSAiO Temperature – *Bottom view*



Model shown : SENSА.TEMP-RTD-1-1-1-L-1-1-N

HMN: SENSА.TEMP
SENSAiO Temperature – *Perspective view*



Model shown : SENSА.TEMP-RTD-1-1-1-L-1-1-N

HMN: SENS.A.PRES
SENSAiO Pressure – *Side view 1*



Model shown : SENS.A.PRES-PRT-1-2-S-L-1-1-N

HMN: SENSА.PRES
SENSAiO Pressure – *Side view 2*



Model shown : SENSА.PRES-PRT-1-2-S-L-1-1-N

HMN: SENSА.PRES
SENSAiO Pressure – *Top view*



Model shown : SENSА.PRES-PRT-1-2-S-L-1-1-N

HMN: SENSА.PRES
SENSAiO Pressure – *Bottom view*



HMN: SENSА.PRES
SENSAiO Pressure – *Perspective view*

