# User's Manual Version 1



Model #: 4SO073A--YZ25

Product Specifications: Power supply: built-in 600 mah battery Includes: 1pc wireless speaker, 1pc 50cm USB cable, 1 user manual

# **Installation & Connection**


## **Powering On the Speaker**

**Step 1**: Locate the silicone cover on the side of the speaker. Gently lift the silicone flap to reveal the power switch and charging port.

**Step 2:** Toggle the power switch to the "ON" position.

The speaker will play a start-up sound effect to indicate it is powered on.

The LED indicator lights will begin flashing, signaling the device is in pairing mode.



# **Wireless Pairing Instructions**

Step 1: Set your mobile device to search for wireless devices.

**Step 2:** Search for available devices in your wireless settings. Select [4SO073A--YZ25] from the list. Note: The default device name is printed on the product label.


Step 3: Once connected, you will hear a confirmation tone, and the LED lights will stabilize.

Step 4: Start playing audio from your device. The sound will now stream through the speaker.

# **Important Notes**

#### Charging:

Use the included USB cable to charge the speaker. Connect it to a 5V adapter or computer port.



### **Safety Tips:**

Charge the speaker fully before first use.

Avoid exposing the charging port to water or dust. Close the silicone cover when not in use. Keep the speaker within a 10-meter (33-foot) range of your wireless device for optimal connectivity.

# **Troubleshooting**

No Power: Ensure the switch is toggled to "ON" and the battery is charged.

Wireless Connection Failed: Turn the speaker off and on to reset pairing mode. Delete the speaker

from your device's wireless list and reconnect.

Poor Audio Quality: Reduce distance from the device or eliminate obstructions.

# **Precautions**

- Do not use in high-temperature, humid, or strong magnetic environments.
- Avoid heavy pressure or dropping the devices.
- Dispose of used batteries per local environmental regulations.
- Questions? Comments? Contact contact@culturefly.com



THIS IS A BATTERY-OPERATED PRODUCT. THIS IS NOT A TOY. INTENDED USE OF THE PRODUCT SHOULD NOT RESULT IN EXPOSURE TO THE BATTERY. In case of rupture, the below hazards exist.

Harmful if swallowed. Causes skin irritation. Causes eye irritation. May cause respiratory irritation.

## **Proper Handling:**

Do not open, disassemble, crush, or burn battery. Do not handle battery in a manner that allows terminal to short circuit. Avoid mechanical damage of the battery. Battery may explode or cause burns, if disassembled, crushed, or exposed to fire or high temperature. Do not short or install with incorrect polarity. Avoid all personal contact, including inhalation. Wear protective clothing when risk of exposure occurs. Use in a well-ventilated area. Prevent concentration in hollows and sumps.

#### **Proper Storage:**

Store in a cool, dry, well-ventilated area. Keep away from heat and direct sunlight.

## **Disposal considerations:**

Recycle in accordance with government, state and local regulations, to ensure proper disposal.

If exposed to the battery - potential health effect and first aid measures:

### After eye contact:

Flush eyes cautiously with plenty of water for several minutes while holding eyelids open. Remove contact lenses, if present and easy to do. Continue rinsing. Get medical attention if irritation persists.

#### After skin contact:

Remove contaminated clothing and shoes. Immediately wash with water and soap and rinse thoroughly. Wash clothing and shoes before reuse. If irritation occurs, get medical attention.

#### After inhalation:

Remove person to fresh air and keep comfortable for breathing. Administer artificial respiration if breathing is difficult. Seek medical attention.

#### After swallowing:

Rinse mouth with water. Do not induce vomiting. Get medical attention.



Battery may burst and release hazardous decomposition products when exposed to a fire situation. Lithium-ion batteries contain flammable electrolyte that may vent, ignite, and product sparks when subjected to high temperature (>302°) (>150°C), when damaged or abused (e.g. mechanical damage or electrical overcharging), may burn rapidly with flare-burning effect, may ignite other batteries in close proximity.

Specific protective actions for fire-fighters:

Wear positive pressure self-contained breathing apparatus (SCBA). Structural firefighters' protective clothing will only provide limited protection.

Eliminate all ignition sources (no smoking, flares, sparks, or flames in immediate area). Do not touch or walk through spilled material. Absorb with earth, sand, or other non-combustible materials. Leaking batteries and contaminated absorbent material should be placed in metal containers.

Small fire: dry chemical, CO2, water spray, or regular foam.

Large fire: water spray, fog, or regular foam.

Suitable fire-extinguishing media:

Questions? Comments? Contact contact@culturefly.com

## **FCC Statement**

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Company Name: Culturefly LLC

Company Address: 120 west 33rd street, 9th Floor, New York NY 10001, New York, United States

Telephone Number: 001-646-8270062