# **VIVITAR**®













**ULTIMATE ESSENTIAL VLOGGING KIT** 

ITEM: VIVVLTR50KIT

#### Introduction

Thank you for purchasing the Vivitar Essential Vlogging Kit, item VIVVLTR50KIT. Start or enhance your vlogging experience with this multi-piece set. Please read this manual carefully before setting up and using the ring light.

### **Safety Precautions**

Before setting up and using the Essential Vlogging Kit, basic safety precautions should always be followed, including:

1. This product is not a toy, do not allow children to play with it. Adult supervision is advised. 2. This product should not be exposed to extreme heat or fire. Do not store in a location with temperatures above  $100^{\circ}\text{F}$ .

3. Do not crush, throw or subject this product to extreme physical force.4. Do not use this product if the legs are cracked or broken.5. Do not use in wet or humid environments.

6. Always detach mounted devices before folding and traveling with this product.
7. Ensure the tripod's legs are locked before attaching your phone or camera.
8. Please recycle or dispose of the product properly based on the laws and rules of your municipality. Contact local recycling facilities and/or the manufacturer of the product for further information.

9. Do not attempt to repair this product yourself. Contact a qualified service center if the product is in need of service.

10. To prevent damage to the product, always set-up the product on a flat surface.

11. Do not use this product outside.


#### **Contents**

- 50" Tripod
- LED Video Light Shotgun Microphone Phone CRadle
- Wireless remote with strap (battery included) GoPro Mount
- User Manual with warranty information

#### **Features**

- 49 LED Frosted Lights
  Light powered by 3 AAA batteries (not included)
  Shotgun Microphone powered by 1 AAA battery (not included)
  Tripod folds to 16.5"

### **Ring Light Set-Up**



#### **Tripod Set-Up**

- 1. Expand the legs of the tripod, placing it on a flat surface. Turn the tripod's lock knob clockwise to lock the legs into place.
- 2. Extend the leg's length by unclasping the three clips on each leg. Once extended, close the clips so the legs are locked into place.
- 3. Attach the included phone cradle onto the tripod's thread mount.

#### Attachments:

- 1. To use the light, insert three AAA batteries into the battery compartment. Twist the gear upward and slide it into the slot on top of the phone cradle. To use, press the power button on the back.
- 2. To use the boom mic, insert one AAA battery into the compartment. Twist the gear upward then slide it into the slot on top of the light.
- 3. To use the included GoPro mount, screw it onto the tripod's thread mount.

### **Using the Wireless Remote**

- 1. Push the power switch on the top of the remote On.
- 2. On your phone, go into the Settings app and in the Bluetooth page. Make sure Bluetooth is On before connecting to the available device that corresponds with the product.
- 3. Bluetooth pairing Name: AB Shutter3
- 4. Once connected, press the shutter button on the remote to take pictures wirelessly.

### **AWARNING**

- **INGESTION HAZARD**: This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause Internal ChemicalBurns in as little as 2 hours.
- KEEP new and used batteries OUT OF REACH of CHILDREN
- Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.



## **AWARNING**

- 1. Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- 2. Even used batteries may cause severe injury or death.
- 3. Call a local poison control center for treatment information.
- 4. Non-rechargeable batteries are not to be recharged.
- 5. Do not force discharge, recharge, disassemble, heat above 60°C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- 6. Ensure the batteries are installed correctly according to polarity (+ and -).
- 7. Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- 8. Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- 9. Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

#### FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
  -- Increase the separation between the equipment and receiver.
  -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  -- Consult the dealer or an experienced radio/TV technician for help.

### **Vivitar One Year Warranty**

This warranty covers the original consumer purchaser only and is not transferable. This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty
Damages or malfunctions not resulting from defects in material or workmanship and damages or
malfunctions from other than normal use, including but limited to, repair by unauthorized parties,
tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information: Call 1-800-592-9541 or visit our website at www.vivtar.com.

To receive warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepaired.

### **Vivitar One Year Warranty (continued)**

NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. IN NO EVENT WILL DISTRIBUTOR, ITS MANUFACTURERS, OR SAKAR INT. BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN. NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.

# **VIVITAR**®

©2024 Sakar International 195 Carter Drive Edison, NJ 08817 Support: 800 592 9541 www.vivitar.com