

AMX-131 Quick Guide

First use and pairing

首次使用

Put the two earbuds into the charging case to power them on, they will enter pairing mode automatically.

把两个耳机放到充电盒里，它们将自动开机并进入配对模式

Connect

连接

Turn on Bluetooth and choose "AMX-131", When the earbuds are in pairing mode.

当耳机处于配对模式时，打开手机蓝牙并选择“AMX-131”进行连接

Automatic reconnection

自动回连

Once the pairing is finished, the headphones will automatically get on and connect to the device last set up after taken out from the charging case.

有配对记录后，从充电盒中取出耳机，耳机将自动开机并连接最近连接过的一台设备

Automatic turning on/off

自动开关机

After taken out from the charging case, the headphones will be turned on automatically

将耳机从充电盒中取出，将自动开机

After put into the charging case and close, the headphones will be turned off automatically

将耳机放回充电盒并合上盖子，将自动关机

Gesture control

手势控制

1. Tap the right or left earbuds to play/pause music or answer/end phone calls.

轻敲右耳或左耳一次可播放/暂停或接听/挂断电话

2. During the music mode, double tap the right earbuds to skip to the next song

播放音乐状态下，双击右耳播放下一曲

During the music mode, double tap the left earbuds to play the previous song

播放音乐状态下，双击左耳播放上一曲

3. Press and hold the right earbuds for 2 seconds to increase volume

长按右耳两秒增加音量

Press and hold the left earbuds for 2 seconds to decrease volume

长按左耳两秒减小音量

4. Triple-tap the right or left earbuds to awake Voice assistance

三击右耳或者左耳唤醒语音助手

5. Press and hold the right or left earbuds for 2 seconds to decline incoming call

长按右耳或者左耳 2 秒拒接来电

Charging instruction

充电说明

Before the first use, put the earbuds back into the charging case and close the charging case, connect the Type-c cable for charging

首次使用时，请将耳机放回充电盒并合上，连接 Type-c 线缆充电

Charging: The charging case indicator light will flash in red

充电中,充电盒指示灯红灯闪烁

Full charge: The charging case will become a steady red light after fully charged

充满电后，充电盒指示灯红灯常亮

[Headphone charging instruction](#)

[耳机充电说明](#)

When the battery level of the headphones is low, put into the charging case and close for charging

当耳机电量较低时，将耳机放入充电仓并合上充电

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ -Reorient or relocate the receiving antenna.
- ▶ -Increase the separation between the equipment and receiver.
- ▶ -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ -Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.