Eumspo

Wireless Headset Model: G3



User Manual

Before using this product, please read the instruction manual carefully to use the earbud correctly and safety.

WELCOME

Thank you for choosing G3 wirelsess Stereo Single Earbud. Please read below instructions carefully before use.It will help you set up and operate this product properly and enjoy the advanced

PRODUCT LISTS

Product lists





User Manual *1 Bluetooth Earbud *1 Charger Case *1





Charging Cable

Eartips*2 (S/M/L)

*If you find any of above product lists damaged or lost when you received, please contact the seller.

DETAILED DESCRIPTION

- ① Microphone
- ② Angle Adjustment Part 3 Multi-Function Button 4 Volume+
- ⑤ Volume-
- 6 Charging Display 8 Rotate Eartip



HOW TO WEAR THE EARPEICE



1.Adjust the angle of the earhook and the microphone boom ,and then hang the earhook on your auricle. 2. We have update a rotatable earplug to meet your requirements

for comfortable angles of wear. After you adjust the earhook, you can hold on the earplug to adjust the eartips angle to find a suitable position then you can wear the earpiece in your ear cannel confortable.

Step1

1- Open the charging case and take out the earbud Earbud will power on automatically and the light will flash (Ice Blue); 2- And will response with a voice prompt "Power on"; It enters the pairing mode and with a voice prompt "Pairing".

PAIRING

Step2

- 1- Turn on Bluetooth function on your phone via 'Setting'>'Blue-
- 2- Tap on "G3" on the retrieved device to connect; 3- After connecting completed, the earbud will response with a
- voice prompt "Connected"; 4- You can use the bluetooth headset to listing music or on a

At the next time you use this earbud, just need take out the blutooth earbud from charging case and turn on your bluetooth function of the smart device to automatically connect.

Wireless Headset Connection



MULTI-FUNCTION BUTTON HOW TO CHARGE

Operate Features Click the "MFB"button once Play/Pause Long Press the "-" button once Pre song Long Press the "+" button once Next song Press the +/- button once Volume +/Volume -Long press the MFB button for 3 seconds Reject call Answer call Press the MFB button once End call Press the MFB button twice to end the call Click the "MFB"button for 3 times Wake up Siri Long press the MFB button for 2 seconds Call Mute Mode to enter/exit when on a call


Please note: When you want enter a call mute mode, please do not click the button twice or press the button for a long time, it will end the call or turn off the headset.

② Charger(Just include the charge cable)

Charge the charging case

③ Power Bank

Plug the charge cable into the charging port, the LED light indicator on the power display will flash constantly; Will display 100 when charging case fully charged.



Charge the Headset

You can use the charging case to charge the headset. Put your headset into the charging case (Please make sure the charging box is fully charged), Close the lid of the charge case and it will charge for the headset automatically.

The headset is charging: The charging case indicator (LED indicator) keep lighting. The headset is fully charged: The charging case indicator(LED indicator) is off.

HOW TO TURN ON/OFF THE HEADSET WITHOUT CHARGING CASE

Turn on the headset

Long press on the MFB button for 3 seconds ,a voice prompt"Power on" that the earbud is turn on;

Turn off the headset

Long press on the MFB button for 5 seconds ,a voice prompt"Power off" that the earbud has been closed.



LED POWER DISPLAY

PRODUCT SPECIFICS

Model	G3
Bluetooth Version	Bluetooth 5.1
Net of headset	13g
Net of charging case	64g
Size of charging case	103x60x31mm
Battery capacity	110mAh(Earpiece) 400mAh (Charging case)
Charging time	1h-2h
Microphone sensitivity	-42bB±3dB
Usage time	Talk time:About 15 hours Music time:About 12 hours Standby time:About 500 hours (connected with device)
Input	DC4.7~5.7 (V)

TROUBLE SHOOTING

1.The headset cannot be connected to the smart device How to fix it:

- ①Confirm the status of the Bluetooth function;
- ②Turn off bluetooth function of your device, delete the historical connection and pairing again; ③ Or please try to connect other accessories device.

2. The headset can not be charged

- ① Make sure that the headset is correctly placed/stored in the
- ②Confirm the battery capacity of the charging case. 3Check whether the charging contact point of charging case or headset have spot or not.

3. The headset does not respond

How to fix it:

How to fix it:

Put the headset in the charging case back, close the lid and wait another 1 minute or so, then take out the headset, and try to connect again.

4. The charging case cannot be charged

- 1) Check whether the charging cable is tightly connected with the
- ②Check the remaining battery capacity.

5.The headset have no sound

③Replace another charge cable

How to fix it:

playback applications).

- ①Check whether the audio track is played via the smartphone
- ②Check the headset battery whether was run out of. 3 Increase the volume of headset and mobile devices (or music
- 4 Make sure that the correct mobile device is connected. ⑤ Please try to connect to other mobile devices.

SAFE PRECAUTIONS

- or high temperature environment. Otherwise, it may cause electric shock, heat generation, or fire;
- Do not disassemble or modify. Otherwise it may cause malfunction or electric shock;
- (non-burnable garbage). May cause fire or rupture;
- babies, that may cause suffocation if swallowed by children;
- Please don't increase the volume at the beginning;
- Please do not add water or objects to the charging case;
- Before charging, keep dry of the earbud and charging case;
- Please charge it regularly;

- Please do not place the wireless earbud in humid, dusty, oily,

- Please do not use it at high volume for a long time;
- Please do not damage the charging cable;

- Generally, please do not throw it away with garbage
- Please keep this device out of reach of children, infants and

- Do not touch the liquid with hands when the battery leaks;
- Do not use if there is any discomfort such as itching.

No matter the product is lost, outdated, broken or you just don't like this product, please contact our customer service, we will do our best to give you a satisfactory answer.



http://www.eumspo.io

Version:2.0 Date:2021/10/15

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, Eumspo may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the Wireless Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Headset .Connect the equipment into an outlet on a circuit different from that to which the receiver is

 Consult the dealer or an experienced radio/TV technician for help. Caution: Any changes or modifications to this device not explicitly approved by manufacturer

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be

could void your authority to operate this equipment

used in portable exposure condition without restriction.



EC REP

MADE IN CHINA

C&E Connection E-Commerce (DE) GmbH

Zum Linnegraben 20, 65933, Frankfurt am Main, Germany