



Tweeze-it



OPERATING INSTRUCTIONS


Thank You for purchasing "Tweeze-it"!

The first tweezers with HD camera that transmit the image of the tip of the tweezers to your smart phone wireless!

"Tweeze-It" has 2 parts. One is the tweezers and the second one is the camera and the power source. When you assemble them together it becomes "Tweeze-it".

FREE TWEEZE-IT APP

Scan the QR code or search for "Tweeze-it"



for iOS



for Android

*must have IOS V9 or Android V6 or later

TWEEZE-IT SPECIFICATIONS

Model	TWEEZE-IT
Camera Resolution	720p HD
Wireless Range	3-5 feet
Operating Time	Up to 200 minutes
Charge Up Time	~115 minutes
Frequency	2.4GHz
Operating Voltage	5V DC
Power Adapter	5V 1A
Operating Temperature	14°F to 113°F (-10°C to 45°C)
Storage Temperature	14°F to 95°F (-10°C to 35°C)
Altitude	Not higher than 2000m (air pressure not less than 1.013×10^5 Pa)

How to use Tweeze-it product?

1. Use the provided USB cable and connect it to a power source so the unit will charge.
2. As soon as the red LED turns on (not flashing), the unit is currently charging. When the red LED turns off, the unit is fully charged and ready to use. (The first charge will take some time)
3. From your IOS App store or Google Play store download the “Tweeze-it” App.
4. Press the power button for 3 seconds until the white LED flashes to indicate powering on. Have the product close to your phone and open the Wi-Fi communication on your phone.

5. Choose the Tweeze-it-**** WLAN Address, the white LED will stay on (not flashing) once connected.
6. Go back to the "Tweeze-it" App and open the App.
7. Press the arrow on the screen and your "Tweeze-it" will show the image of the tip of the tweezers on your phone screen.

Enjoy!!!

The picture transmission is in the range of 3-5 feet.

You can take video as well as single picture via the application screen.

Both options are on the App screen and they are private only to be saved on your phone.

You will also find the Battery charge level display on the App home page. Please charge when it is low.

NOTE: The product will not link via Bluetooth – it is WiFi only.

If the unit fails to power on after reinstalling the battery, please connect it to a power source using the provided USB cable to activate the battery protection IC and allow the unit to power on.

DIGITAL ZOOM

To zoom in on your image, use two fingers or double-tap the screen.

APP SETTINGS

To access Settings, tap the Gear Icon on the screen.




The Settings screen allows you to do the following:

1. Change camera resolution from 720p to 360p, if lower resolution is required.

2. Change to a different WiFi channel if interference from other devices is preventing your Tweeze-it product from connecting to your App. (The recommended or default setting is Auto).

3. Display Modes have Normal (picture orientation reflects camera orientation), Always Up Round and Full Screen – either Round or Full Screen.



WARNING:

- replacement of a battery with an incorrect type may defeat a safeguard;
- disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, may result in an explosion;
- leaving a battery in an extremely high temperature surrounding environment, such as sunshine, fire, or hot surface may result in an explosion or the leakage of flammable liquid or gas;
- a battery subjected to extremely low air pressure may result in an explosion or the leakage of flammable liquid or gas.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can

radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

TWEEZE-IT WARRANTY

Your TWEEZE-IT comes with one year replacement warranty

