Bluetooth

nicole miller
NEW YORK

true wireless
EARBUDS
User Manual



Pairing Instructions:

1. To start the pairing process turn on the Bluetooth™ device

2. Open the charging case and remove the earbuds. They will automatically turn on and start searching for a Bluetooth™ device.
3. Go to your Bluetooth™ settings on your device and click on ***NicoleMiller***. When the earbuds are paired successfully you will hear a voice prompt indicating that they are paired successfully.

Please note: make sure the two devices via Bluetooth™ devices are within 32 feet in order for them to be paired.

Once the earbuds are paired successfully, they will reconnect to the device automatically when turned back on.



Glow earbuds can be connected to these Bluetooth™ devices.

Multi-Function Key

- **Answer The Call:** Click the left or right earbud 1 time
- **Hang Up:** Click the left or right earbud 1 time
- **Reject The Call:** Press the left or right earbud for 2 seconds
- **Play/Pause Music:** In the standby mode, click the left or right earbud's multi-function keys to play music directly. When playing music, click the left or right earphone's multi-function keys to pause music.

Low Battery Alert

When the earbud battery is low it will play the warning sound every 30 seconds until the headset shuts off.

Charging the Earbuds & Case

Charging the Earbud Case: connect the earbud case and wall charger by USB cable.

Charging the Earbuds: Place the earbuds in the charging case. The case will automatically charge earbuds. The red light means it is charging, The light will turned off when the earbuds are fully charged.

Turn On/Off

The earbuds will automatically turn on when they are taken out of the charging case. However if they do not turn on, press and hold the left or right earbud of 3 seconds.

The earbuds will automatically turn off once they are placed in the charging case or press and hold the left or right earbud for 5 seconds.

Specifications:

- **Bluetooth™ Version:** 5.2
- **Operating Distance:** 30 Feet
- **Battery Capacity:** 300 mAh
- **Music Playtime:** 4 Hours
- **Charge Time:** 1-2 Hours

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF expo sure requirement.
The device can be used in portable exposure condition without restriction.