

Product Manual

Aroma Diffuser

- ☐

A-H333S-B
- ☐

A-H333S-W
- ☐


A-H333M-B
- ☐

A-H333M-W
- ☐

A-H333L-B
- ☐


A-H333L-W

Please read the function introduction based on the product model.




【Product Information】

Packing List




Model	A-H333S-B/A-H333S-W	A-H333M-B/A-H333M-W	A-H333L-B/A-H333L-W
Dimension	167*188*86mm/0.5*0.6*0.2ft	220*243*111mm/0.7*0.7*0.3ft	259x292x119mm/0.8*0.9*0.3ft
Bottle Capacity	200ml	500ml	1000ml
Voltage	DC 12V	DC 12V	DC 12V
Power	5.1W	8W	10.6W
Coverage	500m³/5381ft² 1500m³/52972ft³	1200m³/12916ft² 3600m³/127132ft³	1700m³/18298ft² 5100m³/180104ft³
Net Weight	1.4kg	2.4kg	3.4kg

【Function Description】



How to Add Essential Oil



Add successfully

Select room

Select a existing room

Home

+

Next

Assign the device to a location/area, then tap "Next".

Congratulations

Your device is connected. Enjoy!

Please choose a name for your device

A-H333

What is a single name for your device and content name?

Done

Tap here to rename the device.

Tap "Done". (Once the device is successfully added, the app will automatically return to the homepage, where the connected device will appear.)

Scenario Usage Guide

A-H333

Timed work

Length of Time

Set

Smart Scenario

Mode

Default

Essential Oil Info

Essential oil remaining

0%

Tap "Smart Scenarios" to enter the "Smart Timer Scenario" page.

Edit Scenario

Scenario name

Default

02:00 - 15:00

Level 17

MON-FRI

Adding a scheduled task

+

Save

Save and execute

Tap the "Scenario Name" to name your scenario.

Tap " " to turn the task schedule on or off.

Tap "Add Task Schedule" to add a new task.

Tap "Save" to save the settings without execution.

Tap "Save and Run" to save and start executing the task.

Smart Scenario

Mode

Default

Essential Oil Info

Essential oil remaining

0%

Tap "+" to add a scenario.

Tap "Stop/Run" to stop or start executing the preset scenario task.

Tap the chart directly to enter the editing interface.

Edit Scenario

Scheduled Task

Repeat

Start Time

End Time

Level

Cancel

Save

Select working days, start time, stop time, and grade, and don't forget to tap "Save."

WARNING

Safety Instructions

To ensure safe use and prevent harm or property damage, please follow these safety precautions. Failure to comply with these warnings may result in accidents. This product is not designed for the following situations:

- Use by unattended infants, individuals with disabilities, or those with cognitive impairments.

- Use as a toy by young children.

Usage and Storage Instructions

1.This aroma diffuser is designed for use with essential oils. Please read the manual carefully before use.

2.This product is not suitable for individuals with weakened health (including children). Elderly, pregnant individuals, and those with physical, sensory, or intellectual impairments should consult a doctor before use. Those lacking experience or knowledge, especially children, must be supervised by a responsible person to ensure safe use. Otherwise, they should be prevented from accessing the device.

3.The optimal operating temperature for the machine is 20-35°C, with a relative humidity of <85%. Diffusion performance may vary depending on environmental temperature and humidity.

4.Store essential oils in a cool, dry place with the cap securely closed, away from direct sunlight. The recommended storage temperature is around 25°C.

5.Dispose of the product and protective packaging materials in accordance with local regulations.

Prohibited Guidelines

1.Keep away from fire sources.

2.Do not ingest essential oil; seek medical attention if swallowed.

3.Do not use for purposes other than space diffusion; do not apply fragrance essential oil directly to the skin.

4.Avoid extreme temperatures (below -5°C or above 40°C).

Mandatory Guidelines

1.Keep out of reach of children and pets to prevent accidental ingestion. Supervise children to ensure they do not play with the device.

2.Do not modify, disassemble, or repair the machine unless you are a qualified technician. If a malfunction occurs, contact customer service from the original purchase channel.

3.Stop using the device immediately if any abnormalities occur during or after use.

4.Place the machine on a level surface and keep it upright after installation. Tilting or placing the device flat may cause oil leakage or malfunction.

5.Wipe up any spilled essential oil immediately.

Potential Risks of Injury or Property Damage

1. The following actions may cause electric shock, short circuits, or fire hazards:

- Do not get the machine or charging port wet.

- Do not use overloaded power outlets, damaged cords, or faulty plugs.

2. When adding essential oil, avoid excessive pressure to prevent leakage and damage to machine components.

3. Do not pull, crush, cut, or tamper with the power cord.

4. To prevent malfunctions or damage, do not disassemble the machine during use.

5. If the adapter, charging cable, or power cord is damaged, it must be replaced with a specialized component provided by the manufacturer or authorized service provider.

6. Use only the specified low-voltage power supply as marked on the device.

7. Only use the power adapter included with the product.

8. Use only the recommended evaporation medium. Using other substances may pose toxic or fire risks.

Essential Oil Remaining: (For devices that do not auto-detect oil levels, please manually input the initial amount before use. The system will automatically update the data afterward.)

Steps to add essential oil.

Empty Bottle Calibration: When using for the first time, place an empty bottle into the machine and calibrate it to 0%, then add essential oil before operating.

Troubleshooting

If the aroma diffuser is not functioning properly, please check the following and attempt to resolve the issue.

Issue	Possible Causes	Solutions
Device not working	The battery has run out of power.	Charge the device in time.
No mist or weak mist	The atomizing core is clogged.	Clean the atomizing core with a professional cleaner to remove internal residue or replace it with a new one. (Recommended cleaning every 3 months.)
	The liquid tube is not securely attached.	Check and tighten the loose parts.
Oil leakage	The gasket between diffuser head and bottle may be loose or damaged.	Secure the bottle properly or replace the gasket if damaged.
	The bottle is not properly secured.	Check and tighten the loose parts.
Liquid spray	The gasket between diffuser head and bottle may be loose or damaged.	Secure the bottle properly or replace the gasket if damaged.
	The atomizing core is clogged.	Clean the atomizing core with a professional cleaner to remove internal residue or replace it with a new one. (Recommended cleaning every 3 months.)
	The device is tilted.	Ensure the device remains upright during use.
Unusual noise	The essential oil level is too high.	Do not overfill the bottle—keep the essential oil level below 90% capacity.
	The air pump is not secured.	Inspect and re-secure the pump if loose.
	The essential oil level is too high.	Do not overfill the bottle—keep the essential oil level below 90% capacity.

Cleaning & Maintenance

Cleaning and Maintenance
When to Clean the Device.
Cleaning is required in the following situations:
1. When change to a different essential oil.
2. When you notice a decrease in mist output performance.
Tip: We recommend regular cleaning—about once every 3 months.

Cleaning Steps

You will need: Alcohol

1.Connect the power. After unlocking via touch control or the app, lift the diffuser head and unscrew the essential oil bottle.

2.Pour a suitable amount of alcohol into the bottle (30%–90% full), reinstall it into the device, and run it at the highest level or in Instant Diffusion mode for 15–30 minutes.

3.Pour out the remaining alcohol and let the diffuser sit until the bottle, suction tube, and nozzle are completely dry. Cleaning is now complete.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
Not applicable

RF Exposure
This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body. be installed and operated with minimum distance 20cm between the radiator & your body.

ISED Statement

Francais: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
The digital apparatus complies with Canadian CAN ICES - 3 (B)/NMB - 3(B).

English: This device contains license-free transmitters/receivers that are compliant with innovation, science and economic development Canada's license-exempt RSS.
The holding is subject to the following two conditions:
(1) this device must not cause interference.
(2) this device must accept any interference, including interference that may cause unwanted operation of the device.
Canadian compliant ices digital camera can-3 (b)/NMB-3 (b).

This device meets the exemption from the routine evaluation limits in section 6.3 of RSS 102 and compliance with RSS 102 of rf exposure, users can obtain Canadian information on RF exposure and compliance.

This device complies with the standard assessment limit exemption in section 6.3 of CNR - 102 and compliance with RSS 102 of rf exposure, users can obtain Canadian data on rf field exposure and compliance.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

This equipment complies with Canadian radiation exposure limits for an uncontrolled environment.

This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

This equipment should be installed and used at a minimum distance of 20 cm between the radiator and your body.

SAVE THESE INSTRUCTIONS

APP Operation Guide

Standard Mode

A-H333

Manual Mode

ON/OFF

Manual Scenario

Level

Quick-Fragrance

Customize the grade

Timed work

Length of Time

Set

Tap the " " button to turn the fan on or off.

Tap the " " button to lock/unlock the diffuser head. (Note: When the electronic lock is activated, it will heat up. Do not touch it directly with your hands, and avoid repeated short-interval operations to prevent overheating and failure.)

Tap the " " button to power the device on or off.

Swipe left or right to select grades (1–5); the far-right option is the Custom Mode.

A-H333

ON/OFF

Manual Scenario

Level

Quick-Fragrance

Customize the grade

Timed work

Length of Time

Set

In Custom Mode, swipe up/down to set work and stop time.

A-H333

ON/OFF

Manual Scenario

Level

Quick-Fragrance

Customize the grade

Timed work

Length of Time

Set

Quick Fragrance: Activates high-efficiency scent diffusion for 5 minutes (sprays for 55 seconds, stops for 5 seconds, repeated 5 times).

Tap "Set" then swipe to set the desired working period. The machine will shut off automatically when the time ends.

Remaining Oil Level Setting

A-H333

Smart Scenario

Mode

Default

Essential Oil Info

Essential oil remaining

0%

Tap "Essential oil remaining" to enter the "Essential Oil" settings page.

A-H333 essential oil replacement

1. Lift the atomizing head assembly.

2. Unscrew the atomizing head and bottle.

3. Fill the bottle with essential oil and then tighten the bottle and atomizer head again.

4. Plug the used cap into and reconnect the bottle and atomizer head back into the machine.

Essential oil remaining

0%

Essential Oil Remaining: (For devices that do not auto-detect oil levels, please manually input the initial amount before use. The system will automatically update the data afterward.)

Steps to add essential oil.

Empty Bottle Calibration: When using for the first time, place an empty bottle into the machine and calibrate it to 0%, then add essential oil before operating.

Change Password (Bluetooth version only)

A-H333

Manual Mode

ON/OFF

Manual Scenario

Level

Quick-Fragrance

Customize the grade

Timed work

Length of Time

Set

Tap " " to enter the device settings page.

A-H333

Device Settings

Device Name

MAC

PCBA

Firmware

Change Password

Room

New password

No

Confirm

Factory data reset

Tap "Change Password" to enter the password update interface.

Enter a new 4-digit password and tap Confirm.

Note: If you forget the password, press and hold the reset button on the device to restore factory settings. Then enter the default password "8888" to re-add the device. The app is continuously being updated and improved, so the interface and functions may vary depending on the version. Please refer to the actual interface for accuracy.